YING RAY 2018081201

YING RAY Replacement Remote Control for LG Air Conditioner

Model: 6711A20111H / 2018081201

1. Introduction

This manual provides instructions for the YING RAY replacement remote control designed for LG Air Conditioner models, specifically compatible with the 6711A20111H original remote. This remote control operates without programming; simply insert batteries to begin use.



Figure 1: YING RAY Replacement Remote Control. This image displays the front view of the remote control, showing its LCD screen and various control buttons.

2. Safety Information

- Keep batteries out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period.
- Avoid dropping the remote control or exposing it to moisture.

3. Setup and Battery Installation

The remote control requires two "AAA" 1.5V ordinary batteries (not included). Follow these steps for proper battery installation:

1. Open the battery compartment cover on the back of the remote control.
2. Insert two "AAA" batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Close the battery compartment cover securely.

Important Note on Battery Types: There are two common types of AAA batteries ("A" and "B") with slightly different positive pole lengths. If the remote does not function after battery installation, refer to the troubleshooting section regarding battery contact.



Figure 2: Battery Installation and Adjustment. This image illustrates the difference between battery types "A" (longer positive pole) and "B" (shorter positive pole), and demonstrates how to gently pull out the battery spring for Type "B" batteries to ensure proper contact.

4. Operating Instructions

Once batteries are installed, the remote control is ready for use without any further programming. Point the remote control directly at the air conditioner's receiver.

Common Functions:

- **Power Button:** Turns the air conditioner ON or OFF.
- **Mode Button:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temperature Adjustment Buttons (Up/Down Arrows):** Increases or decreases the desired temperature.
- **Fan Speed Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Swing Button:** Controls the louver swing function.
- **Timer Button:** Sets the ON/OFF timer for the air conditioner.
- **Sleep/Eco Button:** Activates sleep mode or energy-saving functions.

Note: Specific button labels and functions may vary slightly depending on your LG Air Conditioner model. Refer to your air conditioner's original manual for detailed function descriptions.

5. Maintenance

- Clean the remote control regularly with a soft, dry cloth.
- Do not use liquid cleaners or abrasive materials.
- Keep the remote control away from direct sunlight and heat sources.

6. Troubleshooting

Remote Control Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-).
- **Replace Batteries:** If the batteries are old or depleted, replace them with new "AAA" 1.5V batteries.
- **Battery Contact Issue (Type "B" Batteries):** If you are using batteries with a shorter positive pole (Type "B" as shown in Figure 2), the battery's positive pole might not be making proper contact with the remote's spring. Gently pull the battery spring out a little to ensure a secure connection. Refer to Figure 2 for visual guidance.
- **Obstruction:** Ensure there are no obstructions between the remote control and the air conditioner's receiver.
- **Distance:** Make sure you are within the effective operating range of the air conditioner.

7. Specifications

Feature	Detail
Model Number	2018081201
Compatible with	LG Air Conditioner Remote Control 6711A20111H
Power Source	2 x "AAA" 1.5V Batteries (not included)
Special Feature	Ergonomic design
Max Number of Supported Devices	1

8. Warranty and Support

This product is a replacement remote control and typically comes with a standard manufacturer's warranty. For specific warranty details or technical support, please refer to the seller's information or contact YING RAY customer service through your purchase platform.

For returns or replacements, please consult the return policy of your retailer. (e.g., Amazon's 30-day return policy for this item).