Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 2018081210

YING RAY Replacement Air Conditioner Remote Control User Manual

Model: AR-DB1, ASY9ASGCW, ASY12ASGCW (Model Number: 2018081210)

Introduction

This manual provides instructions for the YING RAY Replacement Air Conditioner Remote Control, designed for specific air conditioner models including AR-DB1, ASY9ASGCW, and ASY12ASGCW. This remote control is a direct replacement and does not require programming for immediate use.

Important Note: This remote control displays temperature in Celsius only and is not a universal air conditioner remote control.

Setup

Battery Installation

The remote control operates on two "AAA" 1.5V ordinary batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two "AAA" batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.



Figure 1: Battery Installation Tips. This image illustrates two types of AAA batteries (Type A and Type B) and shows how to properly insert them into the remote's battery compartment. It also provides a visual guide for adjusting the positive pole spring for Type B batteries to ensure proper contact.

Note on Battery Types: In some regions like USA & Canada, there are two kinds of battery types, "A" and "B". Type "A" is slightly longer than "B" at the positive pole. If using a Type "B" battery, you may need to gently pull the positive pole spring out a little to ensure good contact, as shown in Figure 1.

Operating Instructions

Once batteries are installed, the remote control is ready for use without any additional programming. Point the remote control directly at the air conditioner's receiver.



Figure 2: Remote Control Layout. This image displays the front of the remote control, highlighting the various buttons and their functions, including Sleep, Timer, Master Control, Set Temp, Set Time, Fan Control, Set Swing, Time Adjust, ACL, and Start/Stop.

Button Functions:

- **START/STOP (Orange Button):** Powers the air conditioner On or Off.
- **SLEEP:** Activates or deactivates the sleep mode function.
- **TIMER:** Sets or cancels the timer function for automatic operation.
- **MASTER CONTROL:** Likely cycles through main operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **SET TEMP (+/-):** Adjusts the desired temperature setting. The display is in Celsius only.
- **SET TIME:** Used to set the current time or adjust timer settings.

- **FAN CONTROL:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **SET SWING:** Controls the horizontal or vertical swing of the air conditioner's louvers.
- **TIME ADJUST:** Fine-tunes time settings.
- **ACL (Accessory Clear/Reset):** A small recessed button, typically used for resetting the remote or clearing certain settings. May require a pointed object to press.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's range decreases or the display becomes dim. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.
- **Avoid Exposure:** Keep the remote control away from direct sunlight, high temperatures, and high humidity.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with correct polarity.
  - Replace old batteries with new "AAA" 1.5V batteries.
  - Ensure there are no obstructions between the remote and the air conditioner's receiver.
  - Confirm you are within the effective operating range of the air conditioner.
- **Display is dim or blank:**
  - Batteries are low; replace them.
- **Air conditioner not responding to specific functions:**
  - Ensure the remote is compatible with your specific air conditioner model (AR-DB1, ASY9ASGCW, ASY12ASGCW). This remote is not universal.
  - Some functions may be specific to certain air conditioner models or modes.

Specifications

Feature	Detail
Brand	YING RAY
Model Number	2018081210
Compatible Models	AR-DB1, ASY9ASGCW, ASY12ASGCW
Compatible Devices	Air Conditioner
Power Source	2 x "AAA" 1.5V Batteries (not included)
Display Unit	Celsius Only
Special Feature	Ergonomic design
Manufacturer	ZHUHAI YINGRAY TRADING CO., LTD.

ASIN	B07GD2XY78

© 2024 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GD2XY78

More documents and user manuals: **https://manuals.plus/**