Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi ICM17210

De'Longhi ICM17210 Drip Coffee Machine User Manual

Model: ICM17210

1. Introduction

This manual provides essential information for the safe and efficient operation of your De'Longhi ICM17210 Drip Coffee Machine. Please read these instructions thoroughly before first use and retain them for future reference.

2. Important Safety Instructions

Observe the following safety precautions to prevent personal injury or damage to the appliance:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The carafe is designed for use with this appliance. It must never be used on a range top.
- Do not place a hot carafe on a wet or cold surface.
- Do not use a cracked carafe or a carafe having a loose or weakened handle.

- Do not clean carafe with cleansers, steel wool pads, or other abrasive material.
- This appliance has a grounded plug. Please ensure your wall outlet is properly grounded.

3. Product Overview

The De'Longhi ICM17210 is a drip coffee machine designed for ease of use and consistent coffee brewing. It features an automated pour-over system and an anti-drip function.

Components:

- Water Reservoir
- Filter Holder
- Glass Carafe (1.25L capacity, approximately 10 cups)
- Lid
- Heating Plate
- Control Panel (Power button, Brew button)
- Water Level Indicator



Figure 1: De'Longhi ICM17210 Drip Coffee Machine. This image displays the complete coffee machine, highlighting its glass carafe, water reservoir, and control buttons at the base.

4. Setup and First Use

4.1 Unpacking

Carefully remove all packaging materials and ensure all components are present and undamaged. Dispose of packaging responsibly.

4.2 Initial Cleaning

Before brewing coffee for the first time, clean the machine to remove any manufacturing residues:

1. Wash the glass carafe and filter holder in warm, soapy water. Rinse thoroughly and dry.
2. Fill the water reservoir with fresh cold water up to the MAX level.
3. Place the empty filter holder and carafe in position.
4. Run a full brewing cycle without coffee grounds. Discard the water.
5. Repeat this process 2-3 times to ensure the machine is clean.

5. Operating Instructions

5.1 Brewing Coffee

1. Ensure the machine is plugged into a grounded electrical outlet.
2. Fill the water reservoir with fresh, cold water to the desired level, using the water level indicator. Do not exceed the MAX line.
3. Place a paper filter (size 4, not included) into the filter holder.
4. Add the desired amount of ground coffee into the filter. A general guideline is one tablespoon of coffee per cup (150ml). Adjust to personal preference.
5. Close the lid securely.
6. Place the empty glass carafe onto the heating plate.
7. Press the Power button to start the brewing cycle. The indicator light will illuminate.
8. The machine will automatically brew the coffee using its automated pour-over system.
9. Once brewing is complete, the machine will keep the coffee warm on the heating plate. The anti-drip system prevents dripping when the carafe is removed during brewing.
10. The machine features an **Auto Shut-Off** function, which will turn off the heating plate after a period of inactivity to conserve energy.

5.2 Important Notes

- Always use fresh, cold water for optimal coffee taste.
- Do not open the lid or remove the filter holder during the brewing cycle.
- The heating plate keeps coffee warm but is not intended for reheating cold coffee.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your coffee machine.

6.1 Daily Cleaning

1. Unplug the machine and allow it to cool completely.
2. Remove the filter holder and discard the used coffee grounds and paper filter.
3. Wash the glass carafe and filter holder in warm, soapy water. Rinse thoroughly and dry. These parts may also be top-rack dishwasher safe (consult product manual for specific confirmation).
4. Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or immerse the machine in water.

6.2 Descaling

Mineral deposits from water can affect machine performance and coffee taste. Descale your machine regularly, depending on water hardness and frequency of use (e.g., every 2-3 months).

1. Prepare a descaling solution according to the descaler manufacturer's instructions, or use a mixture of white vinegar and water (e.g., 1 part vinegar to 2 parts water).
2. Pour the descaling solution into the water reservoir.
3. Place an empty paper filter in the filter holder and the empty carafe on the heating plate.
4. Run a brewing cycle. After about half the solution has brewed through, turn off the machine and let it sit for 15-20 minutes to allow the solution to work.
5. Turn the machine back on and allow the remaining solution to brew through.

6. Discard the solution from the carafe.
7. Rinse the machine by running 2-3 full cycles with fresh, cold water only, discarding the water after each cycle.

7. Troubleshooting

If you encounter issues with your coffee machine, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; verify power supply; try a different outlet.
Coffee is not brewing.	No water in reservoir; filter holder not correctly placed; machine needs descaling.	Fill water reservoir; ensure filter holder is seated properly; perform descaling procedure.
Coffee tastes weak.	Not enough coffee grounds; coffee too coarsely ground; machine needs descaling.	Increase coffee amount; use finer ground coffee; descale the machine.
Coffee overflows from filter.	Too much coffee grounds; filter clogged; carafe not on heating plate.	Reduce coffee amount; ensure filter is not clogged; place carafe correctly.
Water leaks from machine.	Water reservoir overfilled; components not correctly assembled.	Do not exceed MAX fill line; ensure all removable parts are correctly in place.

8. Specifications

Brand	De'Longhi
Model Number	ICM17210 (0132301135)
Color	Silver
Product Dimensions (L x W x H)	18 x 28 x 33 cm
Capacity	1.25 Liters (approx. 10 cups)
Power / Wattage	1800 watts
Voltage	230 Volts
Material	Metal, Glass
Item Weight	3.55 Kilograms
Special Features	Auto Shut-Off, Anti-Drip System, Keep Warm Plate, Water Level Indicator

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official De'Longhi website. Keep your proof of purchase for any warranty claims.
For further assistance, you may contact De'Longhi customer service through their official channels.

© 2024 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GFRGF5M

More documents and user manuals: **https://manuals.plus/**