Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEDIS KACM210EAL

Nedis KACM210EAL Coffee Maker User Manual

Model: KACM210EAL | Brand: NEDIS

Introduction

This manual provides instructions for the safe and efficient use of your Nedis KACM210EAL coffee maker. Please read these instructions carefully before use and keep them for future reference. This appliance is designed for household use only.

Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions:

- Read all instructions before operating the appliance.
- Do not immerse the power cord, plug, or the coffee maker itself in water or other liquids.
- Close supervision is necessary when the appliance is used by or near children.
- Unplug the coffee maker from the electrical outlet when not in use and before cleaning. Allow it to cool before adding or removing parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- Do not use the appliance outdoors.
- Do not let the power cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place the coffee maker on or near a hot gas or electric burner, or in a heated oven.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to 'off', then remove the plug from the wall outlet.
- Do not use the appliance for purposes other than its intended use.
- The appliance must be placed on a flat, stable surface during operation.

Product Components



Image: The Nedis KACM210EAL coffee maker, showing its stainless steel and black design, glass carafe, and visible water level indicator on the side.

1. Top Lid
2. Water Reservoir
3. Water Level Indicator
4. Filter Basket
5. Permanent Filter (removable)
6. Glass Carafe with Handle

7. Warming Plate
8. Control Panel (Display, Power Button, Program Button, Hour Button, Minute Button)

Setup

Before using your coffee maker for the first time:

1. Unpack the coffee maker and remove all packaging materials.
2. Clean all removable parts (glass carafe, filter basket, permanent filter) with warm, soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the coffee maker with a damp cloth.
4. For initial cleaning of the internal system, fill the water reservoir to the '12 Max' level with cold water. Place the empty glass carafe on the warming plate. Run two full brewing cycles without coffee. Discard the water after each cycle.

Operating Instructions

Brewing Coffee



Image: The top lid of the coffee maker is open, revealing the filter basket where coffee grounds and water are added.

1. Open the top lid and fill the water reservoir with fresh, cold water up to the desired level, using the water level indicator on the side. Do not exceed the '12 Max' mark.
2. Place the permanent filter into the filter basket. If using a paper filter (size 1x4), place it inside the permanent filter or directly into the filter basket.
3. Add the desired amount of ground coffee to the filter. A general guideline is one scoop (approximately 7 grams) per cup. Adjust to your taste.
4. Close the top lid securely.
5. Place the empty glass carafe on the warming plate. Ensure it is correctly positioned to activate the drip-stop mechanism.
6. Plug the coffee maker into a grounded electrical outlet. The display will show '00:00'.
7. To start brewing immediately, press the **Power button** (**U**). The indicator light will illuminate, and brewing will begin.

Setting the 24-Hour Programmable Timer



Image: A close-up of the coffee maker's control panel, featuring a digital display showing '00:00' and buttons labeled 'U' (Power), 'P' (Program), 'H' (Hour), and 'M' (Minute).

1. First, set the current time: Press the **'H'** (Hour) button to set the hour and the **'M'** (Minute) button to set the minutes. The clock operates in a 24-hour format.
2. To set the automatic brewing time, press the **'P'** (Program) button once. The display will flash.
3. Use the **'H'** and **'M'** buttons to set the desired time for brewing to start.
4. Press the **'P'** button again to confirm the programmed time. The indicator light next to the 'P' button will illuminate, indicating that the timer is active.
5. The coffee maker will automatically start brewing at the set time.

Keep Warm Function

After brewing is complete, the coffee maker will automatically switch to a keep-warm function. The warming plate will keep the coffee hot for approximately 40 minutes, after which the appliance will automatically shut off for safety and energy saving.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your coffee maker.

Daily Cleaning

- Always unplug the coffee maker and allow it to cool completely before cleaning.
- Wash the glass carafe, filter basket, and permanent filter in warm, soapy water after each use. Rinse thoroughly and dry. These parts are not dishwasher safe.
- Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the surface.
- Do not immerse the main unit in water or any other liquid.

Descaling

Mineral deposits from water can build up in your coffee maker over time, affecting its performance and coffee taste. Descale your coffee maker every 2-4 months, or more frequently if you have hard water.

1. Fill the water reservoir with a descaling solution (e.g., white vinegar and water in a 1:2 ratio, or a commercial descaling agent) according to the descaler's instructions.
2. Place an empty glass carafe on the warming plate.
3. Run a brewing cycle with the descaling solution.
4. After the cycle, let the solution sit in the carafe for approximately 15 minutes.
5. Discard the solution and rinse the carafe thoroughly.
6. Fill the water reservoir with fresh, cold water and run 2-3 full brewing cycles with water only to rinse out any remaining descaling solution.

Troubleshooting

Problem	Possible Cause	Solution
Coffee does not brew.	No power, water reservoir empty, filter basket not correctly placed.	Check power connection. Fill water reservoir. Ensure filter basket is properly seated.
Coffee tastes weak or too strong.	Incorrect coffee-to-water ratio.	Adjust the amount of coffee grounds or water according to your preference.
Coffee maker is leaking.	Carafe not positioned correctly, filter basket overflowing.	Ensure the glass carafe is fully pushed onto the warming plate. Do not overfill the filter basket with coffee grounds.
Timer function is not working.	Timer not activated after setting.	After setting the desired brew time, press the 'P' button again to activate the timer. The indicator light should be on.
Coffee is not hot enough.	Keep warm function has ended.	The keep warm function lasts for approximately 40 minutes. Brew fresh coffee for optimal temperature.

Specifications

Feature	Specification
Brand	NEDIS
Model Number	KACM210EAL
Capacity	1.5 Liters (12 cups)
Power	1080 Watts
Material	Stainless Steel, Plastic
Dimensions (D x W x H)	25.5 cm x 26.5 cm x 38.6 cm
Special Features	24-hour programmable timer, Keep warm function, Drip-stop
Filter Type	Reusable permanent filter

Warranty and Support

This Nedis KACM210EAL coffee maker comes with a **2-year warranty** from the date of purchase. Please retain your proof of purchase for any warranty claims.
For technical support, service, or warranty claims, please contact your retailer or visit the official Nedis website for further assistance. You can find more information and contact details at www.nedis.com.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GH3XGTD

More documents and user manuals: **https://manuals.plus/**