Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro LC-19LE320E-BK

Passion-Electro Replacement Remote Control for SHARP LC-19LE320E-BK TV

User Manual

Introduction

Thank you for choosing the Passion-Electro Replacement Remote Control. This remote is specifically designed to function with SHARP LC-19LE320E-BK TV models, providing full access to all original remote control functions without the need for any programming. Simply insert the batteries, and it is ready for use.



Image: Side view of the remote control, highlighting the Passion-Electro brand.

Product Overview

This replacement remote control offers a layout and functionality similar to your original SHARP TV remote. It features a durable design and an intuitive button arrangement for ease of use.



Image: Top-down view of the remote control, showing the complete button layout.

Setup

Battery Installation

The remote control requires two AAA (LR03) 1.5V batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

The remote is now ready for use. No programming is required.



Image: Back view of the remote control, illustrating the battery compartment.

Operating Instructions

This remote control operates via infrared (IR) technology. Ensure there is a clear line of sight between the remote and your SHARP TV for optimal performance.

Basic Functions

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** Selects channels directly.
- **Volume Up/Down:** Adjusts the sound level.
- **Channel Up/Down:** Changes channels sequentially.
- **Mute Button:** Silences the TV audio.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used for menu navigation and selection.
- **Menu Button:** Accesses the TV's main menu.

- **Source/Input Button:** Switches between different input sources (HDMI, AV, etc.).
- **Colored Function Buttons:** (Red, Green, Yellow, Blue) These buttons perform specific functions depending on the TV mode or on-screen prompts.



Image: Front view of the remote control, highlighting key operational buttons.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.
- **Avoid Exposure:** Do not expose the remote to direct sunlight, heat, moisture, or extreme temperatures.

Troubleshooting

- **Remote not working:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote and the TV's IR receiver.
  - Confirm the remote is pointed directly at the TV.
- **Limited functionality:**
  - While this remote is designed for the SHARP LC-19LE320E-BK, some specific advanced functions might require the original TV remote or specific TV settings.
- **LED indicator not lighting up:**
  - This usually indicates dead or incorrectly inserted batteries. Replace or reinsert batteries.

Specifications

- **Brand:** Passion-Electro
- **Model Compatibility:** SHARP LC-19LE320E-BK TV
- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** Television
- **Batteries Required:** Yes
- **Battery Type:** 2 x AAA (LR03) 1.5V (not included)
- **Special Feature:** No programming required
- **Item Weight:** Approximately 100 grams

Warranty and Support

This product is covered by standard consumer guarantees. For any issues or support inquiries, please refer to the seller's return policy or contact the seller directly through your purchase platform. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GJXQVF1

More documents and user manuals: **https://manuals.plus/**