Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

dbest products 01-769

dbest products Smart Cart Model 01-769 Instruction Manual

For the Rolling Multipurpose Collapsible Basket (Blackout Standard)

1. Introduction

The dbest products Smart Cart Model 01-769 is a versatile, rolling multipurpose collapsible basket designed for convenient transport and storage. Its lightweight yet durable construction makes it suitable for various tasks, from grocery shopping to carrying office supplies. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your Smart Cart.

This utility cart is engineered for ease of use, featuring a retractable handle and smooth-rolling wheels. When not in use, it folds flat for compact storage, making it an ideal solution for individuals seeking portable and efficient hauling.

2. Product Features

- **Multipurpose Use:** Ideal for groceries, school supplies, office materials, laundry, and more.
- **Collapsible Design:** Folds flat to 2 inches for compact storage.
- **Lightweight & Durable:** Weighs 3 lbs, supports up to 110 lbs.
- **Retractable Handle:** Extends up to 41 inches for comfortable pulling.
- **Smooth-Gliding Wheels:** Designed for easy navigation.
- **Weatherproof Material:** Constructed from Polyester Denier.
- **Ergonomic Curvature:** Handle designed for reduced effort when pulling heavy loads.
- **Non-Slip Rubber Grip:** Provides a secure hold.



Image 2.1: Detailed view of the Smart Cart's key features, highlighting the non-slip grip, ergonomic handle, weatherproof fabric, and ball bearing wheels for enhanced usability and durability.

3. Setup and Unfolding

The Smart Cart is designed for quick and easy setup. Follow these steps to unfold your cart:

1. Place the folded cart on a flat, stable surface.
2. Grasp the top edges of the cart and gently pull them apart. The cart's sides will expand, forming the basket shape.
3. Ensure the bottom panel is fully extended and flat to provide a stable base.
4. Extend the telescoping handle by pressing the button on the handle grip and pulling upwards until it locks into your desired height.







Image 3.1: The Smart Cart fully unfolded and ready for operation.



Image 3.2: Visual representation of the Smart Cart's dimensions when unfolded, indicating its capacity.

4. Operating Instructions

4.1. Loading the Cart

- Open the top flap of the cart.
- Place items inside the main compartment. Distribute weight evenly to maintain balance.

- Do not exceed the maximum weight capacity of 110 lbs (approximately 50 kg).
- Close the top flap securely using the hook-and-loop fasteners to protect contents.



Image 4.1: A user loading the Smart Cart with groceries.

4.2. Transporting Items

- Ensure the telescoping handle is extended to a comfortable height.
- Grasp the non-slip rubber grip firmly.
- Tilt the cart slightly backward to engage the wheels and pull it along. The ergonomic handle design assists in pulling heavier loads with less effort.
- Navigate smoothly, avoiding sudden turns or impacts with obstacles to prevent damage to the wheels or frame.



Image 4.2: A user maneuvering the Smart Cart in a retail environment.



Image 4.3: The Smart Cart in use, demonstrating its portability.

5. Folding and Storage

To fold your Smart Cart for compact storage:

1. Empty the cart of all contents.
2. Retract the telescoping handle fully by pressing the button and pushing it down.
3. Push the side panels inward until the cart collapses flat.
4. Secure any fasteners or straps if present to keep the cart in its folded position.
5. Store the folded cart in a closet, car trunk, or under furniture.



Image 5.1: The Smart Cart folded for compact storage, demonstrating its space-saving design.

6. Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your Smart Cart.

- **Cleaning:** The Polyester Denier material can be spot cleaned with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. Allow to air dry completely before folding or storing.
- **Wheels:** Periodically check the wheels for debris or entanglement. Clean as needed to ensure smooth operation.
- **Handle:** Keep the telescoping handle mechanism free of dirt and obstructions. If the handle becomes stiff, a small amount of silicone lubricant can be applied to the extending shafts.
- **Storage:** Store the cart in a dry place away from extreme temperatures.

7. Troubleshooting

If you encounter issues with your Smart Cart, refer to the following common problems and solutions:

- **Handle not extending or retracting smoothly:**
  Solution: Check for any visible obstructions in the telescoping mechanism. Ensure the release button is fully depressed. Clean the handle shafts and apply a small amount of silicone lubricant if necessary.
- **Wheels not rolling smoothly or making noise:**
  Solution: Inspect the wheels for trapped debris (hair, string, dirt). Remove any obstructions. Ensure the wheels are securely attached. If a wheel is damaged, contact customer support for replacement options.
- **Cart does not stay unfolded or collapses unexpectedly:**
  Solution: Ensure the bottom panel is fully extended and flat when unfolding. Verify that the side panels are properly locked into place. Avoid overloading the cart beyond its 110 lbs capacity.
- **Frame appears bent or damaged:**
  Solution: Discontinue use if the frame is significantly damaged, as this can affect stability and safety. Contact customer support for assistance.

8. Specifications

Feature	Detail
Product Dimensions (Unfolded)	18"D x 10"W x 38"H
Brand	dbest products
Material	Polyester Denier, Aluminum (Frame)
Color	Blackout
Special Features	Collapsible, Compact, Easy Assembly, Foldable, Telescoping Handle
Number of Shelves	1
Recommended Uses	Indoor
Handle Material	Plastic
Tire Type	Tubeless
Item Weight	3 Pounds
Number of Wheels	2
Weight Limit	110 Pounds
Assembly Required	No
Item Model Number	01-769
UPC	818550021723

9. Warranty and Support

For warranty information or product support, please contact dbest products directly. Details regarding specific warranty periods and claims procedures are typically provided with your purchase documentation or can be found on the manufacturer's official website. When contacting support, please have your model number (01-769) and proof of purchase available.

It is recommended to retain all packaging and purchase receipts for warranty purposes.

© 2023 dbest products. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GJYRYYG

More documents and user manuals: **https://manuals.plus/**