Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro LC-40LE705E

Passion-Electro Replacement Remote Control User Manual

For SHARP LC-40LE705E Television

1. Introduction

This manual provides instructions for the Passion-Electro replacement remote control, designed for use with the SHARP LC-40LE705E television. This remote control offers full functionality comparable to the original remote, requiring no programming or setup beyond battery installation.



Figure 1: Front view of the Passion-Electro replacement remote control. This image displays the layout of all buttons, including power, mute, channel navigation, volume control, number pad, and smart TV functions.

2. Setup: Battery Installation

The remote control requires two AAA (LR03) 1.5V batteries (not included). No programming is necessary; simply insert the batteries to begin operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2: Back view of the remote control, illustrating the location of the battery compartment. The cover is visible, indicating where to open it for battery insertion.



Figure 3: Close-up view of the battery compartment, showing the slot where the cover slides open and the internal space for battery placement.

3. Operating Instructions

This replacement remote control is designed to function identically to your original SHARP LC-40LE705E TV remote. Point the remote control directly at the television's infrared receiver for optimal performance. The maximum effective range is approximately 10 meters.

Basic Functions:

- **Power Button (● Power):** Turns the television on or off.
- **Mute Button (Mute):** Mutes or unmutes the television's audio.
- **Number Buttons (0-9):** Directly select channels or input numerical values.
- **Volume Up/Down (V+/V-):** Adjusts the television's volume level.

- **Channel Up/Down (P+/P-):** Changes the television channel sequentially.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate through menus and confirm selections.
- **Menu Button:** Accesses the television's main menu.
- **Exit Button:** Exits the current menu or function.
- **Source/Input Button:** Selects the input source (e.g., HDMI, AV).

Advanced Functions:

Depending on your SHARP LC-40LE705E TV model, additional buttons may provide access to specific features such as Smart TV applications (e.g., Netflix), EPG (Electronic Program Guide), Info, and other multimedia controls. Refer to your television's original user manual for detailed information on these specific functions.

4. Maintenance

Cleaning:

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

Battery Replacement:

Replace the batteries when the remote control's response becomes sluggish or stops functioning. Always replace both batteries at the same time with new AAA (LR03) 1.5V batteries. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries according to local regulations.

5. Troubleshooting

- **Remote not responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with new ones.
  - Check for any obstructions between the remote control and the TV's infrared receiver.
  - Ensure you are within the effective operating range (approximately 10 meters) and pointing the remote directly at the TV.
- **Some buttons not working:**
  - This remote is a direct replacement. If specific functions are not working, verify if your SHARP LC-40LE705E TV model supports those functions with its original remote.
  - Clean the remote control as described in the Maintenance section to ensure no debris is interfering with button contacts.

6. Specifications

Brand	Passion-Electro
Compatible Devices	SHARP LC-40LE705E Television
Connectivity Technology	Infrared (IR)
Battery Type	2 x AAA (LR03) 1.5V batteries (not included)
Maximum Range	10 meters
Item Weight	100 g

7. Warranty and Support

For information regarding product warranty or technical support, please refer to the seller's return policy or contact the manufacturer, Passion-Electro, directly. The standard return policy allows for returns or replacements within 30 days of purchase.
Manufacturer: Passion-Electro

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GJZ3H53

More documents and user manuals: **https://manuals.plus/**