Passion-Electro XL-UR2110H

Replacement Remote Control for SHARP XL-UR2110H HI-FI System

Model: XL-UR2110H

Introduction

This manual provides instructions for the use and maintenance of your Passion-Electro replacement remote control for the SHARP XL-UR2110H HI-FI system. This remote is designed to replicate the full functionality of the original remote control without requiring any programming. Simply install the batteries to begin operation.

Setup

1. Battery Installation

The remote control requires two 1.5V AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Rear view of the remote control, highlighting the battery compartment.



Image: Close-up of the battery compartment, showing where to insert AAA batteries.

2. Initial Use

Once batteries are installed, the remote control is ready for immediate use. No programming or setup is required. Point the remote control directly at your SHARP XL-UR2110H HI-FI system and press the desired function button.

Operating Instructions

This replacement remote control provides access to all standard functions of your SHARP XL-UR2110H HI-FI system. The button layout is designed to be intuitive and similar to the original remote.



Image: Front view of the remote control, showing the upper section with navigation and colored function buttons.



Image: Front view of the remote control, showing the lower section with number keys and additional control buttons.



Image: Angled side view of the remote control, displaying its ergonomic design and button arrangement.

Key Functions Overview:

- **Power Button:** Turns the HI-FI system on or off.
- **Volume Up/Down:** Adjusts the audio volume.
- **Mute Button:** Silences the audio output.
- **Number Buttons (0-9):** For direct track selection or input.
- **Navigation Buttons (Up, Down, Left, Right, OK):** For menu navigation and selection.
- **Playback Controls (Play, Pause, Stop, Fast Forward, Rewind):** For controlling media playback.
- **Menu/Setup:** Accesses the system's main menu or settings.
- **Source/Input:** Switches between different audio sources (e.g., CD, Radio, USB).
- **Colored Function Buttons:** May correspond to specific functions within menus or applications, as indicated by your HI-FI system's display.

Refer to your SHARP XL-UR2110H HI-FI system's original manual for specific functions associated with each button, as this replacement remote is designed to mimic those functions.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new 1.5V AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote Control Not Responding:**
  - Ensure batteries are correctly installed with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote control and the HI-FI system's infrared receiver.
  - Ensure you are within the maximum operating range (approximately 10 meters) and pointing the remote directly at the system.
- **Limited Functionality:**
  - Verify that the HI-FI system is powered on and in the correct input mode.
  - Some advanced functions might require specific menu navigation on your HI-FI system.
  - If certain buttons do not work, ensure they correspond to functions available on your specific SHARP XL-UR2110H model.

Specifications

Brand	Passion-Electro
Model	XL-UR2110H (Replacement)
Color	Black
Battery Type	2 x 1.5V AAA batteries (not included)
Maximum Range	Approximately 10 meters
Compatibility	SHARP XL-UR2110H HI-FI System

Warranty and Support

Warranty Information

This product is covered by a return policy of 30 days for refund or replacement, as per the seller's terms. For specific warranty details beyond this period, please refer to the seller, Passion-Electro, directly.

Customer Support

For any questions, technical assistance, or support regarding this replacement remote control, please contact the seller, Passion-Electro. You can typically find their contact information through your purchase platform or order details.

© 2023 Passion-Electro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question