ZdalaMit BN59-01259E

ZdalaMit BN59-01259E Replacement Remote Control Instruction Manual

For Samsung TVs

Introduction

This manual provides comprehensive instructions for the ZdalaMit BN59-01259E replacement remote control, designed for various Samsung TV models. This remote offers a straightforward, pre-programmed solution without requiring complex setup or pairing. Simply insert batteries to begin use.

Compatible TV Models

The ZdalaMit BN59-01259E remote control is compatible with a wide range of Samsung TV models, including but not limited to:

- UN40KU6290, UN40KU6290FXZA, UN65KU6290, UN65KU6290FXZA
- UN40KU6290F, UN65KU6290F, UN40KU6290FXZC, UN50KU6290F, UN50KU6290FXZC
- UN55KU6290FXZC, UN60KU6290FXZC, UN65KU6290FXZC, UN70KU6290FXZC
- UN55KU6290F, UN60KU6290F, UN70KU6290F, UN50KU6290, UN50KU6290FXZA
- UN55KU6290, UN55KU6290FXZA, UN60KU6290, UN65KU6290, UN70KU6290
- UN55KU7000FXZA, UN55KU7000, UN55KU7000F, UN40KU7000FXZA, UN40KU7000
- UN43KU7000, UN43KU7000D, UN40KU700D, UN43KU7000FXZA, UN49KU7000FXZA, UN49KU7000
- UN65KU7000FXZA, UN49NU8000, UN55NU8000, UN65NU8000, UN75NU8000, UN82NU8000
- UN49NU8000FXZA, UN55NU8000FXZA, UN65NU8000FXZA, UN75NU8000FXZA, UN82NU8000FXZA
- UN65KS8500F, UN65KS8500FXZA, UN65KS850DF, UN65KS850DFXZA, UN49KS8500, UN55KS8500
- UN65KS8500, UN49KS8500FXZA, UN55KS8500FXZA, UN49KS8500F, UN55KS8500F
- UN49KS850DF, UN55KS850DF, UN49KS850DFXZA, UN55KS850DFXZA

- UN40KU6300F, UN43KU6300F, UN50KU6300F, UN55KU6300F, UN60KU6300F

Setup Instructions

1. Battery Installation

The remote requires two 1.5V AA alkaline batteries (not included). Please install new Alkaline AA batteries before use.

1. To open the battery compartment, hold the upper part of the back cover and gently press it down.
2. Simultaneously, hold the rear part of the back cover and push it in the direction of the arrow indicated on the remote.
3. Insert the batteries, ensuring correct polarity (+/-) as marked inside the compartment.
4. Close the battery cover securely.



Image: Instructions for opening the remote's back cover for battery installation.

2. Initial Use

No programming or pairing is needed. The remote is pre-programmed for compatible Samsung TVs. After installing batteries, the remote should function immediately.

Video: A demonstration of the BN59-01259E remote control, including battery insertion and basic functionality.

Operating the Remote Control

The ZdalaMit BN59-01259E remote control features a simplified layout for intuitive navigation of your Samsung TV. Below is a guide to its main buttons:



Image: Detailed layout of the remote control buttons and their corresponding functions.

- **Power ON/OFF:** Press to turn the TV on or off.
- **123 (Number pad):** When pressed, a number strip appears on the bottom of the screen. Select numbers and then select Done to enter a numeric value. Use to change the channel, enter a ZIP code, etc.
- **EXTRA:** While watching content, press to display extra information from the content provider.
- **Directional pad (up/down/left/right):** Moves the focus, and changes the values seen on the TV's menu.
- **Select (Center button):** Selects or focuses a program item. When pressed while you are watching content, detailed program information appears.
- **Return:** Press to return to the previous menu. When pressed for 1 second or more, the running function is terminated. When pressed while you are watching a program, the previous channel appears.
- **Home (House icon):** Press to return to the Home Screen.
- **Play/Pause:** When pressed, the playback controls appear. Using these controls, you can control the media content that is playing.
- **VOL (Volume):** Move the button up or down to adjust the volume. To mute the sound, press the button. When pressed for 1 second or more, the Accessibility Shortcuts menu appears.
- **CH (Channel):** Move the button up or down to change the channel. To see the Guide screen, press the button.

Troubleshooting

If your remote control is not functioning as expected, please follow these steps:

1. **Check Batteries:** Ensure new 1.5V AA Alkaline batteries are correctly installed with the proper polarity.
2. **Reset Remote:** Remove batteries from the remote. Press each button once to drain any residual power.
3. **Reset TV:** Unplug the power supply of your TV for a few minutes, then plug it back in to restart it.

4. **Reinstall Batteries:** Install new Alkaline AA batteries into the remote.
5. **Test Remote:** Try using the remote again.

Important Notes:

- This remote is designed for TVs only and is not compatible with soundbars.
- This is an infrared (IR) remote. It does not include a microphone or voice control functionality.

Specifications

Product Dimensions	6 x 1 x 0.5 inches
Item Weight	0.01 ounces
Batteries	2 AAA batteries required (not included)
Compatible Devices	Television
Special Feature	Pre Programmed
Color	black

Warranty and Support

For any issues or inquiries, please feel free to contact us. We are committed to providing timely after-service support within 24 hours.

© 2023 ZdalaMit. All rights reserved.