Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro 32AV933G

Passion-Electro Replacement Remote Control for Toshiba 32AV933G TV

User Manual

1. Introduction

This manual provides instructions for the Passion-Electro replacement remote control, specifically designed for Toshiba 32AV933G televisions. This remote offers full functionality similar to your original Toshiba remote control without requiring any programming.



Image: Front view of the Passion-Electro replacement remote control.

2. Setup and First Use

The Passion-Electro replacement remote control requires no programming. Simply install the batteries, and it will be ready for immediate use with your Toshiba 32AV933G TV.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) AAA 1.5V batteries (not supplied), ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.



Image: Bottom view of the remote control, highlighting the battery compartment.

Once batteries are installed, the remote is ready to operate your Toshiba 32AV933G television.

3. Operating Instructions

This remote control provides access to all essential functions of your Toshiba 32AV933G TV. Point the remote directly at your television's infrared receiver.

3.1 Key Functions Overview

- **Power Button:** Turns the TV on or off.
- **Mute Button:** Mutes or unmutes the TV sound.
- **Number Buttons (0-9):** For direct channel selection.
- **Volume Up/Down (V+/V-):** Adjusts the volume level.
- **Channel Up/Down (P+/P-):** Changes TV channels.
- **Menu Button:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **Source/Input Button:** Selects input sources (HDMI, AV, etc.).
- **Exit Button:** Exits current menu or function.
- **Colored Buttons (Red, Green, Yellow, Blue):** For specific functions within TV menus or smart TV applications (if applicable).



Image: Detailed view of the remote control buttons and their layout.

4. Maintenance and Care

- Keep the remote control dry. Liquids can damage the internal circuits.
- Avoid exposing the remote to extreme temperatures.
- Do not drop or subject the remote to strong impacts.
- Clean the remote with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA 1.5V batteries, ensuring correct polarity.
Remote control range is poor.	Weak batteries; Obstruction between remote and TV; Remote not pointed directly at TV.	Replace batteries. Remove any obstructions. Ensure direct line of sight to the TV's IR receiver.
Specific buttons not responding.	Button stuck or dirty; Internal fault.	Clean around the button. If problem persists, contact customer support.
TV not responding to any commands.	TV's IR receiver blocked or faulty; TV is off.	Ensure TV is on and its IR receiver is clear. Try using the TV's physical buttons.

6. Specifications

- **Brand:** Passion-Electro
- **Compatibility:** Toshiba 32AV933G TV
- **Connectivity Technology:** Infrared (IR)
- **Number of Buttons:** 20
- **Maximum Range:** 10 meters (approx. 33 feet)
- **Battery Type:** 2 x AAA 1.5V (not included)
- **Special Feature:** No programming required, ready to use.

7. Warranty and Support

This Passion-Electro remote control comes with a**2-year manufacturer's warranty**. For warranty claims or technical support, please contact your retailer or Passion-Electro customer service.
For further assistance, please refer to the contact information provided with your purchase or visit the official Passion-Electro website (if available).

© 2023 Passion-Electro. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GL7B7F4

More documents and user manuals: **https://manuals.plus/**