Passion-Electro AKB73796101

Replacement Remote Control User Manual

Model: AKB73796101 | Brand: Passion-Electro

1. Introduction



Figure 1.1: Side profile of the Passion-Electro AKB73796101 Replacement Remote Control.

This manual provides instructions for the use and maintenance of your new Passion-Electro Replacement Remote Control, model AKB73796101. This remote is designed to function as a direct replacement for the original LG AKB73796101 remote, providing access to all original functions. It is a specialized replacement remote and does not require programming. Simply insert the batteries to begin operation.

2. Product Features

- Direct replacement functionality for LG AKB73796101 remote controls.
- No programming required; ready to use upon battery insertion.
- Access to all original remote control functions.
- Integrated LED indicator for signal transmission.
- Durable construction with a comfortable button layout.

3. Package Contents

- 1 x Passion-Electro Replacement Remote Control (Model: AKB73796101)
- *Note: Batteries are not included.*

4. Setup

4.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.



Figure 4.1: Rear view of the remote control with the battery compartment visible. This is where two AAA batteries are inserted.



Figure 4.2: A closer view of the battery compartment, illustrating the cover design for battery insertion.

4.2 Initial Use

Once batteries are correctly installed, the remote control is ready for immediate use. No programming or pairing is required. Point the remote control towards your LG device (TV, DVD/BD player, etc.) and press the desired function button.

5. Operating Instructions

This remote control is designed to replicate the functionality of your original LG AKB73796101 remote. Below is a general guide to common buttons and their functions.



Figure 5.1: Front view of the remote control, displaying the full button layout for operation.



Figure 5.2: Angled view of the remote control, providing a perspective on the button arrangement and ergonomic design.

5.1 Basic Functions

- **POWER (●)**: Turns the device on or off.
- **MUTE**: Mutes or unmutes the audio.
- **TV** / **SAT** / **DVD** / **AUX**: Selects the input source or device mode.
- **MENU** / **EXIT**: Accesses or exits the device's menu system.
- **Number Buttons (0-9)**: Direct channel selection or numerical input.
- **Volume Up/Down (V+/V-)**: Adjusts the volume level.
- **Channel Up/Down (P+/P-)**: Changes the channel.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Navigates through menus and confirms selections.

5.2 Advanced Functions

- **SHIFT**: Activates secondary functions of certain buttons (if applicable).
- **INFO**: Displays information about the current program or input.
- **EPG**: Accesses the Electronic Program Guide.
- **FAV**: Accesses favorite channels list.
- **NETFLIX** / **SMART**: Direct access buttons for streaming services or smart TV features.
- **Color Buttons (Red, Green, Yellow, Blue)**: Used for specific functions within menus or applications, as indicated on screen.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward)**: Controls media playback on compatible devices.

6. Maintenance

6.1 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

6.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or the LED indicator fails to light up consistently. Always replace both batteries simultaneously with new AAA 1.5V batteries. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries according to local regulations.

6.3 Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage and potential damage.

7. Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries. Obstruction between remote and device. Remote out of range.	Check battery polarity and replace batteries if necessary. Ensure a clear line of sight to the device's IR receiver. Move closer to the device (within 10 meters).
LED indicator not lighting up.	Batteries are dead or not making proper contact.	Replace batteries. Ensure batteries are inserted correctly and securely.
Some buttons not working.	Button stuck or dirty. Device incompatibility for specific advanced functions.	Clean around the button. Verify if the function is supported by your specific device model.

8. Specifications

Brand	Passion-Electro
Model Number	AKB73796101
Color	Black
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Number of Buttons	16
Maximum Range	10 Meters
Batteries Required	2 x AAA 1.5V (not included)

9. Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For support or inquiries regarding your Passion-Electro Replacement Remote Control, please refer to the retailer or manufacturer's contact information provided at the point of purchase.

© 2023 Passion-Electro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question