Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi CKM1641D

De'Longhi Livenza Multi-Cooker Instruction Manual

Model: CKM1641D

1. Introduction

Thank you for choosing the De'Longhi Livenza Multi-Cooker. This versatile 6-quart countertop appliance is designed to simplify your cooking process, offering multiple functions including steaming, browning, sautéing, baking, and slow cooking. With its 24-hour programmability, self-regulating precision, and user-friendly LCD display, you can achieve consistent and delicious results with ease.



Figure 1: De'Longhi Livenza Multi-Cooker (Model CKM1641D)

2. Safety Precautions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons. Read all instructions carefully before use.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or heating unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. Components

- Main Unit with Control Panel
- Removable Non-Stick Cooking Pot (6-quart capacity)
- Glass Lid with Handle
- Steam Rack



Figure 2: Components of the Multi-Cooker

4. Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials, stickers, and accessories from the multi-cooker.
2. **Initial Cleaning:** Before first use, wash the removable non-stick cooking pot, glass lid, and steam rack in warm, soapy water. Rinse thoroughly and dry all parts completely. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the multi-cooker on a stable, flat, heat-resistant surface, away from walls or other appliances to ensure proper ventilation.
4. **Power Connection:** Ensure the voltage of your power outlet matches the appliance's requirements (220 Volts). Plug the power cord into a grounded electrical outlet.

5. Operating Instructions

The De'Longhi Livenza Multi-Cooker features an intuitive control panel with an LCD display and rotary dials for selecting cooking modes, time, and temperature.



Figure 3: Intuitive Control Panel

5.1. Cooking Modes

The multi-cooker offers seven distinct cooking modes:

- **Slow Cook (Low, Medium, High):** Ideal for tenderizing meats and simmering stews over extended periods. Automatically switches to Keep Warm mode for up to 12 hours after cooking.
- **Oven Bake:** For baking dishes that require consistent, dry heat.
- **Brown/Sauté:** Perfect for searing meats and sautéing vegetables directly in the pot before slow cooking or other modes. Temperature can be set up to 450°F for effective searing.
- **Steam:** For healthy steaming of vegetables, fish, and other foods using the included steam rack.
- **Rice:** Optimized for cooking various types of rice to perfection.



Figure 4: Mode Selection Dial

5.2. Setting Time and Temperature

1. **Select Mode:** Turn the left dial to select your desired cooking mode (e.g., Brown/Sauté, Oven Bake, Slow Cook).
2. **Set Time/Temperature:** Use the right dial (TIME/TEMP/CUP) to adjust the cooking time or temperature, depending on the selected mode. The LCD display will show the current setting.
3. **Start Cooking:** Press the "START/STOP" button to begin the cooking cycle.
4. **Keep Warm:** The appliance automatically switches to "KEEP WARM" mode after the cooking cycle is complete, maintaining food at an optimal serving temperature for up to 12 hours. You can also manually select "KEEP WARM" by pressing the dedicated button.

Your browser does not support the video tag.

Video 1: Demonstrating the intuitive controls and various cooking modes of the Livenza Multi-Cooker, including setting time and temperature for searing.

6. Maintenance and Cleaning

Proper cleaning ensures the longevity and optimal performance of your multi-cooker. Always unplug the appliance and allow it to cool completely before cleaning.

- **Removable Pot, Lid, and Steam Rack:** These parts are dishwasher-safe for easy cleanup. Alternatively, wash them by hand with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely.
- **Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish. Never immerse the main unit in water or any other liquid.
- **Storage:** Ensure all parts are clean and dry before storing the multi-cooker. Store it in a cool, dry place.



Figure 5: Easy cleanup with dishwasher-safe parts.

7. Troubleshooting

If you encounter any issues with your De'Longhi Livenza Multi-Cooker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; appliance not properly assembled.	Ensure the power cord is securely plugged into a working outlet. Check if the cooking pot is correctly seated in the main unit.
Food not cooking evenly or taking too long.	Incorrect mode or temperature selected; lid not properly sealed; insufficient liquid.	Verify the selected cooking mode and temperature settings. Ensure the lid is securely placed. Add appropriate liquid as per recipe.
Display shows an error code.	Internal malfunction or sensor issue.	Unplug the appliance for 5 minutes, then plug it back in. If the error persists, contact customer support.
Non-stick coating is peeling.	Use of metal utensils; abrasive cleaning; prolonged high heat without liquid.	Always use wooden, silicone, or plastic utensils. Avoid abrasive cleaners. Ensure sufficient liquid when cooking at high temperatures. Replacement pots may be available from De'Longhi.

For further assistance, please refer to the official user manual PDF or contact De'Longhi customer support.

8. Specifications

Feature	Detail
Brand	De'Longhi
Model Number	CKM1641D
Color	Stainless Steel
Material	Stainless Steel
Product Dimensions	12.4"D x 18.11"W x 10.83"H
Capacity	6 Quarts
Wattage	1500 watts
Item Weight	16.7 Pounds (16.65 pounds)
Dishwasher Safe Parts	Yes (Removable Pot, Lid, Steam Rack)
Voltage	220 Volts
Control Method	Touch / Push Button (Electronic controls with LCD display)
UPC	810002431692, 044387166102
Date First Available	August 21, 2018



Figure 6: Product dimensions and weight for the Multi-Cooker.

9. Warranty and Support

For detailed warranty information and customer support, please refer to the official De'Longhi website or the full user manual provided with your product. A digital version of the user manual can be accessed via the following link:

Download Full User Manual (PDF)

For additional support or to explore other De'Longhi products, visit the De'Longhi Store.

© 2024 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GQ3BC5J

More documents and user manuals: **https://manuals.plus/**