ZdalaMit AKB75095307

User Manual for ZdalaMit AKB75095307 Replacement Remote Control

Model: AKB75095307
Brand: ZdalaMit

Product Overview

This document provides comprehensive instructions for the ZdalaMit AKB75095307 Replacement Remote Control. This remote is designed as a direct replacement for various LG LED LCD TV models, ensuring seamless operation without the need for complex programming.

It offers all essential functions of the original remote, allowing you to control your television's power, volume, channels, and access smart TV features like Netflix and Amazon.



Image: Front view of the AKB75095307 replacement remote control, showing all buttons including power, number pad, volume, channel, navigation, and dedicated Netflix and Amazon buttons.

Setup

The AKB75095307 replacement remote control is designed for immediate use. No programming or pairing is required for most compatible LG TV models.

Battery Installation

1. Locate the battery compartment on the back of the remote control.

2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

Once batteries are installed, the remote is ready for use with your compatible LG TV.



Image: Angled view of the AKB75095307 remote control, highlighting its ergonomic design and button layout. This view can also imply the location of the battery compartment on the underside.

Operating Instructions

The AKB75095307 remote control functions identically to the original LG TV remote. Point the remote directly at your television's infrared receiver for optimal performance.

Key Functions:

- **Power Button (●):** Turns the TV on or off.
- **Number Pad (0-9):** Directly enters channel numbers.
- **VOL +/-:** Adjusts the volume level.
- **CH PAGE +/-:** Changes TV channels up or down.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and select options.
- **Back:** Returns to the previous screen or menu.
- **Exit:** Exits the current menu or application.
- **Netflix** / **Amazon Buttons:** Provides direct access to these streaming applications.
- **List:** Displays a list of channels or inputs.
- **Quick Access** / **FAV:** Accesses quick settings or favorite channels.
- **Info:** Displays information about the current program or input.
- **Caption:** Toggles closed captions.
- **Flashback:** Returns to the previously viewed channel.
- **Magic Link** / **SAP/*:** Provides additional functions depending on the TV model.
- **Sleep:** Sets a sleep timer for the TV.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.

Maintenance

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new 1.5V AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage and potential damage.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new 1.5V AAA alkaline batteries, ensuring correct polarity.

Problem	Possible Cause	Solution
Remote works intermittently.	Low battery power; Obstruction between remote and TV; Remote too far from TV.	Replace batteries. Ensure a clear line of sight to the TV's infrared receiver. Move closer to the TV.
Specific buttons not working.	Dirt or debris under the button; Button malfunction.	Clean the remote surface. If the issue persists, the button may be faulty.
Remote does not control TV.	Incompatible TV model; TV's IR sensor is blocked or faulty.	Verify your LG TV model is listed as compatible. Check if anything is blocking the TV's IR sensor. Test with another remote if available.

Specifications

Model: AKB75095307

Brand: ZdalaMit

Product Dimensions: 6 x 2 x 0.6 inches

Item Weight: 2.12 ounces

Batteries Required: 2 x 1.5V AAA Alkaline Batteries (not included)

Compatible Devices: LG LED LCD Televisions (Specific models include 65UJ6540-UB, 60UJ6540-UB, 70UJ6570-UB, 55UJ6540-UB, 43UJ6560-UF, 49UJ6560-UF, 55UJ6580-UE, 65UJ6520-UD, 65UJ6580-UE, 70UJ6520-UA, 75UJ6470-UC, 75UJ657A-UB)

Color: Black

Special Feature: Pre-Programmed (No setup required)

Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For any queries or support needs regarding your ZdalaMit AKB75095307 Replacement Remote Control, please refer to the seller or retailer from whom the product was purchased.

You may also refer to the product listing on the retailer's website for potential contact information or frequently asked questions.

© 2025 ZdalaMit. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.