Passion-Electro SQ552-1ELA

Replacement Remote Control for PHILIPS SQ552-1ELA TV

Model: SQ552-1ELA | Brand: Passion-Electro

Introduction

This manual provides comprehensive instructions for the use and maintenance of your Passion-Electro replacement remote control, specifically designed for PHILIPS SQ552-1ELA TV models. This specialized remote offers full functionality comparable to your original remote control without the need for complex programming.



Figure 1: Front view of the Passion-Electro replacement remote control, showing the button layout and brand logo.

Safety Information

- Keep the remote control away from water and excessive moisture.

- Avoid dropping the remote control or subjecting it to strong impacts.
- Do not expose the remote control to direct sunlight or extreme temperatures.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of used batteries according to local regulations.

Package Contents

Please verify that all items are present in the package:

- 1 x Passion-Electro Replacement Remote Control (Model: SQ552-1ELA)
- (Batteries are not included)

Setup

1. Battery Installation

The remote control requires two 1.5V AAA (LR03) batteries. Ensure correct polarity when inserting the batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two AAA batteries, matching the positive (+) and negative (-) terminals as indicated inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2: Bottom view of the remote control, highlighting the battery compartment.



Figure 3: Back view of the remote control, showing the battery cover.

2. Initial Use

This remote control is pre-programmed for PHILIPS SQ552-1ELA TV models. No additional programming is required.

Once batteries are installed, it is ready for immediate use.

Operating Instructions

The remote control provides access to all standard functions of your PHILIPS TV. Refer to your TV's user manual for specific functions if needed.

Key Functions Overview



Figure 4: Top-down view of the remote control, illustrating the full button layout.

Button Name	Function
Power	Turns the TV on or off.
Mute	Mutes or unmutes the TV sound.
TV/SAT/DVD/AUX	Selects input source (if applicable).
Number Buttons (0-9)	Direct channel selection.
Volume Up/Down (+/-)	Adjusts the volume level.
Channel Up/Down (P+/P-)	Changes TV channels.
Navigation (Up, Down, Left, Right, OK)	Navigates menus and confirms selections.
Menu	Opens the TV's main menu.
Exit	Exits current menu or function.
Source	Cycles through available input sources.
Info	Displays program information.
Back	Goes back to the previous screen or menu.

Button Name	Function
Smart/Netflix/Colored Buttons	Accesses smart TV features or specific applications (functionality may vary based on TV model).

Maintenance

Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads.

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA 1.5V).

Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly inserted batteries.	Check battery polarity. Replace batteries with new ones.
Remote control range is poor.	Low batteries; Obstruction between remote and TV; Remote sensor on TV is blocked.	Replace batteries. Ensure clear line of sight to TV. Clear any obstructions from TV's IR sensor.
Certain buttons do not respond.	Button malfunction; TV model incompatibility for specific advanced functions.	Ensure the remote is pointed directly at the TV. While this remote is designed for the specified model, some advanced TV-specific functions might not be fully supported if they require unique codes not present in the replacement.
LED indicator not lighting up.	No power; Faulty remote.	Check and replace batteries. If problem persists, the remote may be faulty.

Specifications

Brand	Passion-Electro
Model Number	SQ552-1ELA
Compatible Devices	PHILIPS TV (SQ552-1ELA series)
Connectivity Technology	Infrared (IR)
Color	Black

Power Source	2 x AAA 1.5V Batteries (not included)
Number of Buttons	25
Maximum Range	10 Meters (approx. 33 feet)
Country of Origin	China

Warranty and Support

For information regarding warranty, returns, or technical support, please refer to the seller's policy on the product purchase page or contact Passion-Electro directly through the retailer's platform.
This product is designed to provide functionality similar to an original remote control. If you encounter issues not covered in the troubleshooting section, please reach out for assistance.

© 2024 Passion-Electro. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.