Passion-Electro 37PFL9603D/10

Passion-Electro Replacement Remote Control for PHILIPS 37PFL9603D/10 TV

User Instruction Manual

1. Introduction

This instruction manual provides comprehensive guidance for the use and maintenance of your new Passion-Electro replacement remote control. This remote is specifically designed to be compatible with the PHILIPS 37PFL9603D/10 television model, offering full functionality without the need for complex programming.
Please read this manual carefully before using the remote control to ensure proper operation and to maximize its lifespan.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA 1.5V batteries (not included) for operation.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Bottom view of the remote control, highlighting the battery compartment.

2.2 Initial Use

This replacement remote control is pre-programmed for the PHILIPS 37PFL9603D/10 TV. No additional programming or setup is required. Once batteries are installed, the remote is ready for immediate use. Point the remote control directly at your television's infrared receiver for optimal performance.

3. Operating Instructions

The remote control features a standard layout designed for intuitive operation. Below is a guide to its primary functions:



Image: Front view of the remote control, displaying all buttons and their labels.

- **POWER** (Red Button): Turns the television on or off.
- **MUTE**: Mutes or unmutes the television audio.
- **TV** / **SAT** / **DVD** / **AUX**: Selects the corresponding input source on your television.
- **MENU**: Accesses the television's main menu.
- **EXIT**: Exits the current menu or function.
- **SHIFT**: May activate secondary functions for certain buttons (refer to your TV's manual for specific uses).
- **Numeric Keypad (0-9)**: Directly enters channel numbers.
- **SOURCE**: Cycles through available input sources.
- **+/-**: Adjusts volume levels.
- **CH +/- (P+/-)**: Changes television channels.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Navigates through menus and confirms selections.
- **BACK**: Returns to the previous screen or menu.
- **INFO**: Displays information about the current program or input.
- **SLEEP**: Sets a sleep timer for the television.
- **EPG**: Accesses the Electronic Program Guide.
- **TWOTV**: (Specific function, may switch between two TV channels or picture-in-picture if supported by TV).
- **FAV**: Accesses favorite channels list.
- **SMART**: Accesses smart TV features or applications.
- **NETFLIX** / **YouTube**: Direct access buttons for these streaming services.
- **Colored Buttons (Red, Green, Yellow, Blue)**: Used for specific functions within menus or applications, as indicated on-screen.



Image: Angled view of the remote control, providing a clear perspective of the button arrangement.

4. Maintenance

4.1 Cleaning

To clean your remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA 1.5V batteries. Do not mix old and new batteries, or different types of batteries.

4.3 Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage, which can damage the remote control. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote control is not working.	• Dead or incorrectly inserted batteries. • Obstruction between remote and TV. • Remote control is too far from the TV.	• Replace batteries with new ones, ensuring correct polarity. • Remove any objects blocking the line of sight to the TV's IR receiver. • Move closer to the TV (within 10 meters).
Buttons are unresponsive or sticky.	• Dirt or debris under buttons. • Worn-out internal contacts.	• Clean the remote control as described in the Maintenance section. • If cleaning does not resolve the issue, the remote may require replacement.
Limited operating range.	• Weak batteries. • Interference from other electronic devices.	• Replace batteries. • Ensure no strong light sources or other IR devices are interfering.

6. Specifications

Brand	Passion-Electro
Model Compatibility	PHILIPS 37PFL9603D/10 TV
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA 1.5V Batteries (not included)
Maximum Range	10 Meters
Color	Black
Special Feature	Specialized replacement, no programming required

7. Warranty and Support

For any issues or questions regarding your Passion-Electro replacement remote control, please contact the seller or manufacturer directly. Please refer to your purchase documentation for specific warranty terms and contact information.

© 2023 Passion-Electro. All rights reserved.