Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY CH43QX012-H3N1C, CH43QX018-H3N1C, CH43QX024-H3N1C

YING RAY Replacement Remote Control User Manual

For CIAC Air Conditioner Models: CH43QX012-H3N1C, CH43QX018-H3N1C, CH43QX024-H3N1C

1. Introduction

This manual provides comprehensive instructions for the proper setup, operation, and maintenance of your YING RAY replacement remote control for CIAC Air Conditioners. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

1.1 Compatibility

This remote control is specifically designed as a replacement for CIAC Air Conditioner models CH43QX012-H3N1C, CH43QX018-H3N1C, and CH43QX024-H3N1C. It is important to note that this is NOT a universal remote control. If your air conditioner model is not listed, please verify compatibility before use.

2. Setup

2.1 Battery Installation

The remote control requires two 'AAA' 1.5V batteries (not included). Follow these steps to install the batteries:

1. Open the battery compartment cover on the back of the remote control.
2. Insert two 'AAA' batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Close the battery compartment cover securely.

Important Battery Tip (For Type "B" Batteries): If the remote control does not function after battery installation, it may be due to poor contact between the battery's positive pole and the spring in the compartment. As shown in the image below, gently pull the battery spring out a little to ensure better contact.



Figure 1: Illustration of battery installation and how to adjust the battery spring for improved contact, particularly for 'Type B' batteries.

3. Operating Instructions

Familiarize yourself with the buttons and their functions on your YING RAY replacement remote control.



Figure 2: Overview of the YING RAY replacement remote control.

3.1 Remote Control Functions

- **ON/OFF:** Powers the air conditioner unit on or off.
- **MODE:** Cycles through various operating modes (e.g., Cool, Fan, Dry, Heat - depending on AC unit features).
- **TEMP ▲/▼:** Adjusts the desired temperature setting. The display is in Celsius only.
- **FAN:** Controls the fan speed (e.g., Auto, Low, Medium, High).
- **SLEEP:** Activates or deactivates the sleep mode for energy-efficient operation during sleep.
- **TURBO:** Engages maximum cooling or heating power for rapid temperature adjustment.
- **ECO:** Activates economy mode for reduced power consumption.
- **TIMER ON/OFF:** Sets a timer for the unit to automatically turn on or off.
- **SHORT CUT:** Recalls preferred settings.
- **FRESH:** Activates the fresh air function (if available on the AC unit).
- **SELF CLEAN:** Initiates the self-cleaning function (if available on the AC unit).
- **SWING:** Controls the vertical louver movement for air direction.
- **DIRECT:** Adjusts the horizontal louver movement for air direction.
- **LED:** Turns the display light on the air conditioner unit on or off.
- **FOLLOW ME:** Activates a sensor in the remote to measure ambient temperature and adjust operation accordingly (if available on the AC unit).

4. Maintenance

4.1 Cleaning the Remote Control

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's display becomes dim or the remote fails to operate the air conditioner unit. Always replace both batteries simultaneously with new 'AAA' 1.5V batteries. Do not mix old and new batteries or different types of batteries.

5. Troubleshooting

5.1 Remote Control Not Responding

- **Check Batteries:** Ensure batteries are correctly installed with the correct polarity (+/-). Replace with fresh 'AAA' batteries if necessary.
- **Battery Contact:** If using 'Type B' batteries and the remote is unresponsive, refer to the 'Battery Installation' section (Figure 1) and gently pull out the positive pole spring in the battery compartment to ensure proper contact.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the air conditioner unit's receiver. Obstructions can block the signal.
- **Distance:** Operate the remote within the recommended range of the air conditioner unit.

6. Specifications

Feature	Detail
Brand	YING RAY
Compatible Models	CIAC CH43QX012-H3N1C, CH43QX018-H3N1C, CH43QX024-H3N1C

Battery Type	2 x 'AAA' 1.5V (not included)
Display Temperature Unit	Celsius Only
Special Feature	Ergonomic Design
Max Number of Supported Devices	1 (Specific CIAC AC unit)
Manufacturer	ZHUHAI YINGRAY TRADING CO., LTD.

7. Important Notes

- This remote control is a direct replacement for the specified CIAC models and is not a universal remote.
- The temperature display on this remote control is in Celsius only.
- Always dispose of used batteries responsibly according to local regulations.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GTWMQJW

More documents and user manuals: **https://manuals.plus/**