Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY LM012CI-100V232-1X, LM012CI-100P232-1X, LM018CI-100P232-1X, LM024CI-100P232-1X, LM036CI-100P232-1X, LM012HI-100V232-1X,

YING RAY Replacement Remote Control for Lennox Air Conditioners User Manual

Compatible with Lennox Models: LM012CI, LM018CI, LM024CI, LM036CI, LM012HI, LM018HI, LM024HI, LM036HI Series

1. Product Overview

This manual provides instructions for the YING RAY replacement remote control designed for specific Lennox air conditioner models. This remote control is a direct replacement and does not require programming for basic functions.



Image 1: YING RAY Replacement Remote Control. This image displays the front view of the remote control, showing its LCD screen and various function buttons.

2. Setup

2.1 Battery Installation

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA 1.5V ordinary batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

3. Close the battery compartment cover.

The remote control operates without any programming once batteries are installed.

2.2 Battery Contact Troubleshooting (For Type "B" Batteries)

If the remote control does not function after battery installation, it may be due to poor contact between the battery's positive pole and the spring in the remote, especially with certain battery types (Type "B").



Image 2: Battery Contact Adjustment. This image illustrates how to gently pull out the battery spring in the remote control's battery compartment to ensure better contact with the positive pole of a Type "B" battery.

To resolve this, gently pull the battery spring out a little to improve contact, as illustrated in Image 2.

3. Operating Instructions

The remote control features various buttons for controlling your Lennox air conditioner. The display shows temperature in Celsius only.

Remote Control Button Functions

Button	Function
ON/OFF	Powers the air conditioner on or off.
MODE	Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
▲ / ▼	Adjusts temperature settings up or down.
FAN	Adjusts fan speed settings.
TIMER	Sets the timer for automatic on/off operations.
SLEEP	Activates sleep mode for comfortable nighttime operation.
LIGHT	Controls the display light on the air conditioner unit.
QUIET	Activates a low-noise operating mode.
TURBO	Engages maximum power for rapid cooling or heating.
BLOW	Activates a fan-only function to dry the indoor unit and prevent mold.
HEALTH / FRESH AIR	Activates air purification or fresh air intake functions (if supported by AC unit).
ECONO	Activates energy-saving mode.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's display becomes dim or its response time slows. Always replace both batteries simultaneously with new AAA 1.5V ordinary batteries.

4.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

5. Troubleshooting

5.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new ones.
- **Battery Contact:** If using Type "B" batteries, refer to Section 2.2 for instructions on adjusting the battery spring for better contact.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the air conditioner's receiver. Obstructions can block the infrared signal.
- **Remote Sensor:** Ensure the remote control's infrared emitter and the air conditioner's receiver are clean and free from dust.

5.2 Incorrect Functionality

- This remote is designed for specific Lennox models. Verify your air conditioner model is listed as compatible. This is not a universal remote.
- Remove and reinsert batteries to reset the remote control.

6. Specifications

- **Brand:** YING RAY
- **Compatible Air Conditioner Models:** LM012CI-100V232-1X, LM012CI-100P232-1X, LM018CI-100P232-1X, LM024CI-100P232-1X, LM036CI-100P232-1X, LM012HI-100V232-1X, LM012HI-100P232-1X, LM018HI-100P232-1X, LM024HI-100P232-1X, LM036HI-100P232-1X
- **Battery Type:** 2 x AAA 1.5V Ordinary Batteries (not included)
- **Display:** Celsius Only
- **Connectivity Technology:** Infrared
- **Item Model Number:** 2018082601

7. Warranty and Support

Specific warranty information for this YING RAY replacement remote control is not provided in the product details. For warranty inquiries or technical support, please contact the seller directly through your purchase platform.

© 2023 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GTZ56TZ

More documents and user manuals: **https://manuals.plus/**