Syslux BL-DP-MXX

Syslux Christmas Snowfall Projector Light User Manual

Model: BL-DP-MXX

1. Introduction

The Syslux Christmas Snowfall Projector Light is designed to create a festive and romantic atmosphere with a dynamic white snowfall effect. This projector is suitable for both indoor and outdoor decoration, perfect for holidays, parties, and various events. Please read this manual carefully before use to ensure proper operation and safety.

2. Product Overview

2.1 Key Features

- Realistic white snow dots with static, dynamic, and twinkle combinations.
- Wireless remote control for convenient operation.
- Wide projection area with high-definition snowfall effect.
- IP65 waterproof rating for outdoor use in various weather conditions.
- Quick and easy installation with multiple mounting options.
- 270° adjustable projector head for precise aiming.
- Built-in timer function (2H/4H/6H).

2.2 Package Contents

- Snowfall Projector Light Unit
- Remote Control
- Ground Stake
- Round Mounting Base
- Power Adapter
- User Manual (this document)

2.3 Product Diagram



Figure 1: Syslux Snowfall Projector Light with included accessories.



Figure 2: Remote control layout and functions.

3. Safety Information

- Ensure the power adapter is connected to a properly grounded outlet.
- Do not look directly into the light source to avoid eye damage.
- Keep the projector away from open flames or extreme heat sources.
- For outdoor use, ensure the power outlet is waterproof and protected from direct exposure to heavy rain or snow.
- Do not attempt to disassemble or modify the projector. Contact customer support for any issues.
- Operating temperature range is -4°F to 122°F (-20°C to 50°C).

4. Setup

4.1 Installation Options

The projector offers three installation methods:

1. **Ground Mounted:** Attach the ground stake to the projector unit and firmly insert it into soft ground in your garden or yard.
2. **Indoor Mounted:** Attach the round mounting base to the projector unit and place it on a flat surface indoors.
3. **Wall Mounted:** Use appropriate screws (not included) to secure the round mounting base to a wall, then attach the projector unit.



Figure 3: Various installation methods for the projector.

4.2 Adjusting Projection Angle

The projector head can be adjusted up to 270 degrees. Loosen the adjustment knob, position the projector to your desired angle, and then tighten the knob to secure it.



Figure 4: The projector features a 270° adjustable shaft for flexible positioning.

4.3 Power Connection

Connect the power adapter to the projector unit and then plug the adapter into a standard 110V AC power outlet. Ensure the connection is secure, especially for outdoor use where the adapter should be protected from moisture.

5. Operating Instructions

Use the included remote control to operate the projector. The remote has a memory function that will recall the last pattern and setting when powered back on.

5.1 Remote Control Functions

- **ON/OFF:** Powers the projector on or off.
- **S+/S-:** Adjusts the moving speed of the snow dots (faster/slower).
- **F+/F-:** Adjusts the flashing speed of the snow dots (faster/slower).
- **BREATHE:** Activates or deactivates the breathing mode (gradual fade in/out).

- **2H/4H/6H:** Sets the automatic shut-off timer for 2, 4, or 6 hours.
- **CANCEL TIMER:** Deactivates the timer function.

5.2 Projection Distance and Area

The optimal projection distance for the best display is approximately 16 feet. The projection range can extend up to 26.24 feet, covering a large area.



Figure 5: Recommended projection distances for optimal visual effect.

5.3 Indoor and Outdoor Use

The projector is designed for versatile use. For indoor applications, it can project onto walls, ceilings, or even Christmas trees. For outdoor use, it can illuminate houses, gardens, fences, and trees.

Your browser does not support the video tag.

Video 1: Demonstration of the Syslux Christmas Snowfall Projector Light in an outdoor setting, showcasing its effect on a building.



Figure 6: Example of outdoor projection on a house and garden.

6. Maintenance

- Regularly clean the projector lens with a soft, dry cloth to ensure clear projection.
- Do not use abrasive cleaners or solvents.
- When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.
- Ensure all connections are dry before storing.

7. Troubleshooting

Problem	Possible Cause	Solution
Projector does not turn on.	No power supply or loose connection.	Check power adapter connection and ensure outlet is functional.
Remote control not working.	Battery depleted or remote signal obstructed.	Replace remote battery. Ensure clear line of sight to projector. If issue persists, contact customer support.
Projection is blurry or dim.	Lens is dirty or projector is too far/close.	Clean the lens. Adjust projection distance (optimal 16ft).
Snow dots are not moving.	Static mode selected.	Use the remote control to adjust speed (S+/S-) or select a dynamic mode.

8. Specifications

- **Model Number:** BL-DP-MXX
- **Brand:** Syslux

- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Light Source Type:** Light Emitting Diode (LED)
- **Power Source:** Corded Electric
- **Voltage:** 110 Volts
- **Wattage:** 9 Watts
- **IP Rating:** IP65 (Waterproof)
- **Operating Temperature:** -4°F to 122°F (-20°C to 50°C)
- **Product Dimensions:** 5.24"L x 6.34"W x 6.42"H
- **Item Weight:** 1.21 pounds
- **UPC:** 631145621081

9. Warranty and Support

The Syslux Christmas Snowfall Projector Light comes with a 12-month warranty from the date of purchase. If you encounter any issues with your product, particularly if the remote control is not functioning, please do not hesitate to contact Syslux customer service for assistance. We are committed to providing friendly after-sales service and will arrange for a replacement remote control if necessary.
For further support, please visit the official Syslux store or contact your retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question