Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEGO 41163

LEGO 41163 Disney Rapunzel's Petite Tower Building Kit Instruction Manual

Model: 41163 | Brand: LEGO

Introduction

This instruction manual provides detailed guidance for assembling and using the LEGO 41163 Disney Rapunzel's Petite Tower building kit. This set is designed to offer an engaging building experience and imaginative play for fans of Disney's Tangled. It features a compact, hinged tower that opens for interior play, a Rapunzel mini-doll, and essential accessories.

Safety Information

WARNING: CHOKING HAZARD. Small parts. Not for children under 3 years.
This product contains small parts which may pose a choking hazard to young children. Adult supervision is recommended during assembly and play, especially for children at the lower end of the recommended age range (5+ years).

Package Contents

The LEGO 41163 Disney Rapunzel's Petite Tower building kit includes 44 pieces. Please verify that all components are present before beginning assembly.

- LEGO building elements for Rapunzel's Petite Tower
- 1 Rapunzel mini-doll figure
- Accessories: 1 hairbrush, 1 frying pan



Image: All components of the LEGO 41163 set, including the assembled tower, Rapunzel mini-doll, hairbrush, and frying pan.

Setup and Assembly

Follow the step-by-step visual instructions provided in the physical instruction booklet included with your LEGO set. The assembly process is designed to be straightforward for children aged 5 and up.

1. **Unpack Components:** Carefully open the packaging and lay out all 44 LEGO pieces.
2. **Identify Key Elements:** Locate the base plate, wall elements, tower sections, and roof pieces.
3. **Build the Tower Base:** Assemble the foundational pieces of the tower.
4. **Construct the Walls:** Attach the wall elements, ensuring the hinged base is correctly positioned for opening and closing the tower.

5. **Add Details:** Integrate decorative elements such as the window, floral stickers (if included), and the heart-shaped finial on the roof.
6. **Assemble Mini-doll:** Put together the Rapunzel mini-doll figure.
7. **Prepare Accessories:** Have the hairbrush and frying pan ready for play.



Image: Front view of the product packaging, showing the assembled set and Rapunzel.



Image: The Rapunzel's Petite Tower set shown in its open configuration, revealing the interior play space with the Rapunzel mini-doll.

Operating Instructions (Play Guide)

Once assembled, the LEGO 41163 set offers various play possibilities:

- **Imaginative Play:** Use the Rapunzel mini-doll and accessories to recreate scenes from Disney's Tangled or invent new adventures.
- **Hinged Tower:** The tower features a hinged base, allowing it to open and close. This provides access to the interior for play and compact storage.
- **Accessory Use:** The hairbrush can be used with the Rapunzel mini-doll, and the frying pan can be incorporated into

storytelling.

- **Combine with Other Sets:** This set is compatible with other LEGO Disney Princess building sets, allowing for expanded creative construction and storytelling.



Image: A child engaging in play with the assembled LEGO Rapunzel's Petite Tower, demonstrating its interactive features.

Maintenance

To ensure the longevity and cleanliness of your LEGO set:

- **Cleaning:** Clean LEGO bricks with mild soap and water (up to 40°C / 104°F). Rinse thoroughly and air dry. Do not use hot water, harsh chemicals, or abrasive materials.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to prevent discoloration or damage to the plastic. The hinged tower design allows for compact storage.
- **Handling:** Handle pieces carefully to avoid breakage.

Troubleshooting

LEGO sets are designed for durability and ease of assembly. Should you encounter any issues:

- **Missing Pieces:** If a piece is missing, please refer to the official LEGO customer service website for replacement parts.
- **Assembly Difficulty:** Double-check the instruction booklet steps. Ensure all pieces are correctly oriented and firmly pressed together.
- **Damaged Pieces:** Contact LEGO customer service for assistance with damaged components.

Specifications

Feature	Detail
Model Number	41163 (also listed as 6251001)
Brand	LEGO
Series	LEGO Disney Princess
Number of Pieces	44
Recommended Age	5 - 21 years (Manufacturer's minimum recommended age: 60 months)
Product Dimensions (L x W x H)	14.1 x 12.19 x 4.6 cm (5.55 x 4.8 x 1.81 inches)
Weight	0.09 grams
Material	Plastic
Color	Multicolor
Educational Objective	Creative thinking
Character	Disney Rapunzel
Release Date	January 1, 2019
UPC / GTIN	673419301633

Warranty and Support

LEGO products are manufactured to high-quality standards. For information regarding warranty, missing parts, or customer support, please visit the official LEGO website or contact their customer service directly.
Official LEGO Website: www.lego.com

© 2024 LEGO Group. All rights reserved. Disney elements © Disney.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GW1LMSH

More documents and user manuals: **https://manuals.plus/**