Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 2018082802

YING RAY Replacement Remote Control User Manual

For DANBY Air Conditioners

1. Introduction

This manual provides instructions for the YING RAY HA-DAN-03 replacement remote control, designed for use with specific DANBY portable air conditioner models. This remote control is a direct replacement and does not require any programming for operation.

Please read this manual thoroughly to ensure proper setup and use of your new remote control.

2. Compatibility

The HA-DAN-03 remote control is specifically designed to be compatible with the following DANBY portable air conditioner models:

- DPA100E1BDB
- DPA100E1WDB
- DPA120E1BDB
- DPA120E1WDB
- DPA100EAUWDB
- DPA100EAUBDB
- DPA120EAUWDB
- DPA120EAUBDB
- DPA120HEAUBDB
- DPA140HEAUBDB
- DPA140HEBUBDB
- DPA140HEAUWDB
- 810900129A
- 810900128F

Important: This is not a universal remote control. It is only compatible with the specific models listed above and those that use a remote control visually identical to the one shown in the main product image.



This image illustrates the YING RAY replacement remote control alongside two original Danby remote controls, indicating its compatibility as a direct replacement.

3. Setup

3.1 Battery Installation

The remote control requires two (2) "AAA" 1.5V ordinary batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open the compartment.
3. Insert two "AAA" batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



The back of the remote control with the battery cover removed, clearly showing the compartment for two AAA batteries and the battery springs.

3.2 Initial Use

Once batteries are installed, the remote control is ready for immediate use. No programming or pairing is required.

4. Operating Instructions

Point the remote control directly at the air conditioner's receiver window. Ensure there are no obstructions between the remote and the unit.


ON/OFF
FAN
MODE
SWING
TIMER
SLEEP
℃/°F
HA-DAN-03

This image displays the front of the replacement remote control, showing its buttons and LCD screen.

4.1 Button Functions

Button	Function
ON/OFF	Powers the air conditioner on or off.
FAN	Adjusts the fan speed (e.g., Low, Medium, High, Auto).
MODE	Cycles through operating modes (e.g., Cool, Dry, Fan, Heat, Auto).
SWING	Activates or deactivates the automatic louver swing function.
TIMER	Sets the timer for automatic power on/off. Refer to your air conditioner's manual for specific timer settings.
SLEEP	Activates the sleep mode, which adjusts temperature and fan speed for comfortable sleep.
°C/°F	Switches the temperature display between Celsius and Fahrenheit.
Temperature Up/Down Arrows	Adjusts the desired temperature setting.

4.2 Special Features

- **Noctilucent Buttons:** The ON/OFF and temperature adjustment buttons glow in the dark, providing visibility in low-light conditions.


ON/OFF
FAN
MODE
SWING
TIMER
SLEEP
℃/°F
HA-DAN-03

A close-up view of the remote control, pointing out the ON/OFF and temperature adjustment buttons that glow in the dark for easy visibility in low light.

- **Signal Indicator Light:** A small light on the remote illuminates when a button is pressed, indicating that a signal is being transmitted.



This image demonstrates the remote control's signal indicator light, which illuminates to confirm a signal is being transmitted.

5. Troubleshooting

5.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new "AAA" 1.5V batteries if necessary.
- **Battery Contact:** If the remote does not work after installing batteries, the battery springs might not be making proper contact with the battery's positive pole. Gently pull the battery spring out a little to ensure a firm connection.
- **Line of Sight:** Ensure there are no obstructions between the remote control and the air conditioner's infrared receiver.

- **Compatibility:** Double-check that your DANBY air conditioner model is listed in the compatibility section of this manual. This remote is not universal.

6. Specifications

- **Model Number:** 2018082802 (HA-DAN-03)
- **Battery Type:** 2 x "AAA" 1.5V Ordinary Battery
- **Number of Buttons:** 12
- **Special Feature:** Ergonomic design, Noctilucent buttons (ON/OFF, Temp Up/Down)

7. Support

For further assistance or inquiries regarding the compatibility or operation of your YING RAY replacement remote control, please contact the seller directly through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GWBQX98

More documents and user manuals: **https://manuals.plus/**