Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Holiday Living 220086

Holiday Living Zultan The Fortune Teller Animated Halloween Prop User Manual

Model: 220086

1. Introduction

This manual provides instructions for the setup, operation, and maintenance of your Holiday Living Zultan The Fortune Teller Animated Halloween Prop. Please read this manual thoroughly before use and retain it for future reference.
The Zultan Fortune Teller is an animated Halloween decoration designed for indoor use. It features light, sound, and motion activation to create an engaging display.

2. Important Safety Information

- **Indoor Use Only:** This product is designed exclusively for indoor environments. Do not expose to rain, moisture, or extreme temperatures.
- **Battery Safety:** Use only the specified battery type (4 AA batteries). Ensure correct polarity when inserting batteries. Do not mix old and new batteries, or different types of batteries. Remove batteries if the product is not used for an extended period.
- **Choking Hazard:** Keep small parts and packaging materials away from children.
- **Placement:** Place the prop on a stable, level surface to prevent tipping. Ensure it is not obstructing walkways or exits.
- **Electrical Safety:** Do not attempt to modify or repair the product. Refer all servicing to qualified personnel.

3. Package Contents

Upon opening the package, verify that all components are present:

- 1 x Zultan The Fortune Teller Animated Prop
- 4 x AA Batteries (pre-installed or included separately)
- 1 x Instruction Manual (this document)




Zultan
All Seeing
All Knowing



Figure 1: Zultan The Fortune Teller Animated Prop (Main View)

4. Setup Instructions

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for storage.
2. **Battery Installation:**
    - Locate the battery compartment, typically on the back or base of the prop.
    - Open the compartment cover.
    - Insert 4 AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
    - Close the battery compartment cover securely.
3. **Placement:** Position the Zultan prop on a flat, stable surface in your desired indoor location. Ensure there is enough space around it for its animated movements.



Figure 2: Zultan The Fortune Teller Prop in an indoor setting.

5. Operating Instructions

The Zultan Fortune Teller prop is motion-activated and designed for interactive display.

1. **Power On:** Locate the ON/OFF switch, usually near the battery compartment. Switch it to the "ON" position.
2. **Activation:** The prop is equipped with a motion sensor. When motion is detected within its range, Zultan will

activate.

3. **Animated Features:** Upon activation, Zultan will:
    - Illuminate (eyes and hands will glow).
    - Speak various spooky phrases.
    - Perform animated movements.
4. **Power Off:** To conserve battery life, switch the prop to the "OFF" position when not in use.

6. Maintenance

- **Cleaning:** Wipe the surface of the prop with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the prop in its original packaging in a cool, dry place, away from direct sunlight and moisture. Remove batteries before long-term storage.
- **Battery Replacement:** Replace all 4 AA batteries when the prop's lights dim, sounds become distorted, or animations slow down.

7. Troubleshooting

Problem	Possible Cause	Solution
Prop does not activate.	Power switch is OFF. Batteries are dead or incorrectly installed. Insufficient motion detected.	Ensure power switch is ON. Check battery polarity and replace batteries if necessary. Ensure motion is within sensor range and lighting conditions are adequate.
Lights are dim or sound is distorted.	Low battery power.	Replace all 4 AA batteries with new ones.
Prop makes clicking or grinding noises.	Obstruction in moving parts or internal mechanism issue.	Turn off the prop and inspect for any visible obstructions. If none, discontinue use and contact support.

8. Specifications

- **Brand:** Holiday Living
- **Model Number:** 220086
- **Height:** Approximately 5.34 feet (162.76 cm)
- **Power Source:** 4 x AA Batteries (included)
- **Features:** Motion-activated, Lights up, Speaks phrases, Animated
- **Intended Use:** Indoor decoration
- **Product Weight:** 9.59 kg (21.14 lbs)
- **Package Dimensions:** 91.44 x 56.51 x 34.29 cm (36 x 22.25 x 13.5 inches)

9. Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For warranty

inquiries or technical support, please contact Holiday Living customer service through their official website or the retailer where the product was purchased.
Please retain your purchase receipt as proof of purchase.

© 2023 Holiday Living. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GX11CX1

More documents and user manuals: **https://manuals.plus/**