Nine West NW/2229SVSV

Nine West Women's Mesh Bracelet Watch Instruction Manual

Model: NW/2229SVSV

Product Overview

This manual provides instructions for the Nine West Women's Mesh Bracelet Watch, model NW/2229SVSV. This timepiece features a classic design with a silver-tone finish and a comfortable mesh bracelet.

- **Crystal:** Slightly domed mineral crystal lens for durability.
- **Dial:** Silver-tone dial with matching hands and markers for clear readability.
- **Bracelet:** Silver-tone mesh bracelet with an adjustable sliding buckle for a secure and comfortable fit.
- **Movement:** Reliable Japanese-quartz movement ensures accurate timekeeping.
- **Case Diameter:** 31mm case size, suitable for a variety of wrist sizes.
- **Water Resistance:** Please note, this watch is not water resistant.

Setup

1. Adjusting the Mesh Bracelet

The mesh bracelet features an adjustable sliding buckle to ensure a perfect fit. To adjust:

1. Locate the clasp on the mesh bracelet.
2. Using a small tool (like a flat-head screwdriver or a paperclip), gently lift the locking plate on the clasp.
3. Slide the clasp along the mesh band to your desired wrist size.
4. Press the locking plate back down firmly until it clicks into place to secure the adjustment.



Image: Close-up of the adjustable sliding buckle on the mesh bracelet.

2. Setting the Time

To set the correct time on your watch:

1. Pull the crown (the small knob on the side of the watch case) outwards to the time-setting position.
2. Rotate the crown clockwise or counter-clockwise until the hour and minute hands indicate the correct time.
3. Once the time is set, push the crown back into its original position to start the watch movement.



Image: Side view of the watch, highlighting the crown for time adjustment.

3. Initial Operation

Your watch is powered by a Japanese-quartz movement and includes one product-specific battery. After setting the time, the watch should begin operating immediately. If the watch does not start, ensure the crown is fully pushed in.

Your browser does not support the video tag.

Video: A 21-second demonstration of the Nine West Women's NW/2229SVSV Silver-Tone Mesh Bracelet Watch, showcasing its design and features.

Operating Instructions

Your Nine West watch is designed for simple and reliable timekeeping. Once the time is set, no further daily adjustments are typically required unless the time needs to be reset due to travel or daylight saving changes.

- **Time Display:** The watch displays time using analog hour and minute hands.
- **Accuracy:** The Japanese-quartz movement provides accurate timekeeping.

Maintenance

Cleaning Your Watch

To maintain the appearance of your watch:

- Wipe the watch case and bracelet with a soft, dry cloth.
- Avoid using harsh chemicals, cleaning sprays, or abrasive materials, as these can damage the finish.

Water Resistance

This watch is **not water resistant**. To prevent damage:

- Avoid exposure to water, including showering, swimming, or heavy rain.
- Remove the watch before washing hands or engaging in activities where it might get wet.

Battery Replacement

The watch is powered by a product-specific battery. When the watch stops or the time becomes inconsistent, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and prevent damage to the movement.

Troubleshooting

If you encounter issues with your Nine West watch, consider the following common solutions:

- **Watch Not Running:** Ensure the crown is fully pushed in. If it still does not run, the battery may need replacement.
- **Incorrect Time:** Reset the time as described in the 'Setting the Time' section. If the time consistently becomes inaccurate, the battery may be low or the movement may require servicing.
- **Bracelet Discomfort:** Re-adjust the sliding buckle on the mesh bracelet for a more comfortable fit.

For issues not resolved by these steps, please refer to the Support section for further assistance.

Specifications

Feature	Detail
Model Number	NW/2229SVSV
Brand	Nine West
Movement Type	Japanese Quartz
Display Type	Analog
Case Material	Metal
Case Diameter	31 Millimeters

Feature	Detail
Case Thickness	10 Millimeters
Crystal Material	Mineral
Band Material	Stainless Steel
Band Width	12 Millimeters
Clasp Type	Hook Buckle (Sliding Clasp)
Water Resistance	Not Water Resistant
Power Source	Battery Powered (1 Product Specific battery included)
Item Weight	0.25 Pounds
Additional Features	Scratch-Resistant Crystal

Warranty

This Nine West watch is covered by a manufacturer's warranty. For specific details regarding the warranty period, coverage, and claims process, please refer to the warranty card included with your purchase or visit the official Nine West website.

Support

For further assistance, product inquiries, or service requests, please contact Nine West customer support or visit their official website. You can find more information and contact details on the Nine West Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question