Uni-Com JNS_469186

Uni-Com Portable & Plug In Door Chime - Twin Pack

Model: JNS_469186

Your comprehensive guide to installation, operation, and care.

Introduction

Thank you for choosing the Uni-Com Portable & Plug In Door Chime Twin Pack. This system provides a convenient and reliable way to be alerted when someone is at your door. The pack includes one wireless doorbell push button, one portable chime unit, and one plug-in chime unit, offering flexibility for various home setups.



Image: The complete Uni-Com Portable & Plug In Door Chime Twin Pack, showing the wireless doorbell button, the portable chime unit, and the plug-in chime unit.

Setup and Installation

Follow these steps to set up your Uni-Com door chime system.

1. Installing the Doorbell Push Button

- **Powering the Button:** The doorbell push button typically requires batteries (e.g., 1 x 12V A23 battery, not included). Open the battery compartment on the back of the button and insert the battery, ensuring correct polarity.
- **Mounting Location:** Choose a suitable location near your front door, ensuring it is easily accessible to visitors and protected from direct heavy rain.
- **Mounting:** Use the provided screws and wall plugs to securely mount the doorbell button to a wall or door frame. Alternatively, some models may include adhesive pads for mounting on smooth surfaces.

2. Setting Up the Plug-In Chime Unit

- **Power Connection:** Simply plug the chime unit into any standard indoor electrical wall socket. Ensure the socket is easily accessible and not obstructed.
- **Placement:** Position the plug-in chime in a central location within your home to ensure the sound can be heard throughout.



Image: The plug-in chime unit securely inserted into a standard wall socket, ready for operation.

3. Setting Up the Portable Chime Unit

- **Powering the Unit:** The portable chime unit typically requires batteries (e.g., 3 x AA batteries, not included). Open the battery compartment and insert the batteries, observing correct polarity.
- **Placement:** The portable chime can be placed anywhere within range of the doorbell button, allowing you to carry it with you or move it to different rooms as needed.



Image: The portable chime unit positioned on an outdoor wooden table, demonstrating its versatility.



Image: The portable chime unit placed on an indoor surface, next to a decorative lantern and a clock, highlighting its discreet design.

Operating Instructions

Once both the doorbell push button and chime units are powered and placed, the system is ready for use.

- **Activating the Chime:** When the doorbell push button is pressed, it sends a wireless signal to both the portable and plug-in chime units.
- **Sound Alert:** Upon receiving the signal, both chime units will sound the selected melody, alerting you to a visitor.
- **Range:** Ensure the doorbell button and chime units are within the effective wireless range. Obstacles like thick walls or metal structures can reduce the range.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your door chime system.

- **Cleaning:** Wipe the doorbell button and chime units with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these can damage the surface.
- **Battery Replacement (Doorbell Button):** If the doorbell button stops working or its range decreases, replace the battery (e.g., 1 x 12V A23).
- **Battery Replacement (Portable Chime):** If the portable chime unit stops working or its sound becomes weak, replace the batteries (e.g., 3 x AA).
- **Environmental Protection:** While the doorbell button is designed for outdoor use, avoid prolonged exposure to

extreme weather conditions.

Troubleshooting

If you encounter issues with your Uni-Com door chime, try the following solutions:

Problem	Possible Cause	Solution
Chime units do not ring when button is pressed.	Dead batteries in doorbell button or portable chime. Out of range. Interference.	Replace batteries in the doorbell button and portable chime. Move chime units closer to the doorbell button. Check for other wireless devices causing interference.
Chime rings intermittently or without pressing the button.	Interference from other wireless devices. Low battery in doorbell button.	Change the operating frequency/channel if your model supports it (refer to specific product instructions). Replace doorbell button battery.
Weak or distorted sound from chime unit.	Low batteries in portable chime. Unit too far from doorbell button.	Replace batteries in the portable chime. Relocate the chime unit closer to the doorbell button.

Specifications

Manufacturer: UNI-COM

Part Number: 4236

Product Dimensions: 250 x 165 x 78 cm (Packaging); 232 g (Total Weight)

Item Model Number: JNS_469186

Power Source (Plug-in Chime): AC

Included Components: Uni-Com Portable & Plug In Door Chime - Twin Pack (1 x Doorbell Push Button, 1 x Portable Chime Unit, 1 x Plug-in Chime Unit)

Date First Available: 20 July 2018

Warranty and Support

For detailed warranty information, please refer to the product packaging or the official Uni-Com website. Keep your proof of purchase for any warranty claims.

For further assistance, technical support, or to inquire about replacement parts, please contact Uni-Com customer support through their official channels. Contact details can typically be found on the product packaging or the manufacturer's website.

© 2024 Uni-Com. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question