Passion-Electro AM1150

Passion-Electro Replacement Remote Control for Thomson AM1150 HI-FI System

Instruction Manual

1. Introduction

This manual provides instructions for the Passion-Electro replacement remote control, specifically designed for the Thomson AM1150 HI-FI system. This remote offers full functionality comparable to the original remote control without requiring any programming. Simply insert the batteries, and it is ready for use.

Key Features:

- No programming required.
- Access to all functions of the original remote control.
- New product, ready for immediate use.



Image: Side view of the Passion-Electro replacement remote control.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA 1.5V batteries (LR03-AAA). Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back view of the remote control, illustrating the battery compartment.



Image: Bottom view of the remote control, showing the battery compartment cover.

Once batteries are installed, the remote control is ready for immediate use with your Thomson AM1150 HI-FI system.

3. Operating Instructions

This replacement remote control is designed to replicate the full functionality of your original Thomson AM1150 HI-FI system remote. Point the remote control directly at your HI-FI system for optimal performance.

3.1 Basic Functions

- **Power Button:** Located at the top right (often red), press to turn the HI-FI system on or off.
- **Volume Control:** Use the 'VOL+' and 'VOL-' buttons to adjust the sound level.
- **Channel/Track Navigation:** Use the arrow buttons (up/down, left/right) or numbered buttons to select tracks, radio stations, or navigate menus.
- **Mute Button:** Press to temporarily silence the audio. Press again to restore sound.
- **Source/Input Selection:** Use the 'Source' or 'Input' button to switch between different audio sources (e.g., CD, Radio, AUX).



Image: Angled top view of the remote control, displaying the layout of various function buttons.

3.2 Advanced Functions

Refer to your Thomson AM1150 HI-FI system's original manual for specific functions and their corresponding buttons on the remote control. This replacement remote is designed to support all original functions.

4. Maintenance

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or buttons.

4.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA 1.5V batteries. Do not mix old and new batteries or different types of batteries.

4.3 Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the HI-FI system's infrared receiver.
  - Make sure you are pointing the remote directly at the HI-FI system.
- **Some functions not working:**
  - Verify that the HI-FI system is powered on and in the correct input mode.
  - Ensure the remote control is clean and free from debris that might obstruct button presses.

6. Specifications

Brand:	Passion-Electro
Model Compatibility:	Thomson AM1150 HI-FI System
Batteries Required:	2 x AAA (LR03-AAA) 1.5V
Batteries Included:	No
Item Weight:	100 g
ASIN:	B07H74DX38
First Available Date:	October 3, 2018

7. Support

For further assistance or inquiries regarding your Passion-Electro replacement remote control, please

contact the manufacturer or your retailer. Ensure you have your product model (Thomson AM1150) and the remote's brand (Passion-Electro) available when seeking support.

© 2026 Passion-Electro. All rights reserved.