Marshall 1002489

Marshall Woburn II Wireless Bluetooth Speaker

MODEL: 1002489 USER MANUAL

Introduction

The Marshall Woburn II Wireless Bluetooth Speaker is engineered to deliver a powerful and resonant sound experience, reminiscent of live music. It features a robust sound profile with clear high trebles, easily handled low bass, and a lifelike mid-range. Designed with classic Marshall aesthetics, including a textured vinyl covering and iconic script logo, this speaker combines vintage appeal with modern audio technology.

Package Contents

Ensure all items listed below are present in your package:

- Woburn II Speaker
- User Manual
- 3.5mm Cable



Image: Marshall Woburn II speaker with its user manual and 3.5mm audio cable.

Product Overview

The Woburn II features a classic design with modern controls. The top panel provides intuitive access to volume, bass, and treble adjustments, along with source selection and playback controls.



Image: Front view of the Marshall Woburn II speaker in black.



Image: Detailed view of the speaker's top panel with brass-finished knobs for volume, bass, and treble, along with source selection and power toggle.



Image: Back panel of the Marshall Woburn II speaker, showing the power input, RCA, and other connection ports.

Initial Setup

Follow these steps to set up your Marshall Woburn II speaker:

1. **Power Connection:** Connect the power cable to the speaker's rear panel and plug it into a wall outlet.
2. **Bluetooth Pairing:** Activate Bluetooth on your audio device. On the speaker's top panel, press and hold the SOURCE button until the Bluetooth indicator light starts blinking. Select 'Woburn II' from your device's Bluetooth list to pair. Bluetooth 5.0 with aptX technology provides lossless wireless sound at a range of up to 30 feet while maintaining connectivity.
3. **Wired Connections:** For an analog listening experience, plug into the RCA or 3.5mm input ports located on the top panel.
4. **Marshall Bluetooth App:** Download the Marshall Bluetooth app from your device's app store. Use the app to customize your sound, fine-tune equalization, and control music playback.

Basic Operation

Once set up, operating your Woburn II is straightforward:

- **Volume Control:** Use the large VOLUME knob on the top panel to adjust the overall sound level.
- **Bass and Treble Adjustment:** Fine-tune your music's bass and treble levels using the dedicated BASS and TREBLE knobs to suit your preferences and room acoustics.

- **Source Selection:** Press the SOURCE button to cycle through available input sources (Bluetooth, AUX, RCA).
- **Playback Controls:** Use the play/pause and skip buttons on the top panel for convenient music control.

Care and Maintenance

To ensure the longevity and optimal performance of your Marshall Woburn II speaker, follow these care guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the speaker's exterior. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- **Placement:** Place the speaker on a stable, flat surface. Ensure adequate ventilation around the unit to prevent overheating.
- **Environmental Conditions:** Avoid exposing the speaker to extreme temperatures, humidity, or direct sunlight. Keep it away from water and other liquids.
- **Handling:** Handle the speaker with care. Avoid dropping it or subjecting it to strong impacts.

Troubleshooting Guide

If you encounter any issues with your Marshall Woburn II speaker, refer to the following common troubleshooting steps:

- **No Power:** Ensure the power cable is securely connected to both the speaker and a working power outlet. Check if the power switch on the top panel is in the 'ON' position.
- **No Sound:** Verify that the correct input source is selected (Bluetooth, AUX, or RCA). Increase the volume on both the speaker and your audio device. Check all cable connections for wired sources.
- **Bluetooth Pairing Issues:** Make sure the speaker is in pairing mode (blinking Bluetooth indicator). Disable and re-enable Bluetooth on your audio device. Try forgetting the speaker from your device's Bluetooth settings and re-pairing. Ensure your device is within the 30-foot Bluetooth range.
- **Distorted Sound:** Reduce the volume on both the speaker and your audio device. Adjust the bass and treble knobs to a neutral position. Ensure the audio source is not overdriven.
- **Intermittent Connectivity:** Move the speaker closer to your audio device. Avoid placing the speaker near other electronic devices that may cause interference.

If the issue persists after trying these steps, please contact customer support.

Technical Specifications

Feature	Specification
Brand	Marshall
Model Name	Woburn II
Item Model Number	1002489
Speaker Type	Bluetooth
Connectivity Protocol	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters

Speaker Maximum Output Power	130 Watts
Subwoofer Diameter	5.25 Inches
Tweeter Diameter	25.4 Millimeters
Product Dimensions	18.7"D x 11.1"W x 15.4"H
Item Weight	18.85 pounds
Material	Wood
Color	Black
Power Source	Battery Powered
Number of Batteries	1 Lithium Polymer batteries required.
Is Waterproof	FALSE

Warranty & Support

The Marshall Woburn II Wireless Bluetooth Speaker is covered by the Zound Industries USA Inc. one-year Limited Warranty. Additional terms may apply. Please refer to the official user manual for complete warranty details.

For further assistance or support, please consult the full User Manual (PDF) available for download or contact Marshall customer service.

Official User Manual (PDF): Download Here

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question