Maxshine M15Pro

Maxshine M15 Pro Dual Action Polisher User Manual

Model: M15Pro

Introduction

Thank you for choosing the Maxshine M15 Pro Dual Action Polisher. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new polisher. Please read this manual thoroughly before first use and retain it for future reference.
The Maxshine M15 Pro is engineered for professional-grade car detailing and paint correction, offering a 15mm orbital throw for efficient coverage and a powerful 1000W motor for consistent performance. Its ergonomic design ensures comfortable use during extended sessions.

What's in the Box?

Upon opening your Maxshine M15 Pro package, please verify that all the following components are included:

- 1 x Maxshine M15 Pro Dual Action Polisher
- 1 x Tool Bag
- 1 x D-Handle
- 1 x 5-inch Backing Plate
- 2 x Additional Carbon Brushes
- Necessary Hardware (e.g., Allen wrench for assembly)



Image: The Maxshine M15 Pro Dual Action Polisher along with its standard accessories, including the tool bag, D-handle, backing plate, and additional brushes.

Setup

Before operating the polisher, ensure it is properly assembled and connected.

1. Attaching the Backing Plate

1. Ensure the polisher is unplugged from the power source.
2. Align the 5-inch backing plate with the spindle on the polisher.
3. Thread the backing plate onto the spindle by turning it clockwise until it is securely tightened. Use the provided wrench if necessary to hold the spindle.



Image: A detailed view of the polisher's head, showing the attachment point for the backing plate and the internal orbital mechanism.

2. Attaching the D-Handle

1. Locate the two screw holes on the top of the polisher's body.
2. Align the D-handle with these holes.
3. Insert the provided screws and tighten them securely with the appropriate tool.



Image: Side profile of the Maxshine M15 Pro, illustrating the ergonomic grip and the attachment points for the D-handle.

3. Power Connection

Connect the polisher's 13-foot reinforced power cord to a standard 110V AC outlet. Ensure the power cord is free from kinks or damage before plugging in.

Operating Instructions

Follow these guidelines for effective and safe operation of your Maxshine M15 Pro Dual Action Polisher.

1. Attaching Polishing Pads

The 5-inch backing plate is compatible with most foam and microfiber pads. Simply center the desired pad onto the backing plate, ensuring it adheres firmly via the hook-and-loop system.

2. Powering On and Speed Control

To turn on the polisher, press the power switch. The polisher features a variable speed dial, allowing you to adjust

the RPM from 2200 to 5000. Start at a lower speed for initial product spreading and increase as needed for compounding or polishing tasks.



Image: A close-up of the speed control dial, located conveniently on the polisher's body for easy adjustment during operation.

3. Polishing Technique

Apply a small amount of polishing compound or wax directly to the pad or the vehicle surface. Place the pad flat on the surface before turning on the polisher to prevent product sling. Move the polisher in a controlled, overlapping pattern, applying even pressure. The 15mm orbital throw ensures efficient coverage and swirl-free results.



Image: A user demonstrating the proper technique for operating the Maxshine M15 Pro on a car's paint, showcasing the ergonomic grip.



Image: The Maxshine M15 Pro in action, effectively removing imperfections and restoring gloss on a dark vehicle surface.

4. Ergonomics and Control

The ergonomic rubberized grip and optional D-handle are designed to reduce user fatigue, allowing for comfortable and controlled operation even during prolonged detailing sessions. Maintain a firm but relaxed grip to guide the polisher smoothly across surfaces.



Image: The polisher being used with the D-handle attached, illustrating how it enhances comfort and control during operation.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your Maxshine M15 Pro polisher.

1. Cleaning

- Always unplug the polisher before cleaning.
- Wipe down the exterior of the polisher with a clean, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- Clean the backing plate regularly to ensure proper pad adhesion.
- Periodically clear any dust or debris from the motor vents to prevent overheating.

2. Carbon Brush Replacement

The polisher is equipped with carbon brushes that wear down over time. When the motor performance decreases or the polisher stops working, the carbon brushes may need replacement. Your polisher comes with two additional brushes.

1. Unplug the polisher.
2. Locate the brush caps on the sides of the motor housing.
3. Unscrew the caps and remove the old carbon brushes.
4. Insert the new carbon brushes, ensuring they are oriented correctly.
5. Replace and tighten the brush caps.

Troubleshooting

If you encounter issues with your Maxshine M15 Pro, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Polisher does not turn on.	No power supply; faulty power cord; worn carbon brushes.	Check power outlet and cord. Replace carbon brushes if worn.
Pad stops rotating (stalling).	Excessive pressure; uneven surface contact; worn backing plate.	Reduce pressure. Ensure pad is flat on the surface. Inspect backing plate for wear.
Excessive vibration or noise.	Loose backing plate; unbalanced pad; internal component issue.	Ensure backing plate is tight. Check pad for balance. If issue persists, contact support.
Motor overheating.	Blocked air vents; continuous heavy use.	Clear air vents. Allow polisher to cool down during prolonged use.

If the problem persists after attempting these solutions, please contact Maxshine customer support for further assistance.

Specifications

Feature	Detail
Model Number	M15Pro
Power Source	Corded Electric
Voltage	110 Volts
Wattage	1000 Watts
Speed	2200-5000 RPM (No-load speed)
Orbital Throw	15mm
Backing Plate Size	5 inches
Item Weight	5.06 pounds (2.3 Kilograms)
Product Dimensions	18.4 x 6.8 x 6.2 inches
Cord Length	13 feet (4 meters)
UPC	614070283548, 671587893264

Warranty Information

The Maxshine M15 Pro Dual Action Polisher comes with a manufacturer's warranty. For specific details regarding the warranty period, coverage, and terms, please refer to the warranty card included with your product or visit the official Maxshine website.

Customer Support

For any questions, technical assistance, or service inquiries regarding your Maxshine M15 Pro Dual Action Polisher, please contact Maxshine customer support. You can find contact information on the official Maxshine website or through the retailer where you purchased the product.
Visit the official Maxshine Store for more information:Maxshine Store

© 2024 Maxshine. All rights reserved.