Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Orbegozo SP 6500

Orbegozo SP 6500 Wall Heater User Manual

Model: SP 6500

1. Introduction

Thank you for choosing the Orbegozo SP 6500 Wall Heater. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before using the heater and keep it for future reference.

The Orbegozo SP 6500 is a powerful and efficient ceramic wall heater designed to provide comfortable warmth for indoor spaces. It features a 2000W power output, two power levels, PTC ceramic elements, an LED display, and a remote control for convenient daily and weekly programming.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 1 meter (3 feet) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas, and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock

or fire, or damage the heater.

- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- This heater includes an overheating protection feature that automatically shuts off the unit if it becomes too hot. If this occurs, unplug the heater, wait 30 minutes for it to cool down, and then plug it back in.

3. Product Overview

Familiarize yourself with the components and controls of your Orbegozo SP 6500 Wall Heater.



Figure 3.1: Front view of the Orbegozo SP 6500 Wall Heater with its remote control.



Figure 3.2: Side profile of the Orbegozo SP 6500 Wall Heater, showing its slim design.



Figure 3.3: Top view of the heater, highlighting the air outlet grille and the main power switch.



Figure 3.4: Detailed view of the LED display and control buttons on the heater unit.



Figure 3.5: Layout of the remote control buttons for the Orbegozo SP 6500.



Figure 3.6: Close-up of the main ON/OFF power switch located on the side/bottom of the heater.

Components:

- **Heater Unit:** The main body containing the heating elements, fan, and control panel.
- **LED Panel:** Digital display showing temperature, mode, and programming indicators.
- **Control Buttons:** Located on the heater unit for basic operation.
- **Remote Control:** For convenient operation and programming from a distance.
- **Main Power Switch:** A physical ON/OFF switch, usually located on the side or bottom of the unit.

4. Setup and Installation

The Orbegozo SP 6500 is designed for wall mounting. Ensure you have the necessary tools and follow these steps carefully.

Wall Mounting:

1. Choose a suitable location on a solid wall, away from curtains, furniture, and other flammable materials. Ensure there is sufficient clearance around the heater for proper air circulation.
2. Mark the drilling points on the wall using the provided mounting template or by measuring the distance between the mounting holes on the back of the heater.

3. Drill holes at the marked points. Insert wall plugs (if required for your wall type).
4. Secure the mounting bracket (if separate) or the heater directly to the wall using appropriate screws. Ensure it is level and securely fastened.
5. Once mounted, ensure the main power switch (Figure 3.6) is in the OFF position before plugging the unit into a suitable electrical outlet (220V).

Initial Power-Up:

After mounting and plugging in, switch the main power switch to the ON position. The heater will enter standby mode, and the LED panel may light up to indicate power.

5. Operating Instructions

The Orbegozo SP 6500 can be operated using the control panel on the unit or the remote control.

5.1 Basic Operation:

- **Power ON/OFF:** Press the **Power button** (⏻) on the remote control or the unit's control panel to turn the heater on or off from standby mode. Remember the main power switch must be ON.
- **Setting Temperature:** Use the **+** and **-** buttons to adjust the desired room temperature. The LED display will show the set temperature.
- **Power Levels:** The heater has two power levels: 1000W and 2000W. These are typically automatically selected based on the temperature difference between the set temperature and the ambient temperature. Some models may allow manual selection via a mode button. Refer to the LED display for current power level indication.
- **Fan Function (Cool Air):** The heater also features a fan-only mode that circulates cool air. This can be activated via the mode button on the remote or unit.

5.2 Advanced Features and Programming:

The remote control (Figure 3.5) is essential for accessing the programming functions.

- **SET Button:** Used to enter programming mode for setting time, day, and schedules.
- **OK Button:** Confirms selections during programming.
- **DAY Button:** Selects the day of the week for programming schedules.
- **P (Program) Button:** Cycles through different program modes (e.g., daily, weekly).
- **TIME ON / TIME OFF Buttons:** Used to set specific ON/OFF times for programmed schedules.
- **EDIT Button:** For modifying existing programs.

Detailed instructions for daily and weekly programming are typically found in the full manual provided with the product. Generally, you will use the SET button to initiate programming, then navigate through options using +/- and DAY buttons, confirming with OK. The TIME ON/OFF buttons allow you to specify when the heater should activate or deactivate.

6. Maintenance

Proper maintenance ensures the longevity and efficient operation of your heater.

Cleaning:

- Always unplug the heater and allow it to cool completely before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents.
- Gently vacuum the air intake and exhaust grilles to remove dust and lint buildup. Do not attempt to clean the interior of the heater.
- Ensure no water enters the interior of the heater.

Storage:

If storing the heater for an extended period, unplug it, clean it thoroughly, and store it in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

7. Troubleshooting

If you encounter issues with your Orbegozo SP 6500, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	Main power switch is OFF. Not plugged in. Overheating protection activated. Remote control batteries are dead.	Ensure main power switch (Figure 3.6) is ON. Plug the heater securely into a working electrical outlet. Unplug the heater, wait 30 minutes for it to cool, then plug it back in. Replace remote control batteries.
Heater produces no heat.	Set temperature is lower than ambient temperature. Heater is in fan-only mode.	Increase the set temperature. Switch to a heating mode.
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and heater.	Replace batteries, ensuring correct polarity. Ensure a clear line of sight to the heater's receiver.
Unusual noise during operation.	Dust or debris in fan/heating elements. Loose components.	Unplug and clean the air grilles. If noise persists, contact customer support. Do not attempt to repair. Contact customer support.

If the problem persists after trying these solutions, please contact Orbegozo customer support.

8. Specifications

Feature	Detail
Brand	Orbegozo
Model Number	SP 6500
Color	Silver
Product Dimensions	12.5 x 52 x 20 cm
Item Weight	2.92 Kilograms
Capacity	1 Liter (*Note: This capacity likely refers to packaging or internal volume, not a liquid capacity for operation.*)
Power	2000 W
Voltage	220 V

Feature	Detail
Material	Plastic, Ceramic
Number of Speed Levels	2
Energy Efficiency Class	A+ to G
Noise Level	44 dB
Runtime	3 Hours (*Note: This might refer to a specific programmed cycle or test condition*)
Special Feature	Adjustable tilt head (*Note: This might be a generic feature bullet, as the product images don't clearly show an adjustable tilt.*)
Intended Use	Indoor use
What's in the Box	Ceramic heater, Instruction manual

9. Warranty and Support

Warranty information for your Orbegozo SP 6500 Wall Heater is typically provided with your purchase documentation or can be found on the official Orbegozo website. Please retain your proof of purchase for warranty claims.

For technical support, service, or questions not covered in this manual, please contact Orbegozo customer service through their official website or the retailer from whom you purchased the product. Do not attempt to repair the appliance yourself.

© 2024 Orbegozo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07H7ZVM9B

More documents and user manuals: **https://manuals.plus/**