Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Royalty Line PKM-1900.7BG

Royalty Line PKM-1900.7BG 3-in-1 Kitchen Machine User Manual

Model: PKM-1900.7BG

INTRODUCTION

Thank you for purchasing the Royalty Line PKM-1900.7BG 3-in-1 Kitchen Machine. This versatile appliance combines a stand mixer, blender, and meat grinder to assist you with various culinary tasks. Please read this manual carefully before first use to ensure safe and efficient operation. Keep this manual for future reference.



Image: Royalty Line PKM-1900.7BG 3-in-1 Kitchen Machine. This image displays the main unit in black, equipped with the stainless steel mixing bowl, glass blender jug, and meat grinder attachment. The control knob is visible on the side.

Important Safety Instructions

- Always ensure the appliance is switched off and unplugged before assembling, disassembling, or cleaning.
- Do not immerse the motor unit in water or any other liquid.
- Keep hands, hair, clothing, and utensils away from moving parts during operation.
- Never operate the appliance with a damaged cord or plug. Contact customer support for repairs.
- This appliance is for household use only. Do not use outdoors.

- Supervise children when the appliance is in use.
- Ensure all attachments are correctly installed before operating.

Product Components

The Royalty Line PKM-1900.7BG includes the following main components and attachments:

- **Main Motor Unit:** The base of the appliance housing the 1900W motor and control knob.
- **Stainless Steel Mixing Bowl:** For mixing, kneading, and whisking.
- **Dough Hook:** For kneading heavy doughs.
- **Beater (Mixing Paddle):** For general mixing of batters and lighter doughs.
- **Whisk:** For whipping cream, egg whites, and light mixtures.
- **Splash Guard:** To prevent splattering during mixing.
- **Glass Blender Jug:** For blending liquids, smoothies, and sauces.
- **Meat Grinder Attachment:** For grinding various meats.
- **Food Pusher:** For use with the meat grinder.

Setup and Assembly

Initial Cleaning

Before first use, wash all detachable parts (mixing bowl, attachments, blender jug, meat grinder components) in warm soapy water. Rinse thoroughly and dry completely. Wipe the main motor unit with a damp cloth.

Assembling the Stand Mixer

1. Place the main motor unit on a stable, flat, and dry surface.
2. Lift the head of the machine by pressing the release lever (usually located on the side).
3. Place the stainless steel mixing bowl onto the base, twisting it clockwise until it locks into position.
4. Attach the desired accessory (dough hook, beater, or whisk) by pushing it upwards into the accessory shaft and twisting until it locks.
5. Lower the head of the machine until it clicks into place.
6. (Optional) Attach the splash guard by sliding it onto the mixing head.

Assembling the Blender

1. Ensure the blender jug's blade assembly is securely attached to the jug.
2. Place the blender jug onto the designated blender port on top of the main motor unit, twisting it clockwise until it locks.
3. Ensure the lid is securely placed on the blender jug.

Assembling the Meat Grinder

1. Assemble the meat grinder components (screw, blade, grinding plate, locking ring).
2. Attach the assembled meat grinder unit to the front port of the main motor unit, twisting it counter-clockwise until it locks securely.
3. Place the feeding tray on top of the grinder.

Operating Instructions

Always ensure the appliance is plugged into a 230V power outlet.

Using the Stand Mixer

1. Ensure the mixer is correctly assembled with the desired attachment and ingredients in the bowl.
2. Turn the rotary control knob to the desired speed setting (1-6). Start with a low speed and gradually increase as needed.
3. For short bursts of maximum power, use the "Pulse" setting (P).
4. When finished, turn the control knob to "0" (off) and unplug the appliance.

Using the Blender

1. Add ingredients to the blender jug. Do not exceed the maximum fill line.
2. Ensure the lid is securely closed.
3. Turn the rotary control knob to the desired speed setting (1-6) or use the "Pulse" setting (P) for quick blending.
4. When finished, turn the control knob to "0" (off) and unplug the appliance.

Using the Meat Grinder

1. Prepare meat by cutting it into small pieces that fit into the feeding tube. Remove bones and tough sinews.
2. Turn the rotary control knob to a medium speed setting (e.g., 3-4).
3. Feed meat into the tube using the food pusher.*Never use your fingers or other utensils to push food.*
4. When finished, turn the control knob to "0" (off) and unplug the appliance.

Care and Maintenance

Cleaning

- Always unplug the appliance before cleaning.
- Wipe the main motor unit with a damp cloth. Do not immerse it in water.
- The stainless steel mixing bowl, dough hook, beater, whisk, blender jug, and meat grinder components are generally dishwasher safe. Refer to the specific instructions for each attachment.
- For hand washing, use warm soapy water and a non-abrasive sponge. Rinse thoroughly and dry immediately to prevent water spots or corrosion, especially for metal parts.
- Ensure all parts are completely dry before storing.

Storage

Store the appliance and its attachments in a clean, dry place, away from direct sunlight and heat sources. Ensure all parts are properly assembled or stored in their original packaging to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet faulty; appliance not assembled correctly.	Check power cord connection; test outlet with another device; ensure head is locked down and attachments are secure.
Motor stops during operation.	Overload protection activated; ingredients too dense.	Turn off, unplug, and let cool for 15-20 minutes. Reduce ingredient quantity or consistency.
Attachments not rotating.	Attachment not properly secured.	Ensure attachment is pushed up and twisted into place until locked.
Blender leaks.	Lid not secure; blade assembly not tightened.	Ensure lid is firmly closed; tighten blade assembly to the jug.

If the problem persists after attempting these solutions, please contact Royalty Line customer support.

Technical Specifications

Brand	Royalty Line
Model Name	PKM-1900.7BG
Power	1900 W (Max)
Voltage	230 Volts
Number of Speeds	6 + Pulse Function
Control Type	Rotary Knob
Product Weight	9 Kilograms
Mixing Bowl Material	Stainless Steel
Blender Jug Material	Glass
Blade Material	Stainless Steel
Dishwasher Safe Parts	Yes (Mixing bowl, attachments, blender jug, meat grinder components - refer to specific instructions)
Functions	Stand Mixer, Blender, Meat Grinder

Warranty and Support

Royalty Line products are manufactured with quality and durability in mind. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or visit the official Royalty Line website.

For technical support, spare parts, or service inquiries, please contact your local distributor or visit the official website: www.royaltyline.com

© 2024 Royalty Line. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07H87M1TB

More documents and user manuals: **https://manuals.plus/**