**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### seenda wireless-mouse-WGSB-012-Mini-Green-Y

# seenda Wireless Mouse Instruction Manual

Model: wireless-mouse-WGSB-012-Mini-Green-Y
Brand: seenda

## 1. Product Overview

The seenda 2.4G Noiseless Wireless Mouse is designed for comfortable and quiet operation, suitable for various computing environments. It features a compact, portable design and a reliable 2.4GHz wireless connection.




Image 1.1: The seenda wireless mouse in mint green, shown with its accompanying USB receiver.

Key features include:

- **2.4GHz Wireless Technology:** Provides a stable and reliable connection up to 33 feet.

- **Noiseless Clicks:** Designed for quiet operation, minimizing disturbance.
- **Portable Design:** Compact size for easy storage and transport.
- **Energy Saving:** Automatic sleep mode after 10 minutes of inactivity to conserve battery life.
- **Universal Compatibility:** Compatible with Windows XP, Vista, 7, Mac OS X 10.4 and later (Note: Requires USB-A port, will NOT compatible with devices that only have Type-C ports).

## 2. What's in the Box

Upon opening the package, please verify that all components are present:

- 1 x seenda Wireless Mouse
- 1 x USB Receiver
- 1 x User Manual

*Note: AA battery is not included and must be purchased separately.*

## 3. Specifications

| Feature | Detail |
|---|---|
| Model Number | wireless-mouse-WGSB-012-Mini-Green-Y |
| Connectivity Technology | 2.4G USB Wireless |
| Movement Detection | Optical |
| Operating Range | Up to 33 feet (10 meters) |
| Power Source | 1 x AA Battery (not included) |
| Product Dimensions | 4.02 x 2.01 x 1.18 inches (10.2 x 5.1 x 3 cm) |
| Item Weight | 2.39 ounces (67.7 grams) |
| Color | Mint Green |
| Compatibility | Windows XP/Vista/7, Mac OS X 10.4 and later (USB-A port required) |

## 4. Setup Guide

Follow these steps to set up your seenda wireless mouse:

1. **Insert Battery:**

   Locate the battery compartment on the underside of the mouse. Open the cover and insert one AA battery, ensuring correct polarity (+/-). Close the battery cover securely.




Image 4.1: Underside view of the mouse, highlighting the battery slot and USB receiver storage.

2. **Retrieve USB Receiver:**

   The USB receiver is stored inside the battery compartment for convenience during transport. Gently pull out the small USB receiver.

3. **Connect USB Receiver:**

   Plug the USB receiver into an available USB-A port on your computer, laptop, or tablet. Ensure the connection is firm.




Image 4.2: The wireless mouse in use, with its USB receiver plugged into a laptop's USB port.

4. **Automatic Driver Installation:**

   Your operating system should automatically detect and install the necessary drivers. This is a plug-and-play device, so no manual driver installation is typically required.

5. **Begin Use:**

   Once the drivers are installed, the mouse is ready for immediate use.

## 5. Operating Instructions

The seenda wireless mouse operates like a standard optical mouse with additional features for convenience.

### 5.1 Basic Functions

- **Left Click:** Primary button for selecting items, opening files, etc.
- **Right Click:** Secondary button for context menus and additional options.
- **Scroll Wheel:** Scroll up or down through documents and web pages.
- **Middle Click (Scroll Wheel Button):** Often used for opening links in new tabs or other application-specific functions.




Image 5.1: A hand demonstrating the ergonomic grip on the seenda wireless mouse.

### 5.2 Power Saving Mode

To conserve battery life, the mouse will automatically enter sleep mode after approximately 10 minutes of inactivity. To wake the mouse, simply click any button. There is no manual on/off switch.




Image 5.2: Visual representation of the mouse's low power consumption and automatic sleep mode.

## 6. Maintenance

Proper care will extend the life of your wireless mouse.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the device. Do not use harsh chemicals or abrasive cleaners.
- **Battery Replacement:** When the mouse performance degrades or it stops responding, replace the AA battery. Always dispose of used batteries responsibly according to local regulations.
- **Storage:** When not in use for extended periods, it is recommended to remove the battery to prevent leakage. Store the USB receiver inside the mouse's battery compartment to avoid loss.
- **Environment:** Avoid exposing the mouse to extreme temperatures, direct sunlight, or high humidity.

## 7. Troubleshooting

If you encounter issues with your seenda wireless mouse, please refer to the following common solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Mouse not responding | Low or dead battery | Replace the AA battery. |
| Mouse not responding | USB receiver not properly connected | Ensure the USB receiver is firmly plugged into a working USB-A port. Try a different USB port. |
| Mouse not responding | Out of range | Move the mouse closer to the USB receiver (within 33 feet). |
| Mouse not responding | Interference from other wireless devices | Move the mouse and receiver away from other 2.4GHz wireless devices (e.g., Wi-Fi routers, cordless phones). |
| Cursor movement is erratic or jumpy | Dirty optical sensor | Clean the optical sensor on the underside of the mouse with a soft, lint-free cloth. |
| Cursor movement is erratic or jumpy | Unsuitable surface | Use the mouse on a non-reflective, opaque surface. A mouse pad is recommended. |

| | | |
|---|---|---|
| Mouse enters sleep mode too quickly | Normal operation | The mouse is designed to enter sleep mode after 10 minutes of inactivity to save power. Click any button to wake it up. |

## 8. Warranty and Support

seenda provides a standard warranty for this product. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official seenda website.

For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact seenda customer service through their official channels. You can often find contact information on the product packaging or the seenda brand store on Amazon:

Visit the seenda Store on Amazon

*Please note: No official product videos were available for embedding based on the provided data.*

© 2024 seenda. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B07H8TJMX7**

More documents and user manuals: **https://manuals.plus/**