Nerf E3002CU00

Nerf Microshots Zombie Strike Flipfury Instruction Manual

Model: E3002CU00

Product Overview

The Nerf Microshots Zombie Strike Flipfury is a compact, collectible blaster designed for quick, single-shot action. It is part of the Microshots series, offering a mini-sized version of a favorite Nerf blaster, perfect for defending against zombies or engaging in friendly dart battles.



Image 1: The Nerf Microshots Zombie Strike Flipfury blaster, showcasing its compact design and included dart.

What's in the Box

- Nerf Microshots Zombie Strike Flipfury Blaster
- 2 Official Nerf Zombie Strike Darts

Important Safety Information

WARNING: CHOKING HAZARD – Small parts may be generated. Not for children under 3 years.
Always use official Nerf darts. Do not modify darts or blaster. Do not aim at eyes or face. Protective eyewear is recommended for players and people within range.

Setup

Loading Darts

1. Locate the dart loading port at the front of the blaster.
2. Insert one official Nerf Zombie Strike dart into the port until it is fully seated.


NERF
MICRO
SHOTS

Image 2: View of the blaster's handle, showing the pull tab at the bottom used for priming.





Image 3: Close-up of the front of the blaster, illustrating where darts are inserted.

Operating the Blaster

Priming and Firing

1. Ensure a dart is loaded into the blaster.
2. Pull the priming handle located at the bottom of the blaster's grip downwards until it clicks into place. This primes the blaster.
3. Aim the blaster at your target, ensuring no one is in the line of fire.
4. Press the trigger to fire the dart.

The Nerf Microshots Zombie Strike Flipfury fires one dart at a time. Reload after each shot for continuous play.

Maintenance

- Keep the blaster clean by wiping it with a dry cloth.
- Do not use water or cleaning solutions on the blaster.
- Store darts in a clean, dry place to maintain their shape and performance.
- Avoid exposing the blaster to extreme temperatures or direct sunlight for prolonged periods.

Troubleshooting

Problem	Possible Cause	Solution
Dart does not fire or fires weakly.	Blaster not fully primed, dart not fully inserted, or dart is damaged.	Ensure priming handle is pulled all the way down until it clicks. Push dart fully into the barrel. Replace damaged darts with new ones.
Priming handle is stuck.	Dart jammed inside the barrel.	Check the barrel for any jammed darts and carefully remove them. Do not force the priming handle.

Specifications

Brand: Nerf

Model: E3002CU00

Product Dimensions: 1.58 x 7.09 x 6.97 inches

Item Weight: 6.3 ounces

Manufacturer Recommended Age: 8 years and up

Release Date: August 1, 2018

Manufacturer: Hasbro

Warranty and Support

For warranty information or product support, please visit the official Nerf website or contact Hasbro customer service. Keep your purchase receipt as proof of purchase.
Official Nerf Website: www.hasbro.com/nerf

© 2023 Nerf. All rights reserved. Nerf and all related properties are trademarks of Hasbro.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question