Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZAVOR ZSELE02

Zavor LUX Edge 6 Quart Programmable Electric Multi-Cooker User Manual

Model: ZSELE02

Introduction

This manual provides essential instructions for the safe and efficient operation of your Zavor LUX Edge 6 Quart Programmable Electric Multi-Cooker, model ZSELE02. This appliance combines the functions of a pressure cooker, slow cooker, rice cooker, and yogurt maker, offering a versatile cooking experience.
Please read all instructions thoroughly before initial use and retain this manual for future reference.

Important Safety Warnings

- Always ensure the lid is properly locked before operating under pressure. The multi-cooker will not open if it is locked and there is pressure inside.
- Do not overfill the cooking pot. Refer to the maximum fill lines for different food types.
- Exercise caution when releasing pressure, as hot steam will be discharged.
- Keep hands and face clear of the steam release valve during operation.
- Ensure the power cord is securely plugged into the unit and a grounded electrical outlet.
- This appliance is for household use only. Do not use outdoors.
- Always unplug the appliance when not in use and before cleaning.

Product Components

Familiarize yourself with the main parts of your Zavor LUX Edge Multi-Cooker:

- **Main Unit:** Stainless steel exterior with control panel.
- **Lid:** Features an automatic locking mechanism and steam release valve.
- **Removable Stainless Steel Cooking Pot:** PFOA and PTFE free, dishwasher safe.
- **Stainless Steel Cooking Rack:** For steaming and elevating food.
- **Control Panel:** Digital display with backlit icons for various cooking functions.



Image: The Zavor LUX Edge 6 Quart Programmable Electric Multi-Cooker, showing its stainless steel exterior and control panel.



Image: Disassembled Zavor LUX Edge Multi-Cooker, showing the main unit, removable stainless steel cooking pot, and lid.

Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials and inspect the multi-cooker for any damage.
2. **Cleaning:** Before first use, wash the removable stainless steel cooking pot, lid, and cooking rack with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the multi-cooker on a stable, level, heat-resistant surface away from walls and cabinets to allow for proper ventilation.

4. **Power Connection:** Ensure the power cord is firmly inserted into the unit and then into a grounded 110V (AC) electrical outlet.

Operating Instructions

The Zavor LUX Edge offers 16 cooking functions and 4 lit icons for pressure, slow cooking, temperature, and light display. The control panel features backlit icons that indicate the cooking method in use.

General Operation

1. Add ingredients to the stainless steel cooking pot.
2. Place the lid on the unit and rotate it clockwise until it locks into place. Ensure the steam release valve is set correctly for your chosen function (e.g., sealed for pressure cooking).
3. Select the desired cooking function from the control panel.
4. Adjust cooking time and pressure/temperature settings using the '+' and '-' buttons if necessary.
5. Press the 'START/STOP' button to begin cooking.
6. Once cooking is complete, the unit will typically switch to 'Keep Warm' mode.

Specific Functions

- **Pressure Cook (High and Low):** Cooks food up to 70% faster. Ensure the lid is sealed. The display icons will show 'P' for Pressure Cook.
- **Slow Cook (High and Low):** Ideal for tenderizing meats and infusing flavors over longer periods. The display icons will show 'S' for Slow Cook.
- **Rice (White Rice, Brown Rice, Risotto, Steamed Rice):** Equipped with 4 settings for various rice types. The 'Steamed Rice' function cooks rice using steam, similar to a traditional rice cooker.
- **Yogurt:** Prepare homemade yogurt with an easy two-step process.
- **Manual:** Allows use as a pressure cooker, slow cooker, or traditional stockpot. You select the temperature and time.
- **Brown and Sauté:** Use these functions to brown and sauté ingredients directly in the pot before cooking, enhancing flavor.
- **Steam:** Cook vegetables and fish with steam to preserve nutrients. Use the included stainless steel cooking rack.
- **Keep Warm:** Automatically activates at the end of most cooking cycles to maintain food temperature.
- **Time Delay:** Program cooking to start at a later time, up to 6 hours.
- **Mute Feature:** Disables all unit sounds for quiet programming and transitions.

Your browser does not support the video tag.

Video: An introductory video showcasing the Zavor LUX Edge Multi-Cooker and its various functions, including pressure cooking, slow cooking, and yogurt making. It demonstrates the ease of use and the types of meals that can be prepared.

PRESSURE & SLOW COOK

HIGH and LOW presets for faster food or slow flavor infusion.

RICE FUNCTION

Equipped with 4 settings for White Rice, Brown Rice, Risotto, and Steamed Rice which cooks rice as a traditional rice cooker would.

YOGURT

2-step incubation program with on-screen prompts.

MANUAL FUNCTION

Fully programmable, this function lets you use the unit as a pressure cooker, slow cooker, or a traditional stockpot.

DISPLAY ICONS

Backlit icons show which cooking method is being used and when the time delay has been programmed.



Image: Close-up of the Zavor LUX Edge Multi-Cooker's control panel, highlighting the Pressure & Slow Cook, Rice, Yogurt, Manual functions, and display icons.



Image: The Zavor LUX Edge Multi-Cooker with its lid open, showing cooked pasta inside, illustrating its ease of use and cleaning.

Care and Maintenance

- **Cleaning the Pot and Rack:** The stainless steel removable cooking pot and cooking rack are dishwasher safe. For best results, wash immediately after use.
- **Cleaning the Lid:** Hand wash the lid with warm, soapy water. Ensure all components, especially the sealing ring and steam release valve, are clean and free of food debris.
- **Cleaning the Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
- **Storage:** Store the multi-cooker in a dry place. Ensure all parts are clean and dry before storage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Unit does not power on.	Power cord not properly connected; no power from outlet.	Ensure the power cord is fully inserted into the unit and the wall outlet. Test the outlet with another appliance.
Lid will not close or lock.	Sealing ring improperly installed; food debris obstructing lid.	Check that the sealing ring is correctly seated. Clean any food particles from the lid and rim of the pot.
Steam leaking from lid during pressure cooking.	Sealing ring not properly installed or damaged; steam release valve not sealed.	Ensure the sealing ring is correctly in place and not damaged. Verify the steam release valve is in the 'Sealing' position.
Food is undercooked or overcooked.	Incorrect cooking time or temperature/pressure setting.	Adjust cooking time and settings according to recipe or desired results. Ensure sufficient liquid for pressure cooking.

For further assistance, please contact Zavor customer support.

Specifications

- **Brand:** ZAVOR
- **Model:** ZSELE02
- **Capacity:** 6 Quarts
- **Material:** Stainless steel (pot and exterior)
- **Color:** Stainless Steel
- **Wattage:** 1000 Watts
- **Voltage:** 110 Volts (AC)
- **Item Weight:** 14 Pounds
- **Product Dimensions:** 12.2 x 11.4 x 13.8 inches
- **Control Method:** Touch
- **Operation Mode:** Manual, Automatic
- **Dishwasher Safe Parts:** Removable stainless steel cooking pot, stainless steel cooking rack
- **Special Features:** 16 cooking functions, backlit icons, automatic locking lid, PFOA/PTFE free cooking pot.
- **UPC:** 850834008297

Warranty Information

The Zavor LUX Edge Multi-Cooker comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal household use.
The warranty does not cover damage resulting from misuse, abuse, accident, alteration, or commercial use. Please retain your proof of purchase for warranty claims.
For detailed warranty terms and conditions, refer to the official Zavor website or contact customer support.

Customer Support

If you have any questions, require technical assistance, or need to make a warranty claim, please contact Zavor customer support:

- **Website:** Visit the official Zavor website for FAQs, product registration, and support resources.Zavor Store
- **Contact Information:** Refer to the contact section on the Zavor website for phone numbers or email support.

A digital recipe book with over 120 recipes is available for download to help you get started with your multi-cooker.

© 2023 ZAVOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07HJ94R7Y

More documents and user manuals: **https://manuals.plus/**