Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geakv B07HLW1JLG

AIR King Horizontal, Vertical 3 Speed Portable Blower/Dryer User Manual

Model: B07HLW1JLG | Brand: Geakv

1. Introduction

Thank you for choosing the AIR King Portable Blower/Dryer. This powerful and versatile unit is designed to deliver high-velocity, focused airflow for various applications, including drying carpets and floors, or ventilating work areas. Its pivoting fan head and integrated power outlets enhance its utility in professional and home environments.

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new blower/dryer. Please read it thoroughly before use and retain it for future reference.



An image showing the AIR King portable blower/dryer from a front-side angle, highlighting its power dial, speed settings (0, 1, 2, 3), and two integrated 10 Amp Max electrical outlets.

2. Important Safety Instructions

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this blower/dryer.
- This appliance has a GFCI plug. Do not bypass or disable this safety feature.
- Always unplug the unit from the power outlet before cleaning, servicing, or moving.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the blower/dryer.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This blower/dryer is intended for use in dry environments. Do not use outdoors or in wet locations.
- Do not use this blower/dryer near water, such as a bathtub, washbowl, swimming pool, or in a wet basement.
- Use this blower/dryer only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always ensure the unit is placed on a stable, level surface during operation.

3. Setup

1. **Unpacking:** Carefully remove the blower/dryer from its packaging. Inspect the unit for any signs of damage during transit. If damage is found, do not operate the unit and contact customer support.
2. **Placement:** Place the blower/dryer on a firm, level surface. Ensure there is adequate clearance around the air intake and exhaust openings for proper airflow.
3. **Power Connection:** Plug the 3-conductor 10-ft. cord with 5-15P GFCI plug into a standard 120V, 60Hz, 1-phase grounded electrical outlet. The GFCI plug provides additional safety protection.

4. Operating Instructions

4.1 Power and Speed Control

The blower/dryer features a side-mounted rotary dial switch for power and speed control.

1. **To Turn On:** Rotate the dial clockwise from the '0' (Off) position to select your desired speed setting.
2. **Speed Settings:**
    - '1' - Low Speed
    - '2' - Medium Speed
    - '3' - High Speed (350 CFM)
3. **To Turn Off:** Rotate the dial counter-clockwise back to the '0' position.

4.2 Pivoting Fan Head

The unit features a pivoting fan head that allows you to direct airflow horizontally or vertically, or at various angles in between. This flexibility is ideal for drying floors, walls, or circulating air in specific directions.

- Gently adjust the fan head to the desired angle. The head can pivot up to 225° or 270° depending on the specific model variant.
- Ensure the fan head is securely positioned before operating the unit at the new angle.

4.3 Courtesy Outlets

The blower/dryer is equipped with two grounded 120 Volt 10 Amp courtesy outlets. These outlets can be used to power other tools or devices, making the unit a convenient power hub in your work area.

- The total current draw for all devices plugged into these outlets should not exceed 10 Amps.
- Always ensure that the total load does not exceed the rated capacity to prevent circuit overload.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your blower/dryer.

- **Cleaning:** Always unplug the unit before cleaning. Use a soft, damp cloth to wipe down the exterior housing. Do not use harsh chemicals or abrasive cleaners.
- **Air Intakes/Exhaust:** Periodically check the air intake and exhaust openings for dust, lint, or debris buildup. Use a vacuum cleaner or compressed air to clear any obstructions. Ensure the unit is completely dry before plugging it back in.
- **Motor:** The motor is permanently lubricated and requires no additional lubrication.
- **Storage:** When not in use, store the blower/dryer in a cool, dry place, away from direct sunlight and moisture. Coil the power cord neatly to prevent damage.

6. Troubleshooting

If you experience issues with your blower/dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	No power to the outlet; GFCI tripped; Power switch in 'Off' position; Damaged cord/plug.	Check power outlet with another device; Reset GFCI plug; Turn rotary dial to a speed setting (1, 2, or 3); Inspect cord/plug for damage (do not use if damaged).
Reduced airflow.	Air intake/exhaust blocked; Fan blades dirty.	Unplug unit and clear any obstructions from intake/exhaust; Clean fan blades and housing.
Unusual noise during operation.	Foreign object in fan; Unit not on a stable surface.	Unplug unit and check for foreign objects inside; Ensure unit is on a flat, stable surface.

If the problem persists after attempting these solutions, please contact customer support.

7. Specifications

Feature	Detail
Item	Portable Blower/Dryer
Pivoting	Yes
Number of Speeds	3
Blower Wheel Dia.	7"
CFM High	350
Voltage	120V
Hz	60
Phase	1
Amps	0.95/0.80/0.70
Motor HP	1/13
Overall Height	14-1/2"
Overall Width	11"
Overall Length	13"
Housing Height	14-1/2"
Housing Width	11"
Housing Length	13"
Outlet Height	4"
Outlet Width	8"
Housing Color	Gray
Housing Material	ABS Plastic
Number of Blades	56
Propeller Material	ABS

Feature	Detail
Power Cord Length	7 ft.
Number of Conductors	3
Conductor Size (AWG)	14 AWG
NEMA Plug Configuration	5-15P GFCI Plug
Standards	ETL/OSHA
Includes	Permanently Lubricated Ball Bearings and Two Grounded Courtesy 120 Volt 10 Amp Outlets, SO type Black Power Cord, 7" x 7" Blade, Side mounted rotary dial switch
Blower Application	Carpet,Floor
Airflow Direction	Horizontal,Vertical
Number of Power Outlets	2

8. Warranty and Support

For information regarding warranty coverage, technical support, or replacement parts, please refer to the warranty card included with your product or contact the manufacturer directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: CAI - AIR KING

© 2024 Geakv. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07HLW1JLG

More documents and user manuals: **https://manuals.plus/**