YOOHOO B07HP42DT6

YOOHOO 17.9-inch Portable DVD/CD Player User Manual

Model: B07HP42DT6

Brand: YOOHOO

Introduction

This manual provides detailed instructions for the operation and maintenance of your YOOHOO 17.9-inch Portable DVD/CD Player. Designed for portability and versatility, this device features a 15.6-inch high-definition LCD screen with 270-degree swivel capability, a rechargeable battery, and support for various media formats including CD, DVD, SD cards, and USB drives.

Please read this manual thoroughly before using the product to ensure proper function and longevity.

Package Contents

Verify that all items listed below are included in your package:

- 1 x YOOHOO Portable DVD Player
- 1 x Power Adapter (AC)
- 1 x AV Cable
- 1 x Remote Controller
- 1 x Car Charger
- 1 x User Manual (this document)
- 1 x Gamepad (1.5M cable)



Figure 1: Included accessories for the YOOHOO Portable DVD Player.

Product Features

- **Swivel Screen:** 15.6-inch eye-protective LCD screen with 1280x800 resolution. Features 270-degree rotation and 180-degree flip for optimal viewing angles.
- **Extended Battery Life:** Equipped with a 3500 mAh rechargeable lithium battery, providing up to 6 hours of playback. Includes AC power adapter and car charger for versatile power options.
- **Resume Play Function:** Automatically resumes playback from where you last stopped, enhancing convenience.
- **Multi-Media Support:** Directly plays CD, DVD, CD-R/RW, DVD-R/+R, DVD+RW/-RW, VCD, SVCD. Supports USB and SD card playback for MP3/WMA/WAV audio, JPEG images, and AVI/TXT files.



Figure 2: The YOOHOO Portable DVD Player showcasing its screen and key features.

Setup

1. **Charging the Battery:** Connect the provided AC power adapter to the DC 12V input port on the player and plug it into a wall outlet. The charging indicator will illuminate. Allow approximately 4-5 hours for a full charge. For in-car use, connect the car charger to the player and your vehicle's cigarette lighter socket.
2. **Powering On/Off:** Slide the POWER switch to the 'ON' position to turn on the player. Slide it to 'OFF' to power down.
3. **Inserting a Disc:** Gently open the disc cover. Place a DVD or CD onto the spindle with the label side facing up. Close the disc cover securely.
4. **Connecting to a TV (Optional):** Use the supplied AV cable to connect the player's AV output to the AV input ports on your television. Match the yellow, white, and red connectors. Select the correct AV input source on your TV.



Figure 3: Power supply options for the portable DVD player.



Figure 4: Side panel connections including USB, SD card, and AV ports.

Operating Instructions

1. **Disc Playback:** After inserting a disc and powering on, the player will automatically detect and begin playback. Use the remote control or front panel buttons for Play/Pause, Stop, Fast Forward/Rewind, and Chapter Skip.
2. **USB/SD Card Playback:** Insert a USB flash drive into the USB port or an SD card into the SD card slot. Use the 'Source' button on the remote or player to select 'USB' or 'SD'. Navigate through your files using the arrow keys and 'OK' button.
3. **Screen Adjustment:** The screen can swivel up to 270 degrees and flip 180 degrees. Adjust the screen to your preferred viewing angle.
4. **Volume Control:** Adjust the volume using the 'VOL+' and 'VOL-' buttons on the player or remote control.
5. **Gamepad Usage:** Connect the provided gamepad to the designated 'Game' port. Note that the gamepad supports single-player use only. Game discs are not included and must be purchased separately.



Figure 5: Screen rotation and flip functionality.



Figure 6: Supported media and file formats.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the player's exterior. For the screen, use a specialized screen cleaning solution and a microfiber cloth. Do not use abrasive cleaners or solvents.
- **Disc Care:** Handle discs by their edges. Keep them clean and free of scratches. Store discs in their cases when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. If storing the player for an extended period, charge the battery to about 50% and recharge every few months.
- **Storage:** Store the player in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Player does not power on.	Battery is depleted or power adapter is not connected properly.	Connect the AC adapter or car charger and allow the battery to charge. Ensure the power switch is in the 'ON' position.
Disc does not play or skips.	Disc is dirty, scratched, or inserted incorrectly. Disc format is not supported.	Clean the disc with a soft cloth. Ensure the disc is inserted correctly. Verify the disc format is supported (CD, DVD, VCD, SVCD).
No picture when connected to TV.	Incorrect AV cable connection or TV input selection.	Ensure AV cables are securely connected to the correct ports (yellow to yellow, white to white, red to red). Select the appropriate AV input on your TV.
USB/SD card not recognized.	Incorrect file format or card/drive not properly inserted.	Ensure files are in supported formats (MP3, WMA, WAV, JPEG, AVI, TXT). Reinsert the USB drive or SD card. Try a different USB drive or SD card.
Screen is frozen or unresponsive.	Temporary software glitch.	Power off the device, wait a few seconds, then power it back on. If the issue persists, contact customer support.

Specifications

- **Brand:** YOOHOO
- **Model Number:** B07HP42DT6
- **Screen Size:** 15.6 inches (17.9 inches diagonal)
- **Screen Resolution:** 1280x800 (as per feature bullets, product specifications state 1366x768)
- **Screen Rotation:** 270 degrees swivel, 180 degrees flip
- **Battery Capacity:** 3500 mAh
- **Battery Life:** Up to 6 hours
- **Supported Disc Formats:** CD, DVD, DVD+R(-R), DVD+RW(-RW), VCD, SVCD-R(RW), CD-R(RW)
- **Supported Video File Formats:** VOB, AVI, XVID
- **Supported Audio File Formats:** MP3, WMA, WAV
- **Supported Image File Formats:** JPEG
- **Connectivity:** USB port, SD card reader, AV output, Game port
- **Product Dimensions:** 15.6"L x 15.6"W x 15.6"H
- **Item Weight:** 2.44 Kilograms
- **Color:** Black

Warranty and Support

YOOHOO provides a one-year warranty for this product, covering manufacturing defects. For technical support or warranty claims, please refer to the contact information provided with your purchase documentation or visit the official YOOHOO website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question