Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy Future Sport

iJoy Future Sport Bluetooth Waterproof Over Ear Earbud User Manual

Model: Future Sport

1. Introduction

Thank you for choosing the iJoy Future Sport Bluetooth Waterproof Over Ear Earbuds. These earbuds are designed for active lifestyles, offering a secure fit, high-quality audio, and robust waterproofing. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure a seamless and enjoyable experience.



Figure 1.1: iJoy Future Sport Earbuds (Green/Black)
This image displays the iJoy Future Sport earbuds in green and black, highlighting their ergonomic over-ear hook design and the connecting cable between the two earpieces.

2. Package Contents

Please verify that all items listed below are included in your package:

- iJoy Future Sport Earbuds
- Micro USB Charging Cable

- Replacement Ear Buds (2 sizes)
- Small Cable Holder
- Small Carrying Case
- User Instructions (this manual)



Figure 2.1: Package Contents

This image shows the complete contents of the iJoy Future Sport Earbuds package, neatly laid out. It includes the earbuds, a Micro USB charging cable, various sizes of ear tips, a small cable holder, a carrying case, and the user manual.

3. Features

- **Bluetooth 4.1 Connectivity:** Ensures a stable and uninterrupted wireless connection up to 10 meters (33 feet).
- **IPX7 Waterproof Rating:** Designed to withstand submersion in up to 1 meter of water for 30 minutes, making them sweatproof and suitable for various water activities.
- **CVC 6.0 Noise Cancellation:** Provides clear HD stereo sound by reducing ambient noise.
- **Long Battery Life:** Up to 8 hours of continuous music playback and 240 hours of standby time.
- **Comfortable & Secure Fit:** Made of form-fitting silicone with an over-ear design to stay in place during intense workouts.
- **Integrated Controls:** Small buttons on the right earbud allow for volume adjustment, track navigation, and call management.
- **iOS Battery Display:** Monitor earbud battery level directly on your iOS device.



Figure 3.1: Waterproof Design

This image showcases the iJoy Future Sport earbuds with visible water droplets, illustrating their IPX7 waterproof and sweatproof capabilities, ideal for sports and outdoor activities.

4. Setup

4.1 Charging the Earbuds

1. Locate the Micro USB charging port on the right earbud.
2. Connect the provided Micro USB cable to the earbud's charging port.
3. Connect the other end of the USB cable to a USB power source (e.g., computer USB port, wall adapter).
4. The LED indicator on the earbud will illuminate to show charging status. It typically takes about 1.5 hours for a full charge.
5. Once fully charged, the LED indicator will change color or turn off, depending on the model. Disconnect the charging cable.

4.2 Bluetooth Pairing

1. **Power On:** Press and hold the Multi-Function Button (MFB) on the right earbud until you hear a voice prompt indicating "Power On" and the LED indicator starts flashing blue and red, signifying pairing mode.
2. **Activate Bluetooth:** On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings and ensure Bluetooth is turned on.
3. **Search for Devices:** Your device will automatically search for available Bluetooth devices.
4. **Select "Future Sport":** From the list of found devices, select "Future Sport".
5. **Confirm Connection:** Once successfully paired, you will hear a voice prompt "Connected" and the LED indicator will flash blue periodically.
6. If prompted for a password, enter "0000".

The earbuds will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.

5. Operating Instructions

5.1 Basic Functions

- **Power On:** Press and hold the MFB until the LED flashes blue and you hear "Power On".
- **Power Off:** Press and hold the MFB until the LED flashes red and you hear "Power Off".
- **Play/Pause:** Short press the MFB.
- **Volume Up:** Short press the "+" button.
- **Volume Down:** Short press the "-" button.
- **Next Track:** Long press the "+" button.
- **Previous Track:** Long press the "-" button.

5.2 Call Management

- **Answer Call:** Short press the MFB when an incoming call rings.
- **End Call:** Short press the MFB during a call.
- **Reject Call:** Long press the MFB when an incoming call rings.
- **Redial Last Number:** Double-press the MFB.



Figure 5.1: Earbud Controls

This diagram illustrates the location and function of the control buttons on the iJoy Future Sport earbuds. It clearly labels the Multi-Function Button (MFB Key), the volume up/next song button, the volume down/previous song button, and the speaker.

6. Maintenance

To ensure the longevity and optimal performance of your iJoy Future Sport Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the earbuds with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** While IPX7 rated, avoid prolonged submersion beyond specified limits (1 meter for 30 minutes). Ensure the charging port cover is securely closed before exposure to water. Dry the earbuds completely before charging.
- **Storage:** Store the earbuds in their provided carrying case when not in use to protect them from dust, dirt, and physical damage.
- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold) as this can affect battery life and internal components.
- **Charging:** Use only the provided charging cable or a certified Micro USB cable. Do not overcharge the battery.

7. Troubleshooting

If you encounter issues with your earbuds, refer to the following common solutions:

Problem	Possible Cause	Solution
Earbuds won't power on	Low battery	Charge the earbuds fully (approx. 1.5 hours).
Cannot pair with device	Earbuds not in pairing mode / Bluetooth off on device / Device too far	Ensure earbuds are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Keep devices within 1 meter during pairing. Forget previous pairings on your device and try again.
No sound / Low volume	Volume too low on earbuds or device / Not connected / Wrong audio output selected	Increase volume on both earbuds and your device. Ensure earbuds are connected. Check your device's audio output settings.
Intermittent connection	Interference / Out of range / Low battery	Move closer to your device (within 10m). Avoid obstacles. Charge earbuds. Avoid strong Wi-Fi signals or other Bluetooth devices.

8. Specifications

Specification	Detail
Brand	iJoy
Model	Future Sport
Connectivity Technology	Bluetooth 4.1
Wireless Communication Technology	Bluetooth
Ear Placement	Over Ear

Specification	Detail
Form Factor	Over Ear
Water Resistance Level	Water Resistant (IPX7)
Control Type	Media Control
Control Method	Touch (Buttons)
Material	Silicone
Noise Cancellation	CVC 6.0
Battery Life (Music)	Up to 8 hours
Standby Time	240 hours
Charging Time	Approx. 1.5 hours
Charging Port	Micro USB
Operating Distance	10 meters (33 feet)



Figure 8.1: Features and Specifications Overview
This image provides a visual summary of the iJoy Future Sport earbuds' key features and technical specifications, including details on connectivity, battery life, and noise cancellation technology.

9. Official Product Videos

There are no official product videos available from the seller for this product at this time.

10. Warranty and Support

iJoy products are manufactured with quality and performance in mind. For specific warranty information, please refer to

the warranty card included with your product or visit the official iJoy website. If you require technical support or have questions not covered in this manual, please contact iJoy customer service through their official channels.
Contact Information: Please refer to the packaging or the official iJoy website for the most up-to-date customer support contact details.

© 2024 iJoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07HP8NDZS

More documents and user manuals: **https://manuals.plus/**