Passion-Electro LC40R

Passion-Electro Replacement Remote Control for GRANDIN LC40R TV - User Manual

Model: LC40R

Introduction

This manual provides instructions for the Passion-Electro replacement remote control designed for the GRANDIN LC40R TV. This remote control is a specialized replacement, not a generic universal remote, and is engineered to provide access to all functions of your original GRANDIN LC40R TV remote. No programming is required for its use.



Figure 1: Front-angled view of the Passion-Electro replacement remote control, showing the brand logo and main button layout.

Setup

1. Battery Installation

The remote control requires two (2) AAA 1.5V batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 2: Bottom view of the remote control, clearly showing the battery compartment cover for installation.

2. Initial Use

Once batteries are correctly installed, the remote control is ready for immediate use. No additional programming or setup is required. Point the remote control towards your GRANDIN LC40R TV and press the desired function button.

Operating Instructions

This replacement remote control functions identically to your original GRANDIN LC40R TV remote. The button layout is designed to be intuitive and familiar.



Figure 3: Side profile of the remote control, highlighting the arrangement of function buttons including numerical keys, navigation, and special function buttons.

Basic Functions:

- **Power Button:** Press to turn the TV on or off.
- **Number Buttons (0-9):** Use to directly select channels.
- **Channel Up/Down:** Navigate through channels sequentially.
- **Volume Up/Down:** Adjust the sound level.
- **Mute Button:** Temporarily silence the TV audio.
- **Navigation Pad (Up/Down/Left/Right/OK):** Used for menu navigation and selection.
- **Menu Button:** Access the TV's main menu.
- **Source/Input Button:** Select different input sources (HDMI, AV, etc.).

An LED indicator on the remote will illuminate with each button press, confirming signal transmission.

MAINTENANCE

Battery Replacement:

Replace batteries when the remote's response becomes sluggish or the LED indicator fails to light up consistently. Always replace both batteries at the same time with new AAA 1.5V batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning:

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote's surface or internal components.

Storage:

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage and potential damage.

TROUBLESHOOTING

- **Remote Control Not Responding:**
  - Ensure the batteries are correctly installed with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Make sure there are no obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective operating range (up to 10 meters) and pointing the remote directly at the TV.
- **Specific Buttons Not Working:**
  - Check if the button is physically stuck.
  - If multiple buttons are affected, try replacing the batteries.
- **LED Indicator Not Lighting Up:**
  - This usually indicates dead or incorrectly installed batteries. Replace them.

If problems persist after following these steps, please refer to the support section.

Product Specifications

Brand	Passion-Electro
Model Compatibility	GRANDIN LC40R TV
Color	Black
Batteries Required	2 x AAA 1.5V (not included)
Maximum Operating Range	10 Meters
Programming Required	No
Country of Origin	China
ASIN	B07HV22VDD

Warranty Information

This product is covered by a standard return policy. For specific details regarding warranty coverage and return procedures, please refer to the retailer's purchase terms or contact the manufacturer directly.

Customer Support

For further assistance, technical support, or inquiries regarding your Passion-Electro replacement remote control, please contact the manufacturer or your point of purchase. Please have your product model (LC40R) and ASIN (B07HV22VDD) available when contacting support.