Tefal FV9845

Tefal Ultimate Pure Steam Iron

Model FV9845 User Manual

1. Important Safety Instructions

Please read all instructions carefully before using your Tefal Ultimate Pure Steam Iron. Keep this manual for future reference.

- Always plug the iron into a grounded outlet.
- Do not leave the iron unattended while it is connected to the mains or while it is still hot.
- Keep the iron and its cord out of reach of children.
- Never immerse the iron, cord, or plug in water or any other liquid.
- Unplug the iron before filling with water, cleaning, or after each use.
- Use the iron only for its intended purpose, which is ironing clothes.
- Do not operate the iron if it has been dropped, if there are visible signs of damage, or if it is leaking.
- Ensure the voltage indicated on the iron matches your local mains voltage.

2. Product Overview

The Tefal Ultimate Pure Steam Iron FV9845 is designed for powerful and efficient ironing, featuring a unique Micro-Calc Filter system to prevent limescale stains.



Image 2.1: Front view of the Tefal Ultimate Pure Steam Iron FV9845, showcasing its sleek design and water tank.

Key components include the water tank, steam trigger, temperature control dial, and the innovative Durilium AirGlide Autoclean soleplate.



Image 2.2: Underside view of the iron, highlighting the Durilium AirGlide Autoclean soleplate for smooth gliding and even steam distribution.

3. Setup and First Use

3.1 Unpacking

Carefully remove the iron from its packaging. Remove any protective films or stickers from the soleplate and body of the iron.

3.2 Filling the Water Tank

1. Ensure the iron is unplugged from the power outlet.
2. Open the water tank filler cap.
3. Fill the water tank with clean tap water up to the 'MAX' level indicator. Do not overfill.
4. Close the filler cap securely.



Image 3.1: The iron resting on its heel, showing the water tank and the Micro-Calc Filter housing at the rear.

3.3 First Use

For the first use, or if the iron has not been used for a long time, iron an old piece of fabric to remove any manufacturing residues or impurities from the steam vents. This may involve some steam or water discharge initially.

4. Operating Instructions

4.1 Setting the Temperature

1. Plug the iron into a suitable power outlet.
2. Turn the temperature control dial to the desired setting based on the fabric type. Refer to the garment's care label.
3. Wait for the indicator light to turn off, indicating the iron has reached the set temperature.

4.2 Steam Ironing

- Ensure the water tank is filled.
- Set the temperature to a steam-compatible setting (usually indicated on the dial).
- Press the steam trigger for continuous steam output (up to 60 g/min).
- For stubborn creases, use the powerful 260 g/min steam boost by pressing the steam boost button.



Image 4.1: A user demonstrating the iron in use, showing steam being emitted during the ironing process.

4.3 Dry Ironing

For dry ironing, ensure the steam setting is off and the water tank is empty or the steam function is not activated. Set the temperature according to the fabric type.

5. Maintenance and Cleaning

5.1 Cleaning the Soleplate

Allow the iron to cool completely. Wipe the soleplate with a damp cloth. Do not use abrasive cleaners or metallic scouring pads.

5.2 Micro-Calc Filter Cleaning

The Micro-Calc Filter system is designed to capture limescale. Regular cleaning of this filter is essential for optimal performance and to prevent calc stains.

1. Ensure the iron is unplugged and completely cool.
2. Locate the Micro-Calc Filter at the rear of the iron.
3. Unlock and remove the filter cartridge.
4. Rinse the filter under running water to remove any accumulated limescale.
5. Reinsert the clean filter cartridge and lock it into place.



Image 5.1: The Micro-Calc Filter being removed from the iron, showing captured limescale particles.



Image 5.2: A detailed view of the Micro-Calc Filter cartridge, highlighting its design for capturing limescale.

5.3 Storage

After use, unplug the iron and allow it to cool completely. Empty any remaining water from the tank. Store the iron upright in a safe, dry place.

6. Troubleshooting

If you encounter issues with your iron, please consult the table below before contacting customer support.

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet fault; iron not switched on.	Check plug connection; test outlet with another appliance; ensure temperature dial is set.
No steam or insufficient steam.	Water tank empty; temperature too low; steam vents blocked.	Fill water tank; set higher temperature; clean soleplate vents.
Water leaking from soleplate.	Temperature too low for steam; overfilled water tank; calc build-up.	Increase temperature; do not overfill; clean Micro-Calc Filter.
White flakes or stains on clothes.	Limescale build-up.	Clean the Micro-Calc Filter thoroughly.

7. Specifications

Brand: Tefal

Model Name: FV9845

Item Model Number: 3121040069271

Power: 3200W (as per feature bullets)

Continuous Steam Output: Up to 60 g/min

Steam Boost: Up to 260 g/min

Soleplate Technology: Durilium AirGlide Autoclean

Special Feature: Micro-Calc Filter System

Color: Pink/Black

Product Dimensions: 1.1 x 9.7 x 6.5 inches

Item Weight: 4.65 pounds

Voltage: 230 Volts (approx.)

Frequency: 50 Hz

8. Warranty and Support

Your Tefal Ultimate Pure Steam Iron is covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Tefal website.

For technical support, spare parts, or service inquiries, please contact Tefal customer service in your region. Contact details can typically be found on the official Tefal website or on your product packaging.

You can visit the official T-Fal Store for more information:T-Fal Store on Amazon

© 2023 Tefal. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What is the difference between the Tefal FV9845 and the Tefal FV9845E0?

The Tefal FV9845 and FV9845E0 are essentially the same product. In Tefal's model numbering system, the "E0" suffix typically refers to the specific regional market code (often indicating the European market) and the type...

Read full answer