KitchenAid 5KFP0719BBM

KitchenAid 7-Cup (1.7L) Food Processor User Manual

Model: 5KFP0719BBM

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the food processor.
- Do not immerse the motor base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts. Blades are sharp. Handle with care.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter.
- Do not use attachments not recommended or sold by KitchenAid.
- Ensure the lid is securely locked before operating the appliance.

2. Product Overview and Components

The KitchenAid 7-Cup Food Processor is designed for efficient food preparation. Familiarize yourself with its main components:

- **Motor Base:** The main unit containing the motor and controls.
- **1.7L Work Bowl:** The transparent bowl where food is processed.
- **Hinged Lid with Small Feed Tube:** Covers the work bowl and allows for adding ingredients during operation.

- **2-Piece Food Pusher:** Used to guide food through the feed tube.
- **Multi-Purpose Blade (Stainless Steel):** For chopping, mincing, and pureeing.
- **Dough Blade:** Specifically designed for mixing and kneading dough.
- **4mm Medium Slice Disc (Reversible):** For medium slicing.
- **6mm Thick Slice Disc:** For thicker slicing.



Figure 2.1: Front view of the KitchenAid 7-Cup Food Processor in Matte Black, showing the motor base, work bowl, lid, and controls.



Figure 2.2: Close-up view of the food processor's hinged lid and feed tube, illustrating how ingredients are added.



Figure 2.3: The multi-purpose blade, dough blade, and slicing discs included with the food processor.

3. Assembly and Setup

Before first use, wash all parts except the motor base in warm, soapy water. Rinse and dry thoroughly. The work bowl, lid, and blades are top-rack dishwasher safe.

1. **Place the Motor Base:** Position the motor base on a clean, dry, flat surface.
2. **Attach the Work Bowl:** Place the 1.7L work bowl onto the motor base. Rotate it clockwise until it locks securely into place.
3. **Insert the Blade/Disc:**
    - For chopping/pureeing: Carefully place the multi-purpose blade onto the drive adapter in the work bowl.
    - For kneading: Place the dough blade onto the drive adapter.
    - For slicing/shredding: Place the desired slicing disc onto the drive adapter. Ensure the disc is oriented correctly for the desired cut (e.g., 4mm medium slice disc is reversible).
4. **Secure the Lid:** Place the hinged lid onto the work bowl. Rotate it clockwise until it clicks and locks into place. The food processor will not operate unless the lid is properly secured.
5. **Insert Food Pusher:** Place the 2-piece food pusher into the feed tube.



Figure 3.1: Demonstrates the process of carefully placing a slicing disc onto the drive adapter within the work bowl.

4. Operating Instructions

The KitchenAid Food Processor features simple paddle controls for ease of use.

4.1. Controls

- **Speed 1:** Lower speed for softer ingredients or more controlled processing.
- **Speed 2:** Higher speed for harder ingredients or faster processing.
- **O/Pulse:** Press and hold for short bursts of power, ideal for chopping or when precise control is needed. Release to stop.

4.2. Basic Operation

1. Ensure the food processor is correctly assembled and the lid is locked.
2. Plug the appliance into a grounded electrical outlet.

3. Add ingredients to the work bowl. For slicing or shredding, feed ingredients through the feed tube using the food pusher. Do not force ingredients.
4. Select the desired speed (1 or 2) or use the Pulse function.
5. Process until desired consistency is achieved.
6. Once processing is complete, press the 'O' button to turn off the appliance. Unplug from the outlet before removing the lid or work bowl.

4.3. Specific Tasks

- **Chopping & Slicing:** Use the multi-purpose blade for chopping or the slicing discs for uniform slices. The 4mm disc is reversible for medium slices, and the 6mm disc provides thicker slices.
- **Kneading Dough:** Attach the dough blade. Add ingredients according to your recipe. Use the 'Pulse' function or Speed 1 for mixing, then switch to Speed 2 for kneading until the dough forms a ball.
- **Shredding:** Use the appropriate slicing disc for shredding ingredients like cheese or carrots. Feed them through the feed tube.



Figure 4.1: The food processor actively slicing vegetables, demonstrating its capability for precise cuts.



Figure 4.2: The food processor with dough in the work bowl, illustrating its use for kneading.



Figure 4.3: The food processor shredding zucchini, showcasing its efficiency for fine shredding tasks.

5. Care and Maintenance

Proper cleaning and maintenance will ensure the longevity and optimal performance of your food processor.

5.1. Cleaning

- Always unplug the food processor before cleaning.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse it in water.
- **Work Bowl, Lid, Blades, and Discs:** These parts are top-rack dishwasher safe. Alternatively, hand wash them in warm, soapy water. Use caution when handling sharp blades and discs.
- Ensure all parts are thoroughly dry before reassembling or storing.

5.2. Storage

Store the food processor and its accessories in a dry place. The blades and discs can be stored within the work bowl for compact storage.

6. Troubleshooting

If your food processor encounters an issue, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Food processor does not turn on.	Not plugged in; lid or bowl not properly locked; power outage.	Ensure the unit is plugged in. Check that the work bowl and lid are securely locked into place. Verify power supply.
Motor stops during operation.	Overload protection activated; blade jammed.	Unplug the unit. Remove some ingredients if overloaded. Clear any obstructions from the blade. Wait a few minutes for the motor to cool down before restarting.
Ingredients are not processed evenly.	Too many ingredients; ingredients cut too large; incorrect blade/disc.	Process in smaller batches. Cut ingredients into uniform, smaller pieces. Ensure the correct blade or disc is used for the task.

Problem	Possible Cause	Solution
Lid is difficult to lock/unlock.	Food debris or misalignment.	Ensure the rim of the work bowl and lid are clean and free of debris. Align the lid correctly before rotating to lock.

7. Product Specifications

Feature	Detail
Brand	KitchenAid
Model Name	5KFP0719BBM
Capacity	1.7 Liters (7-Cup)
Voltage	240 Volts
Wattage	250 Watts
Material	Stainless Steel (blades), Plastic (bowl, lid)
Color	Matte Black
Item Weight	2.9 Kilograms
Product Dimensions	19.5 x 19.5 x 39 cm
Special Features	Safety Lock
Included Components	1.7L bowl with hinged lid and small feed tube with 2-piece food pusher, Dough blade, Multi-purpose blade (stainless steel), 4mm medium slice disc (reversible), 6mm thick slice disc

8. Warranty and Support

8.1. Manufacturer's Warranty

This KitchenAid Food Processor comes with a**1-Year Manufacturer Warranty**. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal household use.

8.2. Customer Support

For further assistance, troubleshooting not covered in this manual, or warranty service, please contact KitchenAid Customer Service. Refer to the official KitchenAid website or your product packaging for contact details specific to your region.

© 2025 KitchenAid. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question