Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro AIWA JAX-N3

User Manual

Replacement Remote Control for AIWA JAX-N3 HI-FI

1. Introduction

This manual provides essential information for the proper use and maintenance of your new Passion-Electro replacement remote control for AIWA JAX-N3 HI-FI systems. Please read this manual carefully before use to ensure optimal performance and longevity of the product.

2. Product Overview

The Passion-Electro replacement remote control is specifically designed to function with AIWA JAX-N3 HI-FI systems, offering full access to all original remote control functions without the need for any programming. It is a specialized remote, not a generic universal remote.

- **No Programming Required:** Ready to use after battery insertion.
- **Full Functionality:** Accesses all functions of the original AIWA JAX-N3 remote.
- **LED Indicator:** Features an LED indicator for operational feedback.
- **High Quality:** Constructed for superior quality and durability.



Figure 2.1: Front view of the replacement remote control, showing all buttons and the Passion-Electro logo.



Figure 2.2: Angled view of the remote control, highlighting its ergonomic design.

3. Setup

Follow these simple steps to prepare your remote control for use:

1. **Open Battery Compartment:** Locate the battery compartment on the back of the remote control. Slide the cover downwards or press the latch to open it.



Figure 3.1: Back view of the remote control with the battery compartment visible.

2. **Insert Batteries:** Insert two (2) AAA 1.5V batteries (not supplied) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. **Close Battery Compartment:** Slide the battery cover back into place until it clicks securely.
4. **Test:** Point the remote control towards your AIWA JAX-N3 HI-FI system and press any button (e.g., Power) to confirm functionality.

Note: *Always use new batteries of the specified type. Do not mix old and new batteries, or different types of batteries.*

4. Operating Instructions

This remote control is designed to replicate the functions of your original AIWA JAX-N3 HI-FI remote. Simply point the remote control at your HI-FI system and press the desired button.

- **Power Button:** Turns the HI-FI system on or off.
- **Volume Control:** Use the 'VOL+' and 'VOL-' buttons to adjust the volume.
- **Channel/Track Navigation:** Use the arrow keys or dedicated track buttons to navigate through channels, tracks, or menu options.
- **Input Selection:** Use buttons like 'TV', 'SAT', 'DVD', 'AUX' to select different audio/video inputs on your system.
- **Numeric Keypad:** Use the number buttons for direct input or channel selection.
- **Menu/Setup:** Access system menus and settings using the 'MENU' or 'SETUP' buttons.
- **Mute:** Temporarily silences the audio output.

Important: *The exact layout and function of buttons may vary slightly from the image provided, depending on the specific model of the original remote it replaces. Refer to your AIWA JAX-N3 HI-FI system's original manual for detailed function descriptions of each button.*

5. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution, then wipe dry immediately. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always

replace both batteries simultaneously.

- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical shocks and drops, as this can damage internal components.
- **Liquid Exposure:** Keep the remote control away from liquids to prevent damage.

6. Troubleshooting

If you experience issues with your remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
  a. Check if the batteries are inserted correctly with the correct polarity (+/-).
  b. Replace the batteries with new ones.
  c. Ensure there are no obstructions between the remote control and the HI-FI system's infrared receiver.
  d. Make sure you are within the operational range (up to 10 meters) and pointing the remote directly at the HI-FI system.
- **Specific Buttons Not Working:**
  a. Clean the remote control, especially around the non-functioning buttons, to remove any dirt or debris that might be preventing contact.
  b. If only a few buttons are not working after trying new batteries, the remote might be damaged.
- **Interference:**
  Strong light sources (like direct sunlight or certain fluorescent lights) can sometimes interfere with infrared signals. Try operating the remote in a different lighting condition.

If the problem persists after trying these steps, please contact your retailer for further assistance.

7. Specifications

Feature	Detail
Brand	Passion-Electro
Color	Black
Connectivity Technology	Infrared
Special Feature	No programming required
Controller Type	Button Control
Maximum Range	10 Meters
Battery Type	2 x AAA 1.5V (LR03-AAA) batteries (not supplied)
Country of Origin	China

8. Warranty and Support

This product is a new item. While specific warranty details are not provided, standard consumer rights apply. The product is typically dispatched within 48 hours.
For returns, a 30-day return policy is generally available from the date of purchase. Please refer to your purchase

documentation or contact your retailer for specific return procedures and any available support.

© 2025 Passion-Electro. All rights reserved.

Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07HXTCBWC

More documents and user manuals: **https://manuals.plus/**