Passion-Electro AKTV193LED

Passion-Electro Replacement Remote Control for AKAI AKTV193LED TV User Manual

Model: AKTV193LED

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Passion-Electro replacement remote control for the AKAI AKTV193LED television. This remote is designed to function identically to the original remote control for your specific TV model, requiring no programming.



Image: Front view of the Passion-Electro replacement remote control, showing all buttons and the brand logo at the bottom.

Setup

1. Battery Installation

The remote control requires two AAA (LR03) 1.5V batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back view of the remote control, highlighting the battery compartment cover.

Note: This replacement remote control does not require any programming. Once batteries are installed, it is ready for immediate use with your AKAI AKTV193LED TV.

Operating Instructions

This remote control provides full functionality equivalent to your original AKAI AKTV193LED TV remote. Point the remote control directly at your television's infrared receiver.

Key Functions Overview

- **Power Button:** Turns the TV on or off. (Typically red, located at the top left).
- **Mute Button:** Mutes or unmutes the TV sound. (Typically top right).
- **Number Buttons (0-9):** For direct channel selection or inputting numbers.
- **Channel Up/Down (P+/P-):** Changes TV channels sequentially.
- **Volume Up/Down (V+/V-):** Adjusts the TV volume.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used for menu navigation and selection.
- **Menu Button:** Accesses the TV's main menu.
- **Exit Button:** Exits current menu or function.
- **Source/Input Button:** Selects input sources (HDMI, AV, etc.).
- **Smart/Net TV Buttons:** Accesses smart TV features or streaming applications (if supported by your TV model).
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or interactive services.



Image: Angled view of the remote control, providing a clear view of the power button, mute button, number pad, navigation controls, and colored function buttons.

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.
- **Liquid Exposure:** Keep the remote control away from liquids to prevent damage.

Troubleshooting

If you experience issues with your remote control, try the following solutions:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm you are pointing the remote directly at the TV.
- **Intermittent Functionality:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the IR signal.
- **Specific Buttons Not Working:**
  - Check for any debris or stickiness around the button. Gently clean if necessary.
  - If only one or two buttons are affected, it might indicate a fault with the remote.

If these steps do not resolve the issue, please refer to the support information provided by Passion-Electro.

Specifications

Feature	Detail
Brand	Passion-Electro
Compatible Devices	AKAI AKTV193LED Television

Feature	Detail
Battery Type	2 x AAA (LR03) 1.5V batteries
Batteries Included	No
Programming Required	No
Item Weight	Approximately 100 grams
Special Features	Direct replacement, no programming needed

Warranty and Support

For warranty information or technical support regarding your Passion-Electro replacement remote control, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific contact details.
This product is a direct replacement and is expected to function as described without additional programming.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question