ZdalaMit NH500UP

ZdalaMit NH500UP Replacement Remote Control Instruction Manual

For Philips 4K UHD Smart TVs

Introduction

This manual provides instructions for the ZdalaMit NH500UP replacement remote control. This remote is designed to function as a direct replacement for your original Philips 4K UHD Smart TV remote, offering immediate usability without complex setup procedures. It is compatible with a wide range of Philips TV models, ensuring seamless control over your television's functions.
Compatible Philips TV Models include:

- 50PFL5601/F7, 65PFL5602/F7, 55PFL5602/F7, 50PFL5602/F7, 43PFL5602/F7
- 32PFL4902/F7, 40PFL4901/F7, 43PFL4901/F7, 50PFL4901/F7
- 55PFL6902/F7, 43PFL4902/F7, 65PFL6902/F7, 50PFL6902/F7, 50PFL6602/F7, 55PFL6902/F7, 55PFL5402/F7
- 32PFL4902, 40PFL4901, 43PFL4901, 50PFL4901, 43PFL4902
- 50PFL5601, 65PFL5602, 55PFL5602, 50PFL5602, 43PFL5602
- 65PFL6902, 55PFL6902, 50PFL6902, 50PFL6602, 55PFL5402

Setup

1. Battery Installation

The ZdalaMit NH500UP remote control requires two (2) 1.5V AAA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Rear view of the remote control with the battery cover open, illustrating the correct placement for two AAA batteries.

2. Initial Use

No programming or pairing is required for this replacement remote control. Once the batteries are correctly installed, the remote is ready for immediate use with your compatible Philips TV.
If the remote does not function immediately after battery installation, please follow these steps:

1. Unplug the power supply of your Philips TV from the wall outlet.
2. Wait for a few minutes (e.g., 5 minutes).
3. Plug the TV's power supply back into the wall outlet to restart the television.

4. Attempt to use the remote control again.

Operating Instructions

The ZdalaMit NH500UP remote control features a standard layout for easy navigation and control of your Philips Smart TV. Below is a guide to the main buttons and their functions.



Image: Front view of the remote control with detailed labels for each button and its corresponding function.

Remote Control Button Functions

Button	Function
POWER	Turns the TV on from standby or off to standby.
NETFLIX / VUDU / YouTube	Launches the indicated streaming application directly.
Rewind / Play/Pause / Fast Forward	Controls media playback (searches backward/forward, starts/pauses/resumes playback).
Stop	Stops disc playback or media.
NETTV	Accesses Net TV menu directly.
Home (House icon)	Displays the TV's home menu.
FORMAT	Launches the app indicated by the button.
INFO	Displays information about the current program.
Navigation Buttons (Up, Down, Left, Right)	Moves the cursor and selects on-screen menu items.

Button	Function
OK	Press to confirm a selection or command, especially when the Home menu is displayed.
BACK	Returns to the previous menu operation.
OPTIONS	Displays a list of menu items applicable to the highlighted object or screen.
VOL +/-	Adjusts the volume level.
SOURCE	Selects connected input devices (e.g., HDMI 1, HDMI 2).
CH +/-	Selects a television channel.
MUTE (Speaker icon with cross)	Turns the sound on or off.
APP1 / **APP2** / **APP3** / **APP4**	Customizable buttons that work as direct access to user-specified net apps.
Number Buttons (0-9)	Used to enter a channel or program number.
PREV.CH	Returns to the previously viewed channel.
DOT (.)	Used with 0-9 to select digital channels (e.g., to enter 2.1, press "2", then "DOT", then "1").

Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the surface of the remote control. Avoid using liquid cleaners or abrasive materials.
- **Battery Care:**
  - Always use new, high-quality alkaline batteries.
  - Do not mix old and new batteries.
  - Do not mix different types of batteries (e.g., alkaline with rechargeable).
  - Remove batteries if the remote control will not be used for an extended period to prevent leakage.
  - Dispose of used batteries according to local regulations.
- **Storage:** Store the remote control in a dry place, away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the remote control or subjecting it to strong impacts, as this can damage internal components.

Troubleshooting

If you experience issues with your ZdalaMit NH500UP remote control, please refer to the following common solutions:

1. **Remote Not Responding:**
   - Ensure batteries are installed correctly with the correct polarity (+/-).
   - Replace old batteries with new alkaline batteries.
   - Check for any obstructions between the remote control and the TV's infrared sensor.
   - Point the remote directly at the TV's sensor.
2. **TV Not Responding After Battery Change:**
   - Unplug the TV's power cord from the wall outlet.

- Wait for approximately 5 minutes.
- Plug the TV back in and try using the remote again. This can reset the TV's internal systems.

3. **Specific Buttons Not Working:**
   - Ensure the remote is clean and there is no debris lodged under the buttons.
   - If only certain buttons are unresponsive, and other troubleshooting steps fail, the remote may require replacement.

Specifications

Feature	Detail
Model Number	NH500UP
Brand	ZdalaMit
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Product Dimensions	7 x 2 x 0.6 inches (approximately 17.78 x 5.08 x 1.52 cm)
Item Weight	2.2 ounces (approximately 62 grams)
Special Feature	Pre-Programmed (no setup required)
Compatible Devices	Philips 4K UHD Smart Televisions (various models)
Color	Black



Image: Front view of the remote control with its approximate length (7.28 inches) and width (1.77 inches) indicated.

Warranty and Support

This product is designed for reliable performance. Specific warranty details are not provided in the product information. For any queries, technical assistance, or support regarding your ZdalaMit NH500UP replacement remote control, please contact the seller directly through your purchase platform.

Your satisfaction is important. Do not hesitate to reach out if you encounter any issues or have questions about the remote's compatibility or functionality.

© 2026 ZdalaMit. All rights reserved.