Rapoo M100-PINK

RAPOO M100 Wireless Mouse User Manual

Model: M100-PINK

1. INTRODUCTION

Thank you for choosing the RAPOO M100 Wireless Mouse. This mouse offers versatile connectivity options, including 2.4GHz wireless and Bluetooth 3.0/4.0, allowing seamless connection to up to three devices simultaneously. Its quiet click design ensures a silent user experience, ideal for various environments. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting.

Image 1.1: Angled view of the RAPOO M100 Wireless Mouse in pink, showing its ergonomic shape and scroll wheel.

2. KEY FEATURES

- **Multi-mode Wireless Connectivity:** Supports 2.4GHz wireless, Bluetooth 3.0, and Bluetooth 4.0.
- **Connects up to 3 Devices:** Seamlessly switch between three connected devices.
- **Quiet Click Design:** Silent switches reduce click noise for a quiet working environment.
- **High-Precision Tracking:** Equipped with a 1300 DPI tracking engine for smooth and accurate cursor control.
- **Long Battery Life:** Up to 9 months of battery life on a single AA battery.

3. Package Contents

- RAPOO M100 Wireless Mouse
- USB Receiver (typically stored inside the mouse battery compartment)
- 1 AA Alkaline Battery
- Quick Start Guide (this manual)

4. Setup and Connection

4.1. Battery Installation

1. Locate the battery compartment on the bottom of the mouse.
2. Open the battery cover.
3. Insert the included AA battery, ensuring correct polarity (+/-).
4. Close the battery cover securely.

4.2. 2.4GHz Wireless Connection

1. Remove the USB receiver from its storage slot, usually located inside the battery compartment.
2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the mouse using the power switch on the bottom.
4. The mouse should automatically connect to your computer.

4.3. Bluetooth Connection

The M100 mouse supports Bluetooth 3.0 and 4.0. You can connect to two separate Bluetooth devices.

1. Turn on the mouse.
2. Press the device switching button (often on the bottom or top of the mouse) to select a Bluetooth channel (e.g., Bluetooth 1 or Bluetooth 2). The indicator light will blink slowly.
3. Press and hold the device switching button for approximately 3 seconds until the indicator light starts blinking rapidly. This indicates the mouse is in pairing mode.
4. On your computer or device, open Bluetooth settings and search for new devices.
5. Select "RAPOO M100" from the list of found devices and follow the on-screen prompts to complete pairing.

Image 4.1: Top view of the RAPOO M100 Wireless Mouse, showing the left/right click buttons and the scroll wheel. The device switching button is typically located on the bottom or top near the scroll wheel.

4.4. Switching Between Devices

The RAPOO M100 mouse allows you to switch between up to three connected devices (one 2.4GHz and two Bluetooth). Simply press the device switching button (usually located on the top or bottom of the mouse) to cycle through the connected devices. The indicator light will show which channel is active.

5. OPERATING INSTRUCTIONS

5.1. Basic Mouse Functions

- **Left Click:** Primary action, selection.
- **Right Click:** Context menu, secondary actions.

- **Scroll Wheel:** Scroll up/down documents and web pages. Pressing the scroll wheel often acts as a middle click.

5.2. DPI Setting

The RAPOO M100 mouse features a fixed 1300 DPI tracking engine, providing a balanced sensitivity for most daily tasks and office work. No manual DPI adjustment is required or available.

5.3. Quiet Click Feature

The silent switches integrated into the M100 mouse significantly reduce the sound of clicks, making it ideal for quiet environments such as libraries, offices, or late-night use without disturbing others.

6. MAINTENANCE

6.1. Cleaning the Mouse

- Disconnect the mouse from your computer.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the mouse.
- Avoid using harsh chemicals or abrasive materials.
- For the optical sensor, use a dry cotton swab to gently clean any dust or debris.

6.2. Battery Replacement

When the mouse performance degrades or the indicator light suggests low battery, replace the AA battery by following the battery installation steps in Section 4.1.

7. TROUBLESHOOTING

7.1. Mouse Not Responding

- **Check Battery:** Ensure the battery is correctly installed and has sufficient charge. Replace if necessary.
- **Power Switch:** Make sure the mouse is turned on.
- **USB Receiver (2.4GHz):** Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port.
- **Bluetooth Connection:** Verify that Bluetooth is enabled on your device and the mouse is paired. Try re-pairing the mouse (refer to Section 4.3).

7.2. Cursor Movement is Erratic or Lagging

- **Surface:** Use the mouse on a clean, non-reflective, and uniform surface. A mouse pad is recommended.
- **Optical Sensor:** Clean the optical sensor on the bottom of the mouse for any dust or debris.
- **Interference:** Move the mouse closer to the USB receiver or Bluetooth device. Avoid using it near strong electromagnetic interference sources.

7.3. Cannot Switch Between Devices

- Ensure all devices are properly connected (2.4GHz via receiver, Bluetooth devices paired).
- Press the device switching button firmly and briefly to cycle through channels.

8. SPECIFICATIONS

Feature	Detail
Model Number	M100-PINK
Connectivity	2.4GHz Wireless, Bluetooth 3.0, Bluetooth 4.0
DPI	1300 DPI
Number of Buttons	3 (Left, Right, Scroll Wheel/Middle Click)
Battery Type	1 x AA Alkaline Battery
Battery Life	Up to 9 months
Product Dimensions	3.86 x 2.4 x 1.5 inches (9.8 x 6.1 x 3.8 cm)
Item Weight	2.79 ounces (79 grams)
Color	Pink
Manufacturer	RAPOO

9. WARRANTY AND SUPPORT

The RAPOO M100 Wireless Mouse comes with a **2-year replacement warranty**. For warranty claims, technical support, or further assistance, please contact your retailer or the official RAPOO customer service. Please retain your proof of purchase for warranty purposes.

Documents - Rapoo – M100-PINK

Price guide

Product categories

! ADSL / Fibre / LTE	Appliances	Audio / Music / Speakers
Batteries & Chargers	Binoculars, Fieldscopes & Rangefinders	Bluetooth
Cables & connectors	Calculators	CD / DVD / Blu-Ray discs
Cell Phones / Smart Phones	Computer Accessories for branded PCs	Computer Chassis
Computers - barebone / accessories	Computers - built	Digital cameras
Digital notepads	Digital projectors	Displays
Drives	Electronic White Boards	Electronics
Fans / Cooling / Lights / Mods	Gadgets & Toys	Gaming & GAMES
Glasses / eyeware	GPS	Graphics cards
HDMI Switches & Broadcasters	Health and safety [COVID-19 specific]	Home Automation / Smart home
Input devices	KVM switches & cables	Laptops
LED Lights / eco lighting	Media centres / Movie boxes / MP4 DivX	Memory
Modems	Monitors	Motherboards : AMD
Motherboards : Intel	Multi-I/O add-on cards	Network
Notebook accessories	Notebook bags / carry bags	Notebook Spare Parts
Notebooks	Office furniture & supplies	Photo frames
Point of sale	Printers, Copiers & Fax Machines	Processors - AMD
Processors - Intel	Projectors	Refurbished products
Scanners	Screens	Security cameras
Security products	Servers	Software
Solar Power	Tablet PCs & e-book Readers	Telephones
Thunderbolt expansion	Tools - heavy duty & DIY	Tools Kits & tools
TV - LED - LCD - Plasma televisions	UPS / Voltage regulators / Generators	USB
Video / Blu-Ray / DVD standalone	Video Cameras	Warranties & Licenses
Web cams	Wireless hardware	

[ComX-Computers & LaptopDirect Product Price Guide](#)

A comprehensive listing of products, prices, and descriptions from ComX-Computers and LaptopDirect, including various electronics, home appliances, and accessories. Valid as of June 30, 2021.

lang:en score:10 filesize: 4.66 M page_count: 1444 document date: 2021-06-30