Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ECONTROLLY BN59-01259E

ECONTROLLY BN59-01259E Remote Control User Manual

For Samsung TV Models: UN60KU6290F, UN70KU6290F, UN50KU6290, UN55KU6290, UN60KU6290, UN43KU7000D, UN49KU7000, UN70KU6290, UN40KU6290, UN65KU6290, UN40KU6290F, UN55KU6290F

Introduction

This manual provides comprehensive instructions for the ECONTROLLY BN59-01259E remote control. This remote is designed as a replacement for various Samsung TV models, offering direct functionality without the need for complex programming. Please read this manual carefully to ensure proper setup and operation of your new remote control.

Setup

1. Battery Installation

The BN59-01259E remote control requires two (2) AAA alkaline batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Image: Back view of the remote control, illustrating the battery compartment location.

2. Initial Use

This remote control is pre-programmed and does not require any additional setup or programming. Once the batteries are correctly installed, the remote is ready for immediate use with compatible Samsung TV models.

Operating Instructions

The BN59-01259E remote control provides intuitive access to your Samsung TV's functions. Below is a guide to its primary buttons:





Image: Front view of the remote control, highlighting button layout.

- **Power ( )**: Turns the TV on or off.
- **123**: Accesses the virtual number pad for direct channel input or other numerical functions.
- **EXTRA**: Provides access to additional TV functions or information, depending on the TV model.
- **Navigation Pad (Up, Down, Left, Right, Enter)**: Used to navigate menus, select items, and confirm choices.
- **Return (↶)**: Returns to the previous screen or menu.
- **Home (⌂)**: Opens the Smart Hub or main home screen of the TV.
- **Play/Pause/Fast Forward/Rewind ( )**: Controls media playback functions.
- **Volume (VOL)**: Adjusts the TV's volume level. Press the top part to increase, bottom part to decrease. Press the center to mute/unmute.
- **Channel (CH)**: Changes TV channels. Press the top part to go up, bottom part to go down.

Maintenance

Cleaning

To clean your remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you experience issues with your remote control, please refer to the following common problems and solutions:

- **Remote Not Responding**
  - Check if the batteries are installed correctly with the correct polarity (+/-).
  - Replace the batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Confirm the remote is pointed directly at the TV.
- **Buttons Unresponsive or Sticky**
  - Clean the remote control as described in the Maintenance section.
  - If specific buttons are consistently unresponsive, the remote may be damaged and require replacement.
- **Limited Range**
  - Ensure batteries are fresh. Low battery power can reduce the remote's effective range.
  - Remove any objects that might be blocking the signal path between the remote and the TV.
  - The maximum effective range is approximately 33 feet (10 meters). Operating beyond this distance may result in unreliable performance.

If these steps do not resolve the issue, please contact customer support for further assistance.

Specifications

Brand	ECONTROLLY
Model Number	BN59-01259E (RCEC-BN59-01259E)
Connectivity Technology	Infrared (IR)
Compatible Devices	Samsung Televisions (Specific models listed in title)
Power Source	2 x AAA Alkaline Batteries (not included)
Maximum Range	33 Feet (10 meters)
Button Quantity	20
Special Feature	Ergonomic Design
Item Weight	1 Ounce (approximately 28 grams)

Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For any product-related inquiries, technical support, or warranty claims, please refer to the seller or manufacturer's contact information provided at the point of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07J651XD3

More documents and user manuals: **https://manuals.plus/**