Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit NH404UD

ZdalaMit NH404UD Replacement Remote Control for Magnavox TV User Manual

Model: NH404UD

Introduction

This manual provides comprehensive instructions for the ZdalaMit NH404UD Replacement Remote Control. This remote is designed to function as a direct replacement for original Magnavox TV remotes, offering immediate usability without complex setup procedures.

Compatible Magnavox TV Models

The NH404UD remote control is compatible with the following Magnavox TV models:

- 39ME413V/F7, 46ME313V/F7, 46ME313V/F7A, 40ME313V/F7, 39ME313V/F7, 39ME313V/F7A
- 50ME313V/F7, 40ME314V/F7, 40ME324V/F7, 55ME314V/F7, 39ME313/F7A, 55ME345V/F7
- 50ME345V/F7, 43ME345V/F7, 32ME305V/F7, 39MF412B/F7, 50MF412B/F7
- 39ME413V, 46ME313V, 40ME313V, 39ME313V, 50ME313V, 55ME314V, 50ME314V, 40ME314V
- 40ME324V, 55ME345V, 50ME345V, 43ME345V, 32ME305V, 39MF412B, 50MF412B

Package Contents

Your package should contain the following item:

- 1x NH404UD Replacement Remote Control

Note: Batteries and a separate instruction manual are not included in the package.

Setup Instructions

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back view of the remote control with the battery cover open, illustrating the battery insertion area.

2. Initial Use

No programming or pairing is required for this replacement remote. Once batteries are installed, the remote is ready for immediate use with compatible Magnavox TV models.

Operating Instructions

The NH404UD remote control features standard buttons for TV operation. Refer to the image below for button layout and general functions.



Image: Front view of the NH404UD remote control, displaying the power button, number pad, volume, channel, navigation, and menu buttons.

- **Power Button (●)**: Turns the TV on or off.
- **Source Button**: Selects input sources (e.g., HDMI, AV).
- **Number Pad (0-9)**: Direct channel selection.
- **VOL +/-**: Adjusts volume level.
- **CH +/-**: Changes TV channels.
- **Mute Button ( )**: Mutes or unmutes TV audio.
- **Navigation Buttons (Up, Down, Left, Right, OK)**: Navigates through TV menus and confirms selections.

- **Menu Button**: Accesses the TV's main menu.
- **Back Button**: Returns to the previous screen or menu.
- **Picture Size**: Adjusts the aspect ratio of the screen.
- **PIC/SOUND MODE**: Cycles through picture and sound presets.
- **SAP**: Selects Secondary Audio Program.
- **SLEEP**: Sets the sleep timer.
- **Colored Buttons (Red, Green, Yellow, Blue)**: Functionality varies depending on the TV model and current menu.

Maintenance

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new 1.5V AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these may damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the proper polarity.
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and line of sight of the TV.
- **Specific buttons not working:**
  - This remote is a direct replacement and does not require programming. If specific buttons are not functioning, verify compatibility with your exact TV model.
  - Clean the remote's surface, especially around the non-working buttons, to ensure no debris is interfering.

Specifications

Model Number	NH404UD
Brand	ZdalaMit
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Dimensions	7 x 2 x 0.6 inches (approximately)
Item Weight	1.41 ounces (approximately, without batteries)
Color	Black
Compatible Devices	Magnavox Televisions (specific models listed in Compatibility section)

Support

For further assistance or inquiries regarding your ZdalaMit NH404UD Replacement Remote Control, please contact the seller or refer to the product listing where you made your purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JBYCXZP

More documents and user manuals: **https://manuals.plus/**