ZdalaMit 0814frjs-106

Instruction Manual for ZdalaMit AH59-02767A Replacement Remote Control

Model: 0814frjs-106

1. Introduction

This manual provides essential information for the proper use and maintenance of your new ZdalaMit AH59-02767A Replacement Remote Control. This remote is designed to be a direct replacement for original Samsung Soundbar remotes, offering seamless compatibility and functionality without the need for complex programming.
Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. Product Features

- Direct replacement for Samsung Soundbar remote control model AH59-02767A.
- Compatible with Samsung Soundbar models: HW-N650, HW-N550, HW-N450, HW-N450/ZA, HW-N650/ZA, HW-N550/ZA.
- No programming or pairing required; ready for use immediately after battery installation.
- Ergonomic design for comfortable handling.

3. Package Contents

- 1X ZdalaMit AH59-02767A Replacement Remote Control

Note: 2X 1.5V AA Alkaline batteries are required and are not included in the package.

4. Setup

4.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by the arrow to open it.
3. Insert two (2) 1.5V AA Alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Close the battery cover by sliding it back into place until it clicks securely.



Figure 1: Back view of the remote control, illustrating the battery compartment location.

Once batteries are installed, the remote control is ready for immediate use with compatible Samsung Soundbar models. No additional programming or setup is required.

5. Operating Instructions

The ZdalaMit AH59-02767A remote control functions identically to the original Samsung Soundbar remote. Simply point

the remote towards your Samsung Soundbar and press the desired buttons to control its functions.



Figure 2: Front view of the remote control, displaying all functional buttons.

5.1 Key Functions

Button	Function
Power (Red Circle)	Turns the Soundbar On or Off.
Source (Rectangle with Arrow)	Cycles through input sources (e.g., HDMI, Optical, Bluetooth).

Button	Function
Bluetooth Pair (Bluetooth Symbol + PAIR)	Initiates Bluetooth pairing mode.
Volume (VOL +/-)	Adjusts the main volume level.
Woofer (WOOFER +/-)	Adjusts the subwoofer volume level.
Mute (Speaker with Slash)	Mutes or unmutes the sound.
Sound Mode (SOUND MODE)	Cycles through various sound modes (e.g., Standard, Surround, Game).
Settings (Gear Icon)	Accesses Soundbar settings menu.
Navigation Pad (Center Circle)	Used for menu navigation and selection.

6. Maintenance

6.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these may damage the remote's surface or internal components.

6.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries simultaneously with new 1.5V AA Alkaline batteries. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries according to local regulations.

7. Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries.	Ensure batteries are inserted with correct polarity. Replace with new 1.5V AA Alkaline batteries.
Remote range is limited.	Weak batteries; Obstruction between remote and Soundbar.	Replace batteries. Ensure a clear line of sight between the remote and the Soundbar's sensor.
Specific buttons not working.	Dirt or debris under the button; Internal malfunction.	Clean the remote surface. If problem persists, contact customer support.

If you encounter issues not listed here or if the problem persists after attempting the suggested solutions, please refer to the Support section.

8. Specifications

Attribute	Detail
Model Number	0814frjs-106

Attribute	Detail
Compatible Models	Samsung Soundbar HW-N650, HW-N550, HW-N450, HW-N450/ZA, HW-N650/ZA, HW-N550/ZA
Power Supply	2 x 1.5V AA Alkaline Batteries (not included)
Product Dimensions	6 x 1 x 0.5 inches
Item Weight	1.5 ounces
Color	Black
Manufacturer	ZdalaMit Factory
Country of Origin	China

9. Support

For any queries, technical assistance, or issues not covered in this manual, please feel free to contact our customer support. We are committed to providing prompt and helpful assistance.
Please refer to your purchase documentation or the retailer's website for specific contact information.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question