Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj ICX Pearl Theeta

Bajaj Majesty ICX Pearl Theeta Electric Induction Cooktop

USER MANUAL

Product Overview

This manual provides essential instructions for the safe and efficient operation of your Bajaj Majesty ICX Pearl Theeta Electric Induction Cooktop. Please read it thoroughly before first use and retain it for future reference.

1. Setup

1.1 Unpacking

- Carefully remove all packaging materials.
- Inspect the cooktop for any signs of damage. Do not use if damaged.
- Retain packaging for future transport if needed.

1.2 Placement

- Place the induction cooktop on a flat, stable, and heat-resistant surface.
- Ensure adequate ventilation around the unit. Maintain a minimum clearance of 10 cm (4 inches) from walls or other appliances.
- Do not place near water sources or flammable materials.

1.3 Power Connection

- Ensure the power supply matches the voltage specified on the appliance's rating label.
- Plug the power cord into a grounded electrical outlet.



This image displays the front of the Bajaj Majesty ICX Pearl Theeta Electric Induction Cooktop, highlighting its black ceramic glass surface and the white control panel with various function buttons and a digital display.

2. Operating Instructions

2.1 Compatible Cookware

- Use only induction-compatible cookware (made of magnetic materials like cast iron, enameled iron, or stainless steel with a magnetic base).
- Cookware base diameter should be between 12 cm and 26 cm.
- Do not use ceramic, glass, copper, or aluminum cookware unless specifically designed for induction.

2.2 Basic Operation

1. Place induction-compatible cookware centrally on the cooking zone.
2. Plug in the cooktop. The digital display will show "----".
3. Press the **ON/OFF** button to power on the unit. The display will show "0000".

4. Select a cooking function using the pre-set menu buttons (e.g., Curry, Fry, Idly, Dosa/Roti, Milk Tea, Boil, Slow Cook) or use the **Manual** button to adjust power levels.
5. Adjust temperature or power using the **+** and **-** buttons.
6. To stop cooking, press the **ON/OFF** button. The fan may continue to run for a short period to cool the unit.

2.3 Pre-set Menus

The cooktop features several pre-set cooking functions for convenience:

- **Curry:** Optimized for cooking curries.
- **Fry:** Suitable for frying dishes.
- **Idly:** Specific setting for preparing Idly.
- **Dosa/Roti:** Ideal for making Dosa and Roti.
- **Milk Tea:** Designed for boiling milk or making tea.
- **Boil:** For general boiling tasks.
- **Slow Cook:** For dishes requiring longer cooking times at lower heat.

2.4 Timer Function

Press the **Timer** button to set a cooking duration. Use the **+** and **-** buttons to adjust the time. The cooktop will automatically switch off once the set time expires.

2.5 Keep Warm Function

Press the **Keep Warm** button to maintain food at a warm temperature after cooking.



This image provides an angled perspective of the Bajaj Majesty ICX Pearl Theeta Electric Induction Cooktop, detailing the control panel and highlighting features such as wide range voltage, inbuilt sensor, auto wattage regulation, crystal glass, upgraded PCB, anti-insecticide gel, 1900 watts power, 8 pre-set menus, 1-year warranty, and tact switch controls.

3. Maintenance and Care

3.1 Cleaning

- Always unplug the cooktop and allow it to cool completely before cleaning.

- Wipe the ceramic glass surface with a soft, damp cloth and mild detergent.
- For stubborn stains, use a non-abrasive cleaner specifically designed for induction cooktops.
- Do not immerse the unit in water or spray water directly onto it.
- Clean the fan vents regularly to prevent dust accumulation.

3.2 Storage

When not in use, store the cooktop in a dry, cool place, away from direct sunlight and moisture. Ensure it is clean and dry before storage.

4. Troubleshooting

If you encounter any issues, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply; Power cord not plugged in; Fuse blown.	Check power outlet; Ensure cord is securely plugged in; Check household fuse/circuit breaker.
"E" error code displayed.	Incompatible cookware; No cookware on surface; Cookware too small/large.	Use induction-compatible cookware; Place cookware centrally; Ensure cookware size is within recommended range.
Cooking stops unexpectedly.	Overheating protection activated; Timer expired.	Allow unit to cool down; Check if timer was set.
Fan continues to run after turning off.	Normal cooling process.	This is normal. The fan will stop automatically once the unit has cooled.

If the problem persists after attempting these solutions, please contact customer support.

5. Specifications

- **Brand:** Bajaj
- **Model:** ICX Pearl Theeta
- **Type:** Electric Induction Cooktop
- **Heating Elements:** 1
- **Material:** Aluminium (body), Crystal Glass (cooking surface)
- **Color:** White (body), Black (cooking surface)
- **Wattage:** 1900 Watts
- **Controls Type:** Knob and Tact Switch Buttons
- **Power Source:** Corded Electric
- **Special Features:** Electric, Wide Range Voltage, Inbuilt Sensor, Auto Wattage Regulation, Upgraded PCB, Anti-Insecticide Gel, 8 Pre-set Menus
- **Item Weight:** 2 kg 360 g

6. Warranty and Support

This Bajaj Majesty ICX Pearl Theeta Electric Induction Cooktop comes with a**1-year warranty** from the date of purchase. Please retain your purchase receipt as proof of purchase for warranty claims.

For technical support, service, or warranty inquiries, please contact Bajaj customer service. Contact details can typically be found on the product packaging or the official Bajaj website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JGNKBFZ

More documents and user manuals: **https://manuals.plus/**