Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

xDuoo Xduoo 220631 Media Player Xdu-x2

xDuoo X2 Portable HI-FI Music Player User Manual

Model: Xduoo 220631 Media Player Xdu-x2

1. Introduction

The xDuoo X2 is a compact and lightweight portable HI-FI music player designed for audio enthusiasts. It supports various lossless audio formats and offers a high-quality listening experience. This manual provides detailed instructions for the proper use, setup, and maintenance of your X2 player.

2. Safety Information

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble or attempt to repair the device yourself. Refer to qualified service personnel.
- Keep the device away from water and other liquids.
- Use only the specified charging cable and power source.

3. Package Contents

Please check the package for the following items:

- xDuoo X2 Portable HI-FI Music Player
- USB Cable

4. Product Overview

Familiarize yourself with the components and controls of your xDuoo X2 player.



Figure 4.1: Front View

This image displays the front of the xDuoo X2 player, featuring the 0.96-inch OLED screen at the top and the main control buttons below. The buttons include 'MENU', 'VOL+' and 'VOL-' for volume control, and navigation buttons for playback (previous, play/pause, next).



Figure 4.2: Side View

This image shows the left side of the xDuoo X2 player. Visible features include the microSD card slot for expandable storage, a small reset button, and the USB port for charging and data transfer.



Figure 4.3: Back View
This image presents the back of the xDuoo X2 player. It features the product name "X2 HIGH-FIDELITY MUSIC PLAYER" and manufacturing information, including "Designed and Made in China" and the website "www.xduoo.com".

Controls and Ports:

- **Screen:** 0.96-inch OLED display.
- **MENU Button:** Accesses the main menu and confirms selections.
- **VOL+ / VOL- Buttons:** Adjusts volume levels.
- **Navigation Buttons (Previous, Play/Pause, Next):** Controls music playback and navigates menus.
- **MicroSD Card Slot:** For inserting a TF/Micro SD card (up to 32GB).
- **USB Port:** For charging the device and transferring files.
- **Reset Button:** Small pinhole button to reset the device if unresponsive.
- **Headphone Jack:** 3.5mm audio output for headphones.

5. Setup

5.1. Charging the Device

1. Connect the included USB cable to the USB port on the xDuoo X2 player.
2. Connect the other end of the USB cable to a computer's USB port or a compatible USB wall adapter (not included).
3. The screen will indicate charging status. A full charge typically takes a few hours.
4. The device offers approximately 10 hours of continuous playback on a full charge.

5.2. Inserting a MicroSD Card

The xDuoo X2 requires a MicroSD card for music storage (up to 32GB, not included).

1. Locate the MicroSD card slot on the side of the player.
2. Gently insert the MicroSD card into the slot with the gold contacts facing down until it clicks into place.
3. To remove the card, gently push it in again until it springs out.

5.3. Transferring Music Files

1. Ensure a MicroSD card is inserted into the player.
2. Connect the xDuoo X2 to your computer using the USB cable.
3. The player will appear as a removable disk drive on your computer.
4. Drag and drop your music files (MP3, WMA, APE, FLAC, WAV, etc.) into the player's storage.
5. Once files are transferred, safely eject the device from your computer before disconnecting the USB cable.

6. Operating Instructions

6.1. Power On/Off

- **Power On:** Press and hold the Play/Pause button for a few seconds until the screen lights up.
- **Power Off:** Press and hold the Play/Pause button for a few seconds until the screen turns off.

6.2. Basic Navigation

- Use the Previous and Next buttons to navigate through menu options or tracks.
- Press the MENU button to enter a selected option or confirm a choice.
- Press the Play/Pause button to go back to the previous menu or exit a function.

6.3. Playing Music

1. From the main menu, navigate to the "Music" or "Browse" option.
2. Select the desired folder or track using the navigation buttons.
3. Press the Play/Pause button to start playback.
4. During playback, use the Previous and Next buttons to skip tracks.
5. Press the Play/Pause button to pause or resume playback.

6.4. Adjusting Volume

- Use the VOL+ button to increase the volume.
- Use the VOL- button to decrease the volume.

6.5. Menu Options

The main menu typically includes options such as:

- **Music:** Browse and play music files.
- **Settings:** Adjust display brightness, language, equalizer, playback mode (repeat, shuffle), and other system settings.
- **System Info:** View firmware version and storage information.

7. Maintenance

7.1. Cleaning

- Wipe the device with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

7.2. Storage

- Store the device in a cool, dry place when not in use.
- Avoid prolonged exposure to direct sunlight or extreme temperatures.

8. Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Low battery; device frozen.	Charge the device for at least 30 minutes. If still unresponsive, use a pin to press the reset button.
No sound.	Volume too low; headphones not connected properly; corrupted audio file.	Increase volume. Ensure headphones are fully plugged in. Try playing a different audio file.
Cannot transfer files.	USB cable issue; driver issue; MicroSD card not inserted or faulty.	Try a different USB port or cable. Ensure MicroSD card is properly inserted. Reformat the MicroSD card if necessary (this will erase all data).
Screen is blank or flickering.	Device frozen; low battery.	Charge the device. Press the reset button.

9. Specifications

- **Model Name:** Xduoo 220631 Media Player Xdu-x2
- **Screen:** 0.96 Inches OLED
- **Supported Audio Formats:** MP3, WMA, APE, FLAC, WAV
- **Memory Storage:** Supports up to 32GB TF/Micro SD card
- **Battery Life:** Approximately 10 hours continuous playback
- **Connectivity:** USB (for charging/data), 3.5mm Aux
- **Color:** Black
- **Dimensions:** 70.5 x 40.5 x 12.5mm (approximate)
- **Weight:** 50g (approximate)
- **Body Material:** All Aluminum-Alloy
- **Included Components:** USB Cable

10. Warranty and Support

xDuoo products are designed and manufactured to the highest quality standards. For information regarding warranty coverage and technical support, please refer to the warranty card included with your purchase or visit the official xDuoo website. Keep your proof of purchase for warranty claims.
For further assistance, please contact xDuoo customer support.

© 2024 xDuoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JGWZSM3

More documents and user manuals: **https://manuals.plus/**