BOSCH 06008A7D00

Bosch Advanced Aquatak 140 High Pressure Washer Instruction Manual

Model: 06008A7D00

1. Introduction

This instruction manual provides essential information for the safe and effective operation, assembly, maintenance, and troubleshooting of your Bosch Advanced Aquatak 140 High Pressure Washer. Please read this manual thoroughly before using the appliance and retain it for future reference.

2. Safety Instructions

Always observe basic safety precautions to reduce the risk of fire, electric shock, and personal injury. Failure to follow these instructions may result in serious injury or damage to the product.

- **Electrical Safety:** Ensure the power supply matches the voltage specified on the rating plate. Always use a residual current device (RCD) when operating the pressure washer. Do not operate the appliance with a damaged cord or plug.
- **Water Connection:** Connect the pressure washer to a water supply that is clean and free of impurities. Do not connect to the potable water mains without a backflow preventer.
- **Personal Safety:** Wear appropriate personal protective equipment (PPE), including safety glasses and protective footwear. Never direct the water jet at people, animals, electrical equipment, or the appliance itself.
- **Operation:** Keep the work area clear of bystanders. Do not operate the pressure washer in explosive atmospheres or near flammable liquids. Always hold the spray gun firmly with both hands during operation.
- **Children and Pets:** Keep children and pets away from the appliance during operation and storage.

3. Package Contents

Carefully unpack the appliance and check that all items listed below are present and undamaged. If any parts are missing or damaged, contact your retailer.

- Bosch Advanced Aquatak 140 High Pressure Washer Unit

- High-Pressure Gun
- 8-meter High-Pressure Hose
- Variable Fan Jet Nozzle
- Rotary Nozzle
- Detergent Nozzle (550 ml capacity)
- Water Filter
- Power Cable (5 meters)
- Instruction Manual



Figure 3.1: The Bosch Advanced Aquatak 140 High Pressure Washer as packaged.



Figure 3.2: The pressure washer unit displayed with its various nozzles and detergent bottle.

4. Assembly and Setup

Follow these steps to assemble your pressure washer before first use.

1. **Attach the Handle:** Slide the handle into the designated slots on the main unit until it clicks into place.
2. **Connect the High-Pressure Hose:** Securely connect the 8-meter high-pressure hose to the outlet on the pressure washer unit and to the high-pressure gun. Ensure connections are tight to prevent leaks.
3. **Connect Water Supply:** Attach a garden hose (not supplied) to the water inlet on the pressure washer. Ensure the water filter is correctly installed in the inlet. Connect the other end of the garden hose to a water tap.
4. **Connect Power:** Plug the 5-meter power cable into a suitable electrical outlet.
5. **Select Nozzle:** Choose the appropriate nozzle for your cleaning task and attach it to the high-pressure gun.



Figure 4.1: Proper connection of the water supply hose to the pressure washer unit.



Figure 4.2: The pressure washer features wheels and an extendable handle for easy transport.

5. Operating Instructions

Before starting, ensure all connections are secure and the water tap is fully open.

1. **Purge Air:** Squeeze the trigger on the high-pressure gun until a steady stream of water emerges, indicating that all air has been purged from the system.

2. **Start the Appliance:** Switch on the pressure washer using the ON/OFF switch. The pump will start and build pressure.
3. **Begin Cleaning:** Direct the water jet at the surface to be cleaned, maintaining a safe distance. Adjust the nozzle or switch to a different nozzle as needed for various cleaning tasks.
4. **Detergent Application:** If using detergent, fill the detergent nozzle with appropriate pressure washer detergent. Attach the detergent nozzle to the gun. The pressure washer will automatically draw detergent and mix it with water at low pressure.
5. **Stopping Operation:** Release the trigger on the gun. The motor will stop. For longer breaks, switch off the appliance at the ON/OFF switch.
6. **Shutting Down:** After use, switch off the appliance, turn off the water tap, and squeeze the trigger to release any residual pressure in the system. Disconnect the power and water supply.



Figure 5.1: Demonstrating the effective use of the pressure washer for exterior cleaning tasks.

6. Maintenance and Storage

Regular maintenance ensures optimal performance and extends the lifespan of your pressure washer.

- **Cleaning the Water Filter:** Periodically check and clean the water filter located at the water inlet. Remove any debris to prevent blockages.
- **Nozzle Maintenance:** Clean nozzles regularly to ensure an even spray pattern. A clogged nozzle can reduce pressure and damage the pump.
- **Hose and Cable Management:** Utilize the integrated hose reel and cable storage to keep the high-pressure hose and power cable tidy and prevent damage.
- **Winter Storage:** In freezing temperatures, drain all water from the pump, hose, and accessories to prevent damage from ice expansion. Store the appliance in a frost-free environment.
- **General Cleaning:** Wipe down the exterior of the unit with a damp cloth. Do not use harsh chemicals.



Figure 6.1: The integrated hose reel facilitates neat storage and prevents hose damage.

7. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Motor does not start	No power supply; Faulty switch	Check power connection and fuse; Contact service center
Low pressure	Insufficient water supply; Clogged water filter; Air in pump; Worn nozzle	Ensure tap is fully open; Clean water filter; Purge air from system; Clean or replace nozzle
Water leaks	Loose connections; Damaged O-rings	Tighten all connections; Replace damaged O-rings
Motor stops during operation	Overheating; Thermal overload protection activated	Allow appliance to cool down; Check for blockages

8. Technical Specifications

- **Model:** Bosch Advanced Aquatak 140 (06008A7D00)
- **Engine Power:** 2100 W
- **Max. Pressure:** 140 bar
- **Max. Delivery Rate:** 450 l/h
- **Hose Length:** 8 m

- **Cable Length:** 5 m
- **Soap Tank Capacity:** 550 ml
- **Pump Type:** 3 cylinders
- **Weight (without accessories):** 17.6 kg
- **Item Weight:** 20 kg
- **Product Dimensions (L x W x H):** 41 x 37.5 x 81.5 cm
- **Noise Level:** 79 Decibels
- **Power Source:** Corded Electric
- **Color:** Black, Green
- **Certifications:** CE, CSA

9. Warranty and Support

Your Bosch Advanced Aquatak 140 High Pressure Washer comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including warranty period and coverage details.
For technical assistance, spare parts, or warranty claims, please contact your local Bosch service center or authorized dealer. You can find contact information on the official Bosch website or through your purchase documentation.

© 2025 BOSCH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question