Topeak Mountain TT Twin Turbo Mini Pump with Gauge

Topeak Mountain TT Twin Turbo Mini Pump with Gauge User Manual

1. Introduction

The Topeak Mountain TT Twin Turbo Mini Pump with Gauge is designed for efficient and accurate tire inflation for mountain, gravel, and touring bikes. This manual provides essential information for the proper setup, operation, and maintenance of your pump to ensure reliable performance.

2. Product Features

- **Efficient TwinTurbo System:** Dual-stroke design compresses air on both push and pull motions, doubling efficiency for rapid inflation up to 60 psi / 4 bar.
- **Large Analog Gauge:** Oversized 1-1/8” gauge provides easy-to-read, precise pressure measurements for reliable tire performance on any terrain.
- **Universal Valve Fit:** Works seamlessly with Presta, Schrader, and Dunlop valves and includes an integrated dust cap to keep components clean.
- **Durable Trail Build:** Aluminum barrel with polymer thumb lock and handle ensures dependable performance and resistance to wear.
- **Secure On-Bike Mount:** Side-mount bracket keeps the pump easily accessible while preventing movement during rides or transport. The pump dimensions are 10” L x 2” W x 1.6” H.



Image: The Topeak Mountain TT Twin Turbo Mini Pump, showing its compact design and integrated pressure gauge. The pump features a black aluminum barrel and a clear analog gauge for precise readings.

3. Setup

3.1 Mounting the Pump

1. Locate the side-mount bracket and secure it to your bike frame using the provided screws, typically near the water bottle cage mounts.
2. Place the pump into the bracket and secure it with the integrated strap to prevent movement during rides.



Image: The Topeak Mountain TT Twin Turbo Mini Pump securely mounted on a bicycle frame, demonstrating its compact fit alongside a water bottle cage. The pump is held in place by a black strap.

3.2 Valve Compatibility (Presta, Schrader, Dunlop)

The pump head is designed to be compatible with Presta, Schrader, and Dunlop valves. The internal components of the pump head can be reversed to switch between Presta/Dunlop and Schrader configurations. Refer to the diagram below for proper orientation.



Image: A close-up view of the Topeak Mountain TT Twin Turbo Mini Pump head attached to a bicycle tire valve, showing the thumb lock engaged. The integrated gauge is visible, indicating tire pressure.

4. Operating Instructions

4.1 Inflating Tires

1. Ensure the pump head is configured for your tire's valve type (Presta, Schrader, or Dunlop).
2. Remove the valve cap from your tire.
3. Firmly press the pump head onto the valve stem.
4. Flip the thumb lock lever to secure the pump head to the valve.
5. Begin pumping. The TwinTurbo system inflates on both push and pull strokes.
6. Monitor the integrated gauge to reach your desired tire pressure (up to 60 PSI / 4 BAR).
7. Once the desired pressure is reached, flip the thumb lock lever to release the pump head.
8. Carefully remove the pump head from the valve and replace the valve cap.



Image: A hand holding the Topeak Mountain TT Twin Turbo Mini Pump, actively inflating a bicycle tire. The integrated gauge clearly displays the pressure, allowing for precise inflation.

4.2 Video Overview

[redacted]

Video: An official overview of the Topeak Mountain TT G Bike Pump with Gauge, demonstrating its features, valve compatibility, and the Twin Turbo inflation technology in action. This video provides a visual guide to the pump's functionality.

5. Maintenance

- Keep the pump clean from dirt and debris, especially the pump head and shaft.
- Periodically inspect the rubber seals and O-rings for wear and tear. Replace if necessary to maintain optimal performance.
- Store the pump in a dry place to prevent corrosion.
- Ensure the dust cap is always on the valve head when not in use to protect internal components.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Air leaks from valve connection	Pump head not securely attached or incorrect valve configuration.	Ensure thumb lock is fully engaged. Verify pump head is configured for the correct valve type. Inspect rubber seals for damage.
Pump feels stiff or difficult to operate	Lack of lubrication or internal debris.	Clean the pump shaft and apply a small amount of silicone-based lubricant to the O-rings.
Inaccurate gauge reading	Gauge malfunction or extreme temperature changes.	Compare reading with another reliable gauge. If consistently inaccurate, contact customer support.
Pump not inflating tire	Valve core issue or significant internal damage.	Check if the valve core is loose or damaged. Ensure the pump head is properly sealed. If issues persist, seek professional service.

7. Specifications

Feature	Detail
Brand	Topeak
Model	Mountain TT Twin Turbo Mini Pump with Gauge
Material	Aluminum barrel, Polymer handle
Maximum Pressure	60 PSI / 4 BAR
Valve Compatibility	Presta, Schrader, Dunlop
Gauge Type	Integrated Analog, 1-1/8”
Dimensions (L x W x H)	10” x 2” x 1.6”
Item Weight	6.8 Ounces
Included Components	Bike pump, Side-mount bracket

8. Warranty

This Topeak product is covered by a**2-Year Manufacturer's Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, abuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

9. Support

For further assistance, technical support, or warranty inquiries, please visit the official Topeak website or contact their customer service department. You can find more information and contact details on the Topeak Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question