Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Easytry123 Easytry3449

Easytry123 Replacement Remote Control User Manual

For Optoma DLP Projectors (Models: T662, T763, T764, T862, EX611ST, EW609, EX635, EX400, EW400)

Introduction

This document provides essential information for the proper use and maintenance of your Easytry123 replacement remote control. This remote is designed to be compatible with specific Optoma DLP projector models. Please read these instructions carefully to ensure optimal performance and longevity of your device.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off in the direction indicated by the arrow.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Back view of the remote control, showing the battery compartment. The compartment is located on the lower half of the remote's back, with a textured grip area and a yellow label containing model information.

2. Initial Use

This is a replacement remote control and typically does not require programming. Once batteries are installed, point the remote directly at your compatible Optoma DLP projector and begin operation.

Operating Instructions

Familiarize yourself with the buttons on your remote control. Below is a general overview of common functions. Specific functionality may vary slightly depending on your projector model.



Figure 2: Front view of the Easytry123 remote control. The remote is black with various gray and green buttons. Key buttons include Power (red), Laser (green), directional pad (Up, Down, Left, Right, Enter), Volume, Source, Menu, Keystone, Brightness, and numerical input buttons.

- **Power Button (Red):** Turns the projector on or off.
- **Laser Button (Green):** Activates the laser pointer function (if available on your projector).
- **Directional Pad (Up, Down, Left, Right, Enter):** Navigates through menus and confirms selections.
- **Volume (+/-):** Adjusts the audio output level.
- **Source:** Cycles through available input sources (e.g., HDMI, VGA, S-Video).
- **Menu:** Opens or closes the projector's on-screen display (OSD) menu.
- **Keystone (+/-):** Adjusts the keystone correction to square the image.
- **Brightness (+/-):** Adjusts the image brightness.
- **Numerical Buttons (0-9):** Used for direct input or selecting specific options.

- **Page+ / Page-:** Used for presentation control.
- **Re-SYNC:** Resynchronizes the image signal.
- **Freeze:** Pauses the current image display.
- **AV Mute:** Mutes both audio and video output.

Maintenance

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops functioning. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote.

Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are correctly installed with proper polarity.
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote and the projector's IR receiver.
  - Ensure you are within the effective range of the projector's IR receiver.
- **Limited functionality:**
  - Verify that your projector model is listed as compatible with this remote control.
  - Some advanced functions may not be supported by all replacement remotes or projector models.

Specifications

Model Number	Easytry3449
Power Source	2 x AAA Batteries (not included)
Controller Type	Button Control
Special Feature	Ergonomic Design
Compatibility	Optoma DLP Projectors: T662, T763, T764, T862, EX611ST, EW609, EX635, EX400, EW400

Warranty Information

As a replacement item, specific warranty details are typically provided by the seller at the time of purchase. Please refer to your purchase documentation or contact the seller directly for information regarding warranty coverage.

Support

For further assistance or technical support, please contact the seller from whom you purchased this remote control. They can provide specific guidance related to your purchase and product functionality.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question