Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Surpars House S0180032

Surpars House Elegant Mini Chandelier User Manual

Model: S0180032

1. Introduction

Thank you for choosing the Surpars House Elegant Mini Chandelier. This plug-in crystal pendant light is designed to add a touch of elegance to your indoor spaces. This manual provides essential information for the safe installation, operation, and maintenance of your new chandelier.



Image 1.1: The Surpars House Elegant Mini Chandelier, Model S0180032, illuminating a bedside area.

2. Safety Information

Please read all safety instructions before installation and use. Keep this manual for future reference.

- Ensure the power outlet matches the chandelier's voltage (120V).
- Do not operate with a damaged cord or plug.
- Do not immerse the chandelier or cord in water or other liquids.

- This product is for indoor use only.
- Always unplug the chandelier from the power outlet before cleaning or replacing the bulb.
- Use only E12 base bulbs, maximum 60 watts.
- Keep away from flammable materials.

3. Package Contents

Carefully unpack your chandelier and check for the following items:

- 1 x Surpars House Elegant Mini Chandelier (with pre-assembled crystals)
- 1 x Power Cord with In-line On/Off Switch and Standard American Plug
- Mounting Hardware (hooks, anchors)

Note: E12 light bulb is not included and must be purchased separately.

4. Setup and Installation

The Surpars House Mini Chandelier is designed for easy setup. The crystal components are pre-assembled, requiring no complex wiring.

1. **Select Location:** Choose a suitable indoor location where you wish to hang the chandelier. Ensure there is a power outlet nearby and the cord can reach without tension.
2. **Install Bulb:** Screw in one E12 base bulb (max 60W) into the chandelier's socket. Do not overtighten.
3. **Mounting:**
    - Determine the desired hanging height and position.
    - Using the provided mounting hardware (hooks and anchors), securely attach the hook to the ceiling or wall. For drywall, use appropriate anchors.
    - Hang the chandelier from the installed hook.
4. **Route Cord:** Route the 180-inch power cord neatly to the nearest power outlet. You may use additional cord clips (not included) to secure the cord along the wall or ceiling for a cleaner look.
5. **Plug In:** Insert the standard American plug into a 120V power outlet.

Your browser does not support the video tag.

Video 4.1: Official seller video demonstrating the ease of setting up the chandelier. This video shows the process of hanging the light and plugging it in.



Image 4.1: Diagram showing the dimensions of the chandelier: 7 inches in diameter and 11.8 inches in height, with a 180-inch cord.

5. Operating Instructions

To operate your Surpars House Mini Chandelier:

1. Ensure the chandelier is properly installed and plugged into a live power outlet.
2. Locate the in-line on/off switch on the power cord.
3. Press the switch to the "ON" position to illuminate the chandelier.
4. Press the switch to the "OFF" position to turn off the chandelier.

6. Maintenance

Regular maintenance will help keep your chandelier looking its best.

- **Cleaning:**

- Always unplug the chandelier before cleaning.
- Dust the metal frame and crystals gently with a soft, dry cloth.
- For more thorough cleaning of crystals, lightly dampen a soft cloth with water or a mild glass cleaner (avoid spraying directly onto the chandelier). Wipe crystals and dry immediately.
- Do not use abrasive cleaners or solvents, as these may damage the finish.

- **Bulb Replacement:**
  - Ensure the chandelier is unplugged and the bulb has cooled completely.
  - Unscrew the old E12 bulb and replace it with a new E12 bulb (max 60W).
  - Plug the chandelier back in.



Image 6.1: A detailed view of the clear crystal embellishments and gold-finished frame of the chandelier.

7. Troubleshooting

If you encounter any issues with your chandelier, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chandelier does not light up.	• Not plugged in. • Power outlet is not active. • Bulb is loose or burnt out. • In-line switch is off.	• Ensure the plug is fully inserted into the outlet. • Test the outlet with another device. • Tighten or replace the E12 bulb. • Ensure the in-line switch is in the "ON" position.
Light flickers.	• Loose bulb. • Faulty bulb.	• Tighten the E12 bulb. • Replace the E12 bulb.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Detail
Brand	Surpars House
Model Number	S0180032
Color	Gold Plug in
Material	Glass
Style	Modern
Light Fixture Form	Chandelier
Room Type	Indoor
Power Source	Corded Electric
Voltage	120 Volts
Wattage	60 Watts (Max)
Bulb Base	E12
Switch Type	Push Button (In-line)
Cord Length	180 inches (4.8 meters)
Item Dimensions (Diameter x Height)	7" x 11.8" (18cm x 30cm)
Item Weight	2 pounds
Installation Type	Plug-in
Embellishment Feature	Crystal

9. Warranty Information

The Surpars House Elegant Mini Chandelier (Model S0180032) comes with a**2-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper installation.
Please retain your proof of purchase for warranty claims.

10. Customer Support

For any questions, technical assistance, or warranty claims, please contact the retailer where you purchased this product or visit the official Surpars House website for support contact information.
You can also visit the Surpars House Store on Amazon for more product information and support resources.

© 2026 Surpars House. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JJ9WSD5

More documents and user manuals: **https://manuals.plus/**